


KitchenAid®

14-CUP FOOD PROCESSOR

MODELS:

KFP1466WH0 (White)
KFP1466OB0 (Onyx Black)
KFP1466ER0 (Empire Red)
KFP1466CU0 (Contour Silver)
KFP1466QG0 (Liquid Graphite)
KFP1466SZ0 (Slate)

PROCESADOR DE ALIMENTOS KFP1466







PROCESADOR DE ALIMENTOS KFP1466

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10694199	Use and Care Guide
2	W10451326	Adapter, Motor
3	W10451327	Support, Bearing
4	W10723417	User Interface Assembly
5	W10723418	PCB Assembly

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Housing, Upper
	W10723449	White
	W10723447	Onyx Black
	W10723450	Empire Red
	W10723453	Contour Silver
	W10723454	Liquid Graphite
	W10760373	Slate
7	W10724212	Button, Adjust
8	W10724213	Lever, Adjust Control

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10724217	Motor, with Gearbox
10	W10451329	Cord, Power (2-Prong)
11	W10723404	Band, Trim
12	W10451322	Block, Terminal
13	W10723400	Base, Housing
14	W10451320	Foot
15	W10723405	Bearing, Ball

PROCESADOR DE ALIMENTOS KFP1466









PROCESADOR DE ALIMENTOS KFP1466

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10724215	Dicing Assembly
2	W10723406	Disc, Slicing
3	W10723459	Brush, Adjust Shred Disc
4	W10451463	Blade, Multi- Purpose

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10723411	Blade, Dough
6	W10723412	Box, Accessory
7	W10451465	Disc, Shredding
8	W10723416	Adapter, Common

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10723414	Adapter, Shredding (Baffle)
10	W10723409	Blade, Mini
11	W10723413	Adapter, Slicing Shaft

PROCESADOR DE ALIMENTOS KFP1466





PROCESADOR DE ALIMENTOS KFP1466

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10461924	Pusher, Round
2	W10461925	Pusher, Regular
3	W10723407	Pusher, Wide Mouth
4	W10723444	Lid Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10480168	Gasket, Lid
6	W10723408	Bowl, Mini
7	W10723445	Bowl, 14-Cup

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10724214	Lid, Dicing Assembly
		OPTIONAL PARTS NOT ILLUSTRATED
	W10723415	Bowl, Chef's