

KitchenAid®

6 QT. STAND MIXER


MODELS:

KP26M9XCCU5 (Contour Silver)

KP26M9XCER5 (Empire Red)

KP26M9XCOB5 (Onyx Black)


KP26M9XCWH5 (White)




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing
	W10327951	Contour Silver
	9705300	Empire Red
	9705296	Onyx Black
	9703311	White
2		Trim Band
	W10870719	Platinum
3		Lower Gearcase
	W10327958	Contour Silver
	9706331	Empire Red
	9706311	Onyx Black
	9706047	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Planetary
	W10327955	Contour Silver
	9708180	Empire Red
	9708176	Onyx Black
	9708172	White
5		Bowl Support and Pins
	W10327966	Contour Silver
	9705360	Empire Red
	9705356	Onyx Black
	9703674	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Column and Pins
	W10328003	Contour Silver
	9705324	Empire Red
	9705320	Onyx Black
	9703673	White
7		Base & Foot Assembly
	W10328017	Contour Silver
	9705348	Empire Red
	9705344	Onyx Black
	9703690	White



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Gearcase Motor Housing (Refer to Color Variation Parts Page)	12	16897	Bearing, Lower Center	25	W10247536	Motor, 120 Volt
2	9707983	Cap, Attachment Hub (Nickel)	13	9703339	Gear, Internal	26		Cord, Power
3		Band, Trim (Refer to Color Variation Parts Page)	14	3400814	Screw		W10325654	White
4	9709125	Transmission Housing	15	9706247	Seal, Motor Shaft		W10325656	Black
5	9703338	Gear, Attachment Hub Level	16		Bearing	28		Planetary Assembly (Refer to Color Variation Parts Page)
6	9709511	Gasket, Transmission		W10170080	Front	29	W10323379	Washer, Fiber
7	9703680	Clip, Retaining	17	9703445	Bearing, Thrust	30	9703438	Ring, Retaining
8	9703337	Gear, Bevel	18	9709231	Gear, Worm	31	9706090	Washer
9	9707223	Pin, Retaining	19		Control Assembly	32	9707627	Gear, Pinion
10	9706529	Gear, Worm Follower		9706648	Control with Black Knob	33	8533910	Washer
11		Lower Gearcase (Refer to Color Variation Parts Page)	21	3400200	Screw	34	9708191	Shaft, Agitator
			22	3400617	Screw	35	9704677	Pin, Groove
			23		Thumb Screw			
				9709194	Black			
			24	9703312	Sensor, Hall Effect			



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10862776	Use & Care Guide
2	3400200	Screw
3	W10245586	Bowl, 6 Quart
4	240185	Pin, Retaining Bowl
5	W10504114	Clip, Bowl Retainer
6	3400018	Screw
7		Bowl Support (Refer to Color Variation Parts Page)
8		Base and Foot Assembly (Refer to Color Variation Parts Page)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	9708649	Foot
10	9703307	Ring, Retaining
11	W10598835	Rod, Bowl Lift
12	9237	Spring, Lift Rod
13	9703439	Washer
14	8533907	Nut
15		Column Assembly (Refer to Color Variation Parts Page)
16	9703485	Beater, Flat (Burnished)
17	W10536041	Hook, Dough (Burnished)
18	9706885	Arm, Bowl Lift

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10352664	Whip, Wire
20	9703426	Cam, Adjusting
21	3400863	Screw
22	W10598836	Handle, Bowl Lift
23	W10769141	Cap, Handle
24	W10617049	Shield, Pouring (Wide)