

KitchenAid®


BOTTOM MOUNT FRENCH DOOR REFRIGERATOR

MODELS:

KRFC704FBS02 (Black Stainless)

KRFC704FSS02 (Stainless Steel)

REFRIGERADOR KRFC704FBS02



REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11190777	Tech Sheet (English)
	W11190778	Tech Sheet (French)
	W11307646	Use and Care Guide
	W11112950	Energy Guide
2	12990302	Screw
3	W10840312	Block, Pivot
4	W10838044	Pad, Sound
5	W11093037	Control, Electronic
6	W10415341	Gasket, HV Box
7		Assembly, Roller
	W11084045	Left Hand
	W11084046	Right Hand
8	W10846099	Brake, Roller
9	12990521	Screw
10		Hinge, Top
	W11032616	Left Hand
	W11032620	Right Hand
11	W10673840	Screw (Stainless)
12		Cover, Top Hinge
		Left Hand
		(Includes Foil)
	W10868791	Black
	W10921527	Grey
13		Cover, Top Hinge
		Right Hand
	W10895446	Black
	W10895492	Grey
14	W10731474	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15		Hinge, Center
		Left Hand
	W10691674	Black
	W10816322	Grey
16		Hinge, Center
		Right Hand
	W10691700	Black
	W10816323	Grey
17		Cover, Corner
	12587703B	Black
	W10868482	Grey
18	W11095287	Valve, Water
19	W11105994	Switch, Reed
20	W10709365	Screw
21		Divider, Air
	W10878918	Rear
	W10878920	Bottom
22		Grille, Toe
	W10821308	Black
	W10821309	Grey
23	12992601	Screw
24		Assembly, Outer Air
		Tunnel (Includes
		Gasket)
	W10835554	Black
	W10838744	Grey
25	W10141645	Screw
26	12990511	Screw
27	W10831587	Bushing
28	W10754144	Cover, Control Box
29	W10141645	Screw


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
30	W10669259	Cover, Unit
31	M0108107	Clamp, Tube
32	W10853597	Tube, Icemaker Water
		(Includes Seal)
	W10853599	Tube, Dispenser
		water (includes Seal)
33	W10768379	Lid, HV
34	W10705239	Retainer, Door
35		Cabinet (Not a
		Servicable Part)
36	549193	Clamp, Power Cord
37		Assembly, Inner Air
		Tunnel (Includes
		Gasket)
	W10835557	Black
	W10838745	Grey
38	W10858468	Assembly, Jumper
		Wire
39	W10208592	Cover, Valve
40	12990702	Screw
41	W11243631	Gasket

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR KRFC704FBS02



REFRIGERADOR KRFC704FBS02

Illus.
No. **Part No.** **Description**

1		Liner (Not A Serviceable Part)
2	W10708473	Housing, Water Tank
3	W10786645	Strip, LED
4	W11024082	Reservoir, Water
5	W10908836	Valve, Dual Water
6	W11024083	Housing, Water Filter
7	W10900011	Cover, Water Valve
8	W10789102	Tube, Water Filter
9	W10815965	Cover, Cooling Duct
10	W11259417	Cover, Tower
11	W10680605	Filter, Water
12	W10315189	Filter, Air
13	W10708474	Bracket, Filter
14	W10119266	Screw
15	12990518	Screw

Illus.
No. **Part No.** **Description**

16	W10839501	Insulation, Under Filter
17	W10817432	Assembly, Air Filter
18	W10856502	Cover, Air Filter
19	W10906507	Assembly, Manifold Jumper Wire
20	W10813883	Cap, Filter
21	W11327989	Assembly, Evaporator Cover (Includes Fan Motor, Wire Assembly and Thermistor)
22	W11130330	Assembly, Evaporator
23	W10906201	Strip, LED
24	W10831305	Insulator, Foam
25	W10815960	Base, Tower Cover
26	W10848895	Harness, Air Tower Jumper
27	12990501	Screw


Illus.
No. **Part No.** **Description**

28	W10877761	Heater, Filter
29	W10901792	Gasket, Sealing
30	W10818463	Gasket, Evaporator Air Dam
31	W11090564	Assembly, Heat Shield
32	W10921470	Gasket, Heat Shield
33	10623002	Clip, Evaporator
34	W11127384	Heater, Defrost
35	W10909562	Clip, Evaporator Heater
36	W11307147	Cover, Filter
37	W10280385	Thermistor

FOLLOWING PARTS
NOT ILLUSTRATED

W10871610 Assembly, Valve Wire


REFRIGERADOR KRFC704FBS02



REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	9	W10683507	Clip, Defrost Heater	16	B8381501	Gasket, Drain
2	W11032200	Assembly, Evaporator	10	W10668191	Shield, Heat	17	W10797088	Thermistor
3	W10843353	Assembly, LED Light Module	11	W10683540	Gasket, Drip Tray Rear	18	W10770923	Seal, Crisp Front
4	W10772353	Assembly, Evaporator Cover (Includes Fan Motor and Wire Assembly)	12		Dam, Air	19	W10685479	Assembly, Icebox Fan
				W10668201	Left Hand	20	W10911358	Assembly, Evaporator Jumper Wire
				W10668198	Right Hand			
			13	W10858452	Assembly, Evaporator Heater Wire (Includes Thermistor)			
5	12990511	Screw						
6	W10668195	Heater, Defrost	14	W10503218	Assembly, Drain Funnel			
7	W10847855	Switch, Light						
8	10623002	Clip, Evaporator	15	M0500703	Seal			

REFRIGERADOR KRFC704FBS02



Illus.
No. **Part No.** **Description**

1 Door, Refrige
 Left Hand
W11110293 Black Stainles
 order item # 1
W11110292 Stainless (Als
 item # 18)

2 Door, Refrigerator
 Right Hand
W10798252 Black Stainless
W10831951 Stainless

3 W10238319 Screw

4 **W10798124** **Assembly, Ice**

5 ~~W10763415~~ ~~Door~~
 ~~Bracket, Door Stop~~

6 Mullion, Door

W11034029 Black

W11034034 Grey

7 12990204 Screw

8 Handle, Door

9

Illus.
No. **Part No.** **Description**

7 12990204 Screw

8 Handle, Door

W11202867 Stainless

9 W10810008 Switch, Rocker Arm

18 **W11227903** **Assembly, User**
 Interface

19 **W10828418** **Gasket, Cooling Duct**

20 Bin, Door

W10776705 Gallon

21 **W10883965** **Tube, Water**

22 Gasket, Door

W10917312 Black

W10917313 Grey

23 **W10823512** **Trim, Gallon**

24 **W10795526** **Assembly, Utility**
 Bin

Illus.
No. **Part No.** **Description**

25 W10795523 Base, Utility Bin


26 W10803630 Door, Utility Bin
 (Includes Gasket)

27 W10795525 Gasket, Utility Bin

28 W10795524 Lid, Utility Bin



29 W10917894 Assembly, Fill Tube
 (Icemaker)

REFRIGERADOR KRFC704FBS02



1	Door, Refrigerator	
	Left Hand W11110293 Black Stainless (Also order item # 18)	
	W11110292 Stainless (Also orde	
2	Door, Refrigerator	
	Right Hand	
	W10798252 Black Stainless	
	W10831951 Stainless	
3	W10238319 Screw	
4	W10798124 Assembly, Ice Door	
5	W10763415 Bracket, Door Stop	
6	Mullion, Door	
	W11034029 Black	
	W11034034 Grey	
7	12990204 Screw	
8	Handle, Door	
	W11202867 Stainless	
9	W10810008 Switch, Rocker Arm	


10	Bumper, Door	
	W10407187 Black	
	W10798308 Grey	
11	W10518672 Badge	
12	W10460893 Screw	
13	W10795606 Trivet, Ice Compartment Door	
14	Bin, Door	
	W10806697 Medium	
15	W10834282 Retainer, Door Duct	
16	W10853441 Gasket, Ice Door	
17	Closer, Door	
	W10872968 Left Hand	
	W10872969 Right Hand	
18	W11227903 Assembly, User	
19	W10828418 Gasket, Cooling Duct	
20		



REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Door Gasket)	7	12990518	Screw	15		Gasket, Door
	W10798129	Black Stainless	8	W11102087	Assembly, Top Pan		W10436253	Black
	W10832272	Stainless	9	W10277361	Collar, Gear		W10868406	Grey
2		Handle, Door	10	12991401	Screw	16	W10697812	Bar, Support
	W11251055	Stainless	11	W10469177	Support, Pan	17	W10874022	Roller
3	W10460893	Screw	12	489443	Screw (Stainless)	18	W10839803	Axle, Roller
4	W10851956	Shaft, Rack	13	W10795835	Assembly, Upper Half Pan	19	W10830659	Rail, Guard
5		Assembly, Bracket	14		Stop, Pan	20	W10837296	Roller
	W10795843	Left Hand		W10795820	Left Hand			
	W10795847	Right Hand		W10795822	Right Hand			
6	W10795851	Assembly, Bottom Pan						

REFRIGERADOR KRFC704FBS02




REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw
2	W10820084	Screw
3	W10658357	Baseplate
4	12990511	Screw
5	W10860180	Assembly, Drain Extension
6	W11084143	Assembly, 3 Way Valve
7	W10838081	Pad, Sound
8	W10877573	Tray, Evaporator
9	W10683708	Gasket, Condenser Fan
10	W10697007	Bolt
11	W10697017	Clip, Retaining
12	W11317283	Assembly, Orion Box (Include Wiring Harness for Compressor and Power Cord)
13	W10774846	Roller
14	12992101	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10836504	Grommet, Compressor
16	W11199416	Condenser
17	W10391376	Bracket, Valve
18	W11198954	Cover, Housing
19	W10141645	Screw
20	W10792503	Filter, EMI
21	W10701009	Cover, Terminal
22	2169104	Insulation, Sound Deadening
23	W11199420	Assembly, Suction Tube
24	W10858511	Harness, Unit (Condenser Fan)
25	W10805035	Drier (Service Drier Without Dye)
26	W11393142	Compressor
27	W10883082	Assembly, Condenser Fan
28	12477202	Axle, Roller

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
29	W10709318	Coil, 3 Way Valve
30	W10884826	Grommet, Condenser
31	W10735062	Tube, Process
		FOLLOWING PARTS NOT ILLUSTRATED
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
		REFRIGERANT CHARGE
		4.50 oz. (R-134A)


REFRIGERADOR KRFC704FBS02



REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10794563	Base, Pantry	13	W10663641	Spacer, Handle	28	W10794565	Support, Pantry
2	W10696184	Ring, Handle	14	W10804533	Glass, Crisper Cover	29	W10794557	Cover, Pantry
3	W11347069	Assembly, Filter Door	15		Glide, Crisper	30	W10794250	Bar, Support
4	W10792132	Insulation, Filter Housing		W10816001	Left Hand	31	W10834719	Cover, Wiring Harness
5	2223877	Latch, Push		W10814857	Right Hand	32	W10779301	Assembly, Pantry Wire (Includes Thermistor)
6	W10793467	Assembly, 15" Full Shelf	16	W10903881	Handle	33	W10794550	Assembly, Center Support
7	W11116719	Assembly, 12" Full Shelf	17	W10918349	Assembly, Crisper Pan	34	W10794547	Frame, Crisper Cover
8	W10794646	Assembly, Tuck Shelf	18	W10758550	Assembly, Light	35	W10794336	Gasket, Crisper Cover (Rear)
9		Assembly, Block	19	W10903879	Screw	36	W10794242	Gasket, Crisper Cover (Front)
	W10817922	Front Left/Back Right	20	W10826105	Assembly, Produce Preserver	37	W10835866	Jumper, Crisper LED
	W10817921	Front Right/Back Left	21	W10818078	Pan, Under Shelf	38	W10854845	Cover, Wiring Harness
10	W10898655	Pan, Pantry	22	W10794571	Glass, Platter	39		Support, Side
11	W11082108	Assembly, Platter Shelf	23	W10840918	Flange, Side Support		W10794553	Left Hand
12		Glide, Platter	24	W10840920	Knob, Side Support		W10794555	Right Hand
	W10843722	Left Hand	25	W10795580	Assembly, Herb Storage (Includes Lid and Gasket)	40	W10834285	Screw (Grey)
	W10814862	Right Hand	26	W10815941	Bar, Pantry Support	41	W10847999	Screw
			27	W10804977	Screw			





REFRIGERADOR KRFC704FBS02



REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	7		Tray, Drip	15	W10696713	Gasket, User Interface Adapter
2	W11293313	Assembly, User Interface	7	W10792138	Black	16	W10696704	Assembly, Ice Door Motor Bracket
3		Wall, Dispenser False	8		Ring, Trim	17	W10663699	Pad, Sound
	W10792135	Black	8	W10792136	Chrome	18	W10752689	Heater, Dispenser
4		Paddle, Water Dispenser	9		Paddle, Ice Dispenser	19	W10757499	Bracket, User Interface Adapter
	W10889223	Chrome	10	W10403752	Switch, Limit	20	W10809296	Guide, Light
5		Seperator	11	W10672578	Spring, Torsion			
	W10889235	Black	12	W10663682	Spring, Torsion			
6	W10837350	Grate, Drip	13	W10704135	Assembly, Paddle Jumper Wire			
			14	W10888235	Gasket			

REFRIGERADOR KRFC704FBS02





REFRIGERADOR KRFC704FBS02

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10793257	Plate, Ice Chute
3	W10291905	Gasket
4	W10903434	Assembly, Ice Container

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10678163	Shaft-Motor
6	W11185741	Motor, Dispenser
7	8281163	Screw (Stainless)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W11026494	Assembly, Icemaker
9	W10280386	Thermistor

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet
	IC13B	Icemaker Kit

TORX SCREW WRENCH

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key