


REFRIGERADOR KRFF305ESS03




REFRIGERADOR KRFF305ESS03

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10544193	Tech Sheet
	W11298859	Use and Care Guide
	W11308946	Energy Guide
2	W11046934	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)
3	12698403	Plate, Pivot
4	B5759655	Gasket
5		Cover, Right Hinge
	12962302AP	Grey
6		Cover, Left Hinge (Includes Foil)
	12962301AP	Grey
7	M0108107	Clamp, Tube
8	12990504	Screw
9	12992602	Screw
10		Hinge, Top
	12963204ED	Left Hand
	12963205ED	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10673840	Screw (Stainless)
12	12957702SP	Lid, HV Box
13		Cabinet (Not A Serviceable Part)
14	12992403	Screw
15		Hinge, Center (Left)
	W10740150	Grey
16		Hinge, Center (Right)
	W10740146	Grey
17		Cover, Corner
	12587703AP	Grey
18	12961602	Cover, Control Box
19		Assembly, RollerW10515763 Left Hand W10515762 Right Hand
20	W10709365	Screw
21		Shim, Hinge
	12999501	Left Hand
	12999502	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
22		Grille, Toe
	W10534155	Grey
23	12957801SP	Gasket, HV Box
24	W10420083	Valve, Water Inlet
25	12990511	Screw
26	12726003	Cover, Water Line
27	W10208593	Guard, Dual Water Valve
28	688983	Screw
29	W10528513	Sweep, Dual Tube
30	W10211855	Cover, Unit
31	W10317076	Board, HV Control
32	A3076901	Plug, Button
33	W10658542	Block, Fill Tube
34	W10141622	Brake, Roller
35	12990702	Screw
36	12991604	Screw

REFRIGERADOR KRFF305ESS03




REFRIGERADOR KRFF305ESS03

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10464764	Module, Light
3	W10632601	Overlay
4	W10464767	Module, Control
5	W10746274	Board, Control
6	W10847853	Switch, Light
7	W11132917	Cover, Light
8	W10443023	Housing, Light
9	W11251749	Light Module, LED
10	10685510	Gasket, Seal
11	12806801	Insert, Damper Cover
12	12990604	Screw
13	12806701	Cover, Damper
14	13012402	Insulation, Damper
15	W10594329	Control, Damper

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10117358	Insulation, Water Tank
17	12704801	Plate, Filter
18	W11308018	Head, Water Filter (Includes Bypass Cartridge)
19	W11256384	Filter, Water
20	12568001	Cover, Filter
21	12990512	Screw
22	B8390302	Clip, Facade
23	W10585703	Facade, Dispenser
24	W10585699	Plate, Dispenser
25	12575501	Switch, Limit
26	W11031909	Guide, Waterline
27	12251001	Clip, Water Tube
28	12707005	Facade, Dispenser (Top)
29	W11097710	Tank, Water

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
30	61006182	Union, Water
31	12664501SP	Cartridge, Bypass
32	12990513	Screw
33	W10190541	Mount, Crisper Support
Following Parts Not Illustrated		
	W10224292	Harness, Controls (Refrigerator)


REFRIGERADOR KRFF305ESS03



REFRIGERADOR KRFF305ESS03

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	15	13058002	Clip, Evaporator Motor			
2	A3189392	Gasket, Foam	16	W10847849	Switch, Light			
3	W11261524	Guide, Fill Tube	17	12002497	Gear			
4	12791419SP	Thermistor	18	W10662407	Assembly, Drain Funnel			
5	13062901	Motor, Evaporator	19	M0500703	Seal			
6	W11260635	Arm, Shut Off	20	A3189396	Gasket			
7	W10157765	Diverter, Air	21	B8381501	Gasket, Drain			
8	12815301	Cover, Thermistor	22	13024803	Grille, Freezer Air			
9	W11251749	Light Module, LED	23	13057901	Shroud, Evaporator Fan			
10	W10289690	Cover, Icemaker	24	2169142	Blade, Fan			
11	W10308416	Cover, Evaporator	25		Bracket, Door			
12	12990511	Screw		W10330991	Left Hand			
13	W10150583	Grommet, Fan Motor		W10330993	Right Hand			
14	W10277025	Module, Light	26	12990521	Screw			
			27		, Basket			
				W10280608	Left Hand			
				W10280613	Right Hand			
			28	W10860513	Slide, Door			
			29		Adapter, Slide			
				W10284684	Left Hand			
				W10284685	Right Hand			
			30	12990501	Screw			
			31	W10802332	Shaft, Rack			
			32		Rack, Side			
				W10516603	Left Hand			
				W10516602	Right Hand			
			33	W10171529N	Pan, Ice			
			34	W10793298	Assembly, Icemaker (Complete)			
			35	W10793621	Harness, Icemaker Wire			

REFRIGERADOR KRFF305ESS03




REFRIGERADOR KRFF305ESS03

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	13107888S	Stainless
2		Door, Right
	13107887S	Stainless
3	12804701SP	Door, Dairy
4	12369502SP	Tray, Dairy
5	W10371194	Bucket, Medium
6	12990204	Screw
7	W10460893	Screw
8		Gasket, Door
	W10830162	Grey
9	W10449760	Gripper, Gallon

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10450021	Gripper, Medium
11		Handle, Door
	W10775000	Stainless
12	W10289497	Bucket, Gallon
13		Nameplate
	W10765861	Grey
14		Mullion, Door
	12722803APN.	Grey
15	12990504	Screw
16		Closure, Door
	12028505AP	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17		Stop, Door
	12968202AP	Grey
18		Latch, Door Closer
		Right Hand
	W10833739	Grey
19		Latch, Door Closer
		Left Hand
	W10833741	Grey
20	12990519	Screw
21	12996601	Clip, Bushing

REFRIGERADOR KRFF305ESS03




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12977880S	Door, Freezer Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10772582	Handle, Door Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10443320	Gasket, Door Grey
4	W10460893	Screw

REFRIGERADOR KRFF305ESS03



REFRIGERADOR KRFF305ESS03

Illus.
No. **Part No.** **Description**

1	12992301	Screw
2	12825803	Blade, Fan
3	W10480111	Basepan
4	12990511	Screw
5	W10350564	Capacitor
6	W10233569	Tube, Discharge
7	W11174745	Harness, Evaporator Heater
8	W10655368	Pan, Drain
9	W10622701	Screw
10	12729123	Heater, Defrost
11	W10216075	Strap, Bale
12	W10796752	Device, Start
13	W10137529	Grommet, Condenser
14	2319835	Grommet, Condenser
15	12477102	Roller
16	12992101	Screw
17	10835903	Grommet
18	W10346415	Condenser


Illus.
No. **Part No.** **Description**

19	W10281329	Clip, Drier
20	W10292803	Tray, Drip
21	12990701	Screw
22	W10669255	Evaporator
23		Dam
	12225602	Left Hand
	12225702	Right Hand
24	W11373924	Motor, Condenser Fan
25	10428101	Clip, Heater
26	W11224411	Harness, Unit (Includes Power Cord)
27	W10177049	Drier
28	W10879296	Compressor
29	10623002	Clip, Evaporator
30	12477202	Axle, Roller
31	W10189184	Shroud, Condenser Fan
32	W10622099	Extension, Drain Tube
33	W10236396	Strap, Compressor

Illus.
No. **Part No.** **Description**

34	W10815863	Clip, Condenser
35	2169104	Insulation, Sound Deadening
36	W11244122	Gasket, Foam
		Following Parts Not Illustrated
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
		REFRIGERANT CHARGE
		5.0 oz. (R-134A)

REFRIGERADOR KRFF305ESS03



REFRIGERADOR KRFF305ESS03

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10893772	Glass, Shelf
2	W10742811	Rack, Wine
3	W10149389N	Lift, Bail Arm
4	W10528935	Support, Glass
5	12227305WH	Brace, Pantry
6	12531901	Track, Deli Drawer
7	W10171558	Divider, Basket (Upper)
8	W10241046	Divider, Basket (Upper)
9	12656901	Gasket, Pantry
10	12656202	Housing, Control
11	W10739590	Assembly, Fixed Shelf
12	12655402	Slide, Temperature Control
13	12990512	Screw
14	W10235370	Glide, Pantry
15	12990513	Screw
16		Endcap, Pantry
	W10845509	Left Hand
	W10845508	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	12804601SP	Pan, Crisper
18	12642303WD	Brace, Crisper Cover
19	W10231345N	Trim, Crisper
20	W10329866	Frame, Crisper
21	12204824N	Glass, Shelf
22	W10273463	Ladder, Center
23	W10569182	Ladder, Side
24	12990513	Screw
25	W10215666	Screw
26	12990504	Screw
27	12530805SP	Slide, Humidity Control
28	12655304	Bar, Control
29	12731302	Drawer, Pantry
30	12655204	Knob, Temperature Control
31	12656813	Lid, Pantry
32	W11115781	Basket, Freezer (Lower)
33	W10146440	Divider, Basket (Lower)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
34	W11115256	Basket, Freezer (Upper)
35		Gear, Spur
	W10474716	Left Hand
	W10474715	Right Hand
36	W10781754	Assembly, Fixed Shelf
37	W10802333	Shaft, Rack
38		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
39	W10326469N	Rail, Center Crisper
40	13062602	Support, Crisper Frame
41	W10738157	Assembly, Tuck Shelf
42	13025201	Tray, Lower Basket
43	12802602SP	Front, Crisper Pan

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key