


KitchenAid®

SIDE BY SIDE REFRIGERATOR

MODELS:

KRSC503ESS00 (Stainless Steel)



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10768946	Use & Care Guide
	W10751694	Service & Wiring Sheet
	W10728960	Energy Guide
2	2150304	Roller
3	W10297485	Screw
4	12477102	Roller
5	12477202	Axle, Roller
6	981125	Rivet, Roller
7	W10369091	Tube, Drain
8	W10257186	Bracket, Foot
9	W10141622	Brake, Roller
10	W10308751	Screw (Black)
11	W10498992	Valve, Inlet
12		Hinge, Top (Freezer)
	W10673327	Grey

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Hinge, Top (Refrigerator)
	W10611065	Grey
14	W10308489	Screw (Grey)
15		Hinge, Bottom (Freezer)
	W10249943	Grey
16		Hinge, Bottom (Refrigerator)
	W10666895	Grey
17		Closer, Door (Refrigerator)
	W10738911	Grey
18	W10141645	Screw
19	549193	Clamp, Power Cord
20	W10226427	Control, Electronic (Power Supply)
21		Filler, Wrapper
	12587703AP	Grey

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
22		Grille
	W10713153	Grey
23	W10142234	Screw
24		Closer, Door (Freezer)
	W10257200	Grey
25	W10001250	Screw
26	W10279882	Tube, Filter Inlet
27	W10279885	Tube, Filter Outlet
28	W10370680	Fitting, Drain
29	12957702	Lid, HV Box
30	W10743957	Electronic Control
31		Cabinet (Not A Serviceable Part)
32	W10247993	Box, Control
33	W10333887	Cover, Unit
34	2223388	Clip, Axle Retainer



Illus.


No.	Part No.	Description
1		Liner (Not A Serviceable Part)
2	W10387382	Evaporator Cover
3	W10569758	Filter, Water
4	W10323459	Thermistor, Evaporator Fan
5	W10747235	Cover, Air Tower
6	W10656773	Switch, Light
7	W10538994	Reservoir
8	W10271541	Connector, Union
9	W10280385	Thermistor
10	W10223364	Support, Evaporator (Right Hand)

Illus.

No.	Part No.	Description
11	W10315189	Filter, Air
12	W10341548	Cover, Air Filter
13	W10394053	Housing, Water Filter
14	W10425252	Cover, Thermistor
15	W10637153	Assembly, LED Light Module
16	W10300482	Cover, Water Filter
17	W10723753	Fan Assembly, Evaporator
18	W10723752	Evaporator Insulation, With Fan Assembly

Illus.

No.	Part No.	Description
19	W10223366	Support, Evaporator (Left Hand)
20	W10710826	Lighting, LED-Strip
21	W10727376	Lighting, LED
22	W10724473	Assembly, LED
23	W10260462	Gasket, Rear
24	W10387387	Gasket, Upper
25	W10394945	Gasket, Rear



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10440265	Cover, Assembly
2	W10440266	Cover, Assembly
3	W10542037	Pan, Snack
4	W10278139	Roller
5	W10257246	Axle, Roller
6	W10531081	Pan, Crisper
7	W10531082	Meat Pan
8	W10316452	Housing, Humidity

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10257334	Slide, Humidity
10	W10395554	Wine Rack
11	W10387406	Assembly, Shelf
12	W10531022	Trim, Handle
13	W10542020	Trim, Handle
14	W10531023	Trim, Handle
15	W10408747	Holder, Filter
16	W10346771	Filter, Produce Preserver

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
17		Rail, Track
	W10247942	Left Side
	W10247940	Right Side
18		Rail, Track
	W10257433	Left Side
	W10257431	Right Side
19		Shelf, Filler
	W10392412	Grey



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10362174	Cover Assembly
3	W10315527	Assembly, Shelf
4	W10280386	Thermistor
5	W10315530	Shelf, Glass Lower
6	W10542036	Pan, Freezer Upper
7	W10278139	Roller

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10257246	Axle, Roller
9	W10542035	Pan, Freezer Lower
10	1115373	Switch, Rocker Arm Combination (Freezer)
11	W10425252	Cover, Thermistor
12	W10724473	Assembly, LED
13	W10656772	Switch, Rocker Arm
14	W10542018	Trim, Handle

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10315529	Shelf, Glass Upper
16	W10710826	Lighting, LED-Strip



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10369322	Assembly, Ice Bin
2	W10258552	Assembly, Latch
3	2220458	Coupling, Bottom
4	W10258544	Shaft, Drive
5	W10754509	Spring, Coupling
6	W10293211	Assembly, Mounting Plate

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	2198628	Seal
8	W10291905	Gasket
9	2212370	Washer
10	W10225313	Motor, Dispenser
11	W10669473	Cover, Container
12	W10691248	Plate, Switch

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10666871	Rocker, Switch
14	W10656772	Switch, Rocker Arm
15	W10749467	Filler, EPS, IM Cover
16	W10646076	Assembly, Wire Jumper Switch



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)
	W10771436	Stainless
2	W10316457	Bin, Door Gallon
3	W10296816	Screw
4	W10316461	Door Bin, Shallow
5		Gasket, Door
	W10249918	Grey

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Handle
	W10776877	Stainless
7	2200086	Thimble, Top
8	W10460893	Screw
9		Closer, Upper Cam Door
	W10257203	Grey
10	W10296804	Screw
11	W10367462	Bracket, Door Stop

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Nameplate
	W10518672	Grey
13	W10307614	Screw
14		Cover, Door Stop
	W10257218	Grey
15	W10324760	Assembly, Utility Compartment
16	W10494334	Frame, Gallon Door Bin
17	W10494333	Frame, Shallow Door Bin



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 8 And Dispenser Front Parts)
	W10728959	Stainless
2		Handle
	W10776877	Stainless
3	2200086	Thimble, Top
4	W10296804	Screw
5	W10460893	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10434529	Door Bin
7	W10296816	Screw
8		Gasket, Door
	W10249919	Grey
9		Closer, Upper Cam Door
	W10257206	Grey
10	W10247907	Bracket, Door Stop
11	W10307614	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Cover, Door Stop
	W10632062	Grey
13	W10494336	Frame, Door Bin



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		False Wall, Dispenser
	W10317255	Stainless
2	W10317270	Grate, Drip Tray
3	W10347633	Assembly, Ice Door
4	W10435760	Guide, Ice
5	W10205978	Motor, Dispenser
6	W10353593	Assembly, Seperator
7	W10346124	Support, Ice Door

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	4449745	Screw
9	W10386774	Assembly, Spigot
10	W10238083	Assembly, LED
11	W10784395	User Interface Assembly
12		Pad, Ice and Water
	W10346924	Grey
13		Tray, Housing
	W10317261	Stainless

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
14		Drip Tray, Insert
	W10317276	Grey
15	W10691730	Tube, Water
16	W10342760	Harness, Wire



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	Fan Scroll
2	2223733	Retainer, Fan Motor
3	W10260388	Duct, Upper Air
4		Bi-Metal Defrost (Not Serviced)
5	W10382902	Freezer, Air Duct
6	W10001260	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10556724	Motor, Fan
8	2169142	Blade, Fan
9	W10240370	Gasket, Evaporator Cover
10	W10449920	Grommet, Motor
11	W10369602	Clip, Evaporator Cover
12	W10679946	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10142292	Screw
14	W10388269	Cover, Evaporator
15	W10260382	Cover, Light



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271543	Connector, Water Tube
2	2225834	Blade, Fan
3	W10240365	Assembly, Condenser
4	W10142255	Screw
5	W10223368	Tube, Drain
6	W10171469	Screw
7	W10277958	Connector, Water
8	W10303521	Sleeve
9	W10142287	Bolt
10	W10296661	Clip, Bottom Cover
11	W10223328	Tube, Suction
12	W10248621	Clip, Condenser

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10710090	Assembly, Inverter Box
14	2325479	Tube, Process
15	2205813	Tie, Wire
16	W10239732	Evaporator
17	2161324	Clip, Defrost Heater
18	W10527155	Motor, Condenser Fan
19	W10713147	Tray, Evaporator
20	W10376319	Heat Shield
21	W10286069	Drier
22	W10679948	Assembly, Unit Wire
23	W10680691	Baseplate
24	W10261232	Cord, Power

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	W10251467	Baffle, Air
26	W10495968	Heater, Defrost
27	W10284726	Cover, Unit Bottom
28	W10695094	Compressor
29	2183042	Grommet
30	W10331270	Assembly, Valve Body
31	W10643261	Evaporator, Dual-RC
32	W10317862	Pan, Drip
		REFRIGERANT CHARGE 5.75 oz. (R-134A)



Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10237915	Bracket, Water Valve
2	W10760070	Assembly, Ice Maker

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10691732	Tube, Water
4	W10341320	Assembly, Water Valve
5	W10141625	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Fill Tube Assembly (Not Serviced)
7	W10238083	Assembly, LED

OPTIONAL PARTS (NOT INCLUDED)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque
	8171357	Graphite

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	80051	Graphite

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque
	8171358	Graphite

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10300794	Handle Installation Kit
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	4318168	Sealer

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key