


KitchenAid®

30" SLIDE IN GAS CONVECTION RANGE

MODELS:

KSGB900EBL0 (Black)
KSGB900EWH0 (White)
KSGB900ESS0 (Stainless)

ESTUFA KSGB900E




ESTUFA KSGB900E

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10665256	Instructions, Installation
	W10896670	Guide, Use & Care
	W10844271	Sheet, Tech
	W10903847	Diagram, Wiring
	9762761	Tips, Safe Cooking (English)
	W10065852	Tips, Safe Cooking (French)
	W10400066	Guide, Quick Start (English)
	W10400067	Guide, Quick Start (French)
	2	
W10479989		Black
W10697322		Black
3		Console
	W10697323	White
	W10697324	Stainless
4	W10256028	Spreader, Flame (Right Front)
	W10256025	Spreader, Flame (Right Rear & Center)
	W10464795	Spreader, Flame (Left Rear)
	W10495853	Spreader, Flame (Left Front)
	5	
W10536181		Black
W10536182		White
W10588278		Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	7101P485-60	Screw, Anti-Tip Kit
7		Knob
	W10786065	Stainless (All except Left Front)
	W10786064	Stainless (Left Front)
8		Kit, Grate
	W10432520	Black
9	3196169	Screw
10	W10289170	Support, Cooktop (Left)
	W10289169	Support, Cooktop (Right)
11	8016P022-60	Glide, Main Top
12		Endcap
	W10555936	Black (Left)
	W10555935	White (Left)
	W10555937	Stainless (Left)
	W10555939	Black (Right)
	W10555938	White (Right)
	W10555940	Stainless (Right)
13		Trim, Vent
	W10577781	Black
	W10636527	White
	W10577782	Stainless
14	W10759287	Control, MRC2
15	W10603094	Assembly, Display
16	W10558372	Bracket, Control
17		Bezel
	W10785119	Stainless (Kit of 5)
18	W10645947	Grommet

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10664705	Bumper
20		Console, Lower Panel
	W10555932	Black
	W10555933	White
	W10555934	Stainless
21	W10606241	Bracket, Anti-Tip
22	W10162253	Brace, Corner (Left)
	W10162252	Brace, Corner (Right)
23	W10555923	Bracket, User Interface
24	W10598048	Bracket, Console (Center)
25	W10757531	Keypad, Shield
		FOLLOWING PARTS NOT ILLUSTRATED
	W10580232	Harness, Main
	W10754419	Harness, Bake/Broil
	W10598169	Harness, Display
	W10580265	Harness, Bake/Warm Drawer
	W10575120	Harness, Keypad
	313438	Clip, Harness
	3196520	Clip, Wire
	W10580229	Wire, Ground
	W10916510	Insulation, Burner Box


ESTUFA KSGB900E



ESTUFA KSGB900E

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10614920	Assembly, Flue	18	W10323077	Diffuser, Flame	37	W10137382	Clip, Panel
2	9758701	Spacer, Door	19	3196178	Screw	38	W10457998	Module, Spark (0+2)
3	W10273002	Bracket, Oven Support	20	W10289166	Back, Main	39	W10475149	Module, Spark (5+0)
4		Panel, Side	21	W10162385	Gasket, Door	40	W10655451	Guard, Splash
	W10162245	Black	22	W10031780	Screw	41	W10162254	Duct, Cooling
	W10575396	White	23	W10603482	Rack, Ladder	42	W10162255	Duct, Cover
5	W10780482	Assembly, Cooling Fan	24	W10273192	Rod, Door Switch	43	W10273204	Pan, Bake
6	W10627802	Switch, Door	25	W10889764	Cord, Power	44	W10289168	Box, Burner SI
7	W10554006	Rack, Maximum Capacity	26	W10035900	Support, Oven Bottom	45	W10162257	Duct, Cooktop
8	W10554008	Rack, Sliding	27	W10541959	Shield, Bake	46	W10289172	Cover, Back
9	W10289077	Receiver, Hinge	28	W10454648	Assembly, Light	47	W10162249	Cover, Wire
10	W10058460	Foot, Leveling	29	311255	Bulb, Oven Light	48	W10162241	Channel, Rear
11	W10211368	Bottom, Oven	30	W10341186	Assembly, Front Foot	49	W10813366	Shield, Wire
12	W10586204	Sensor	31	W10390007	Assembly, Base Rail (Right)	50	W10686408	Kit, Reservoir (Steam Rack)
13	3601P356-45	Baffle, Bake Burner		W10390008	Assembly, Base Rail (Left)	51	W10732648	Probe, Wireless Meat
14	3196178	Screw	32	W10558276	Box, Burner Gas			INSULATION
15	W10552502	Element, Broil Assist	33	W10874477	Assembly, Convection		4820F015-59	Insulation, Strap
16	W10311326	Assembly, Flue (Upper)	34	W10346153	Baffle, Full Convection		W10289173	Insulation, Wrap
17	W10362924	Screw	35	W10362924	Screw		W10162240	Insulation, Back
			36	W10554007	Rack, Steam			


ESTUFA KSGB900E



ESTUFA KSGB900E

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10673618	Screw	8	W10566057	Valve, Gas (Right Rear & Center)	21	3601P336-45	Baffle, Broil Burner
2	W10552120	Assembly, Orifice (Right Front)		W10566062	Valve, Gas (Right Front)		W10575401	Clip, Spring (Electrode)
	W10552119	Assembly, Orifice (Right Rear)		W10831591	Valve, Gas (Left Rear)	23	W10140571	Seal, Switch Shaft
	W10552121	Assembly, Orifice (Left Rear)		W10432224	Valve, Gas Duel (Left Front)	24	W10762686	Bracket, Manifold Support
	W10552122	Assembly, Orifice (Left Front)	9	W10224921	Bracket, Aegis			Following Parts Not Illustrated
	W10552124	Assembly, Orifice (Center)	10	W10439242	Burner, Broiler		W10566535	Kit, LP Conversion (Bake/Broil)
3	W10295996	Bracket, Saddle Valve	11	W10680035	Burner, Bake		W10681410	Kit, LP Conversion (Burners)
4	W10432252	Tube, Gas Supply	12	W10554066	Valve, Regulator		W10566535	Kit, LP Conversion (Bake/Broil)
5	W10432517	Harness, Switch Spark	13	W10324262	Igniter, Bake			
6	W10496872	Electrode (Right Rear)	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
	W10496870	Electrode (Right Front & Center)	15	W10583216	Fitting, Broil Burner			
	W10464799	Electrode (Left Rear)	16	W10333842	Electrode, Broil			
	W10496874	Electrode (Left Front)	17	W10434277	Orifice (1.8MM) (Right Front)			
7	W10826727	Assembly, Manifold		W10657949	Orifice (9.2K) (Right Rear)			
				W10256132	Orifice (1.2K) (Left Front)			
				W10566082	Orifice (19K) (Left Front)			
				W10657947	Orifice (8K) (Center)			
				W10515054	Orifice (5K) (Left Rear)			
			18	3196178	Screw			
			19	3196385	Screw			
			20	3400016	Screw			

ESTUFA KSGB900E




ESTUFA KSGB900E

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10541911	Bracket, Glass Upper Handle
2	8533988	Screw
3		Assembly, Outer Door
	W10634272	Black
	W10634273	White
	W10634271	Stainless
4	W10541882	Liner, Door
5	W10541888	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Assembly, Door Handle
	W10551000	Stainless
7	W10031780	Screw
8	W10541885	Support, Glass
9		Scoop, Door
	W10613791	Black
	W10613790	White
	W10551024	Stainless
10	W10388635	Hinge, Door (Active)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10319024	Washer, Door
12	W10541883	Hinge, Support Rail
13	W10031790	Screw
14		Badge
	W10518672	Grey
15	W10327235	Screw

ESTUFA KSGB900E



ESTUFA KSGB900E

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Drawer Handle
	W10551000	Stainless
2	W10757442	Drawer, Bake
3	W10550987	Seal, Drawer
4		Panel, Drawer Front
	W10541953	Black
	W10541952	White
	W10541954	Stainless
5	W10921904	Slide, Drawer (Left)
	W10921905	Slide, Drawer (Right)
6	W10327235	Screw
7	8533988	Screw
8	W10634260	Enclosure, Warming
9	W10551025	Cover, Gas Valve

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10634259	Cover, Wire
11	W10586204	Sensor
12	W10541944	Element, Bake
13	W10551019	Cover, Side
14	3823F017-45	Spacer, Handle
15	W10551018	Insulation, Drawer Front
16	W10550982	Insulation, Drawer
17	W10541947	Panel, Front Inner
18	W10729897	Fuse, Thermal
19	W10550984	Insulation, Drawer Side
20	W10550985	Retainer, Side Insulation
21	3196560	Screw
22	W10602493	Rack, Bake Drawer

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
23	W10551011	Insulation, Bake Drawer Bottom
24	W10655446	Shield, Corner
		FOLLOWING PARTS NOT ILLUSTRATED
	W10550983	Insulation, Retainer Bake Drawer
	W10541960	Insulation, Drawer Top

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	31463A	Protectant, Cooktop
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	WA906B	Scraper, Cooktop
	242905	Kit, Canning Unit
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10432545	Kit, Grill
	W10432544	Griddle
	W10432019	Alt Cleaning Kit Assembly, Trim (5/8")
	W10675026	Black
	W10675027	White
	W10675028	Stainless (1 1/8")
	W10731886	Black
	W10731885	White
	W10731887	Stainless Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless