


**KitchenAid®**

**30" SLIDE IN GAS CONVECTION RANGE**

**MODELS:**

KSGB900ESS1 (Stainless Steel)

# ESTUFA KSGB900ESS1




# ESTUFA KSGB900ESS1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10665256	Instructions, Installation
	W10722060	Guide, Use & Care
	W10665227	Sheet, Tech
	W10703182	Wire Diagram
	9762761	Tips, Safe Cooking (English)
	W10065852	Tips, Safe Cooking (French)
	W10400066	Guide, Quick Start (English)
	W10400067	Guide, Quick Start (French)
2		Kit, Burner Cap
	W10479989	Black
3		Console
	W10901118	Stainless
4	W10256028	Spreader, Flame (Right Front)
	W10256025	Spreader, Flame (Right Rear & Center)
	W10464795	Spreader, Flame (Left Rear)
	W10495853	Spreader, Flame (Left Front)
5		Cooktop
	W10588278	Stainless
6	7101P485-60	Screw, Anti-Tip Kit

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7		Knob
	W10786065	Stainless (All except Left Front)
	W10786064	Stainless (Left Front)
8		Kit, Grate
	W10432520	Black
9	3196169	Screw
10	W10289170	Support, Cooktop (Left)
	W10289169	Support, Cooktop (Right)
11	8016P022-60	Glide, Main Top
12		Endcap
	W10555937	Stainless (Left)
	W10555940	Stainless (Right)
13		Trim, Vent
	W10577782	Stainless
14	W10453984	Control MRC2
15	W10603094	Assembly, Display
16	W10558372	Bracket, Control
17		Bezel
	W10785119	Stainless
18	W10645947	Grommet
19	W10664705	Bumper
20		Console, Lower Panel
	W10555934	Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
21	W10606241	Bracket, Anti-Tip
22	W10162253	Brace, Corner (Left)
	W10162252	Brace, Corner (Right)
23	W10555923	Bracket, User Interface
24	W10598048	Bracket, Console (Center)
25	W10757531	Keypad, Shield
		FOLLOWING PARTS NOT ILLUSTRATED
	W10580232	Harness, Main
	W10754419	Harness, Bake/Broil
	W10598169	Harness, Display
	W10580265	Harness, Bake/Warm Drawer
	W10575120	Harness, Keypad
	313438	Clip, Harness
	3196520	Clip, Wire
	W10580229	Wire, Ground
	W10716764	Insulation, Burner Box
	W10701082	Insulation, Vent Trim

# ESTUFA KSGB900ESS1




# ESTUFA KSGB900ESS1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10614920	Assembly, Flue
2	9758701	Spacer, Door
3	W10273002	Bracket, Oven Support
4		Panel, Side
	W10162245	Black
5	W10780482	Assembly, Cooling Fan
6	W10627802	Switch, Door
7	W10554006	Rack, Maximum Capacity
8	W10554008	Rack, Sliding
9	W10289077	Receiver, Hinge
10	W10058460	Foot, Leveling
11	W10211368	Bottom, Oven
12	W10586204	Sensor
13	3601P356-45	Baffle, Bake Burner
14	3196178	Screw
15	W10552502	Element, Broil Assist
16	W10311326	Assembly, Flue (Upper)
17	W10362924	Screw
18	W10323077	Diffuser, Flame

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	3196178	Screw
20	W10289166	Back, Main
21	W10162385	Gasket, Door
22	W10031780	Screw
23	W10603482	Rack, Ladder
24	W10273192	Rod, Door Switch
25	W10624590	Cord, Power
26	W10035900	Support, Oven Bottom
27	W10541959	Shield, Bake
28	W10454648	Assembly, Light
29	311255	Bulb, Oven Light
30	W10341186	Assembly, Front Foot
31	W10390007	Assembly, Base Rail (Right)
	W10390008	Assembly, Base Rail (Left)
32	W10558276	Box, Burner Gas
33	W10617484	Assembly, Convection
34	W10346153	Baffle, Full Convection
35	W10362924	Screw
36	W10554007	Rack, Steam

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
37	W10137382	Clip, Panel
38	W10457998	Module, Spark (0+2)
39	W10475149	Module, Spark (5+0)
40	W10655451	Guard, Splash
41	W10162254	Duct, Cooling
42	W10162255	Duct, Cover
43	W10273204	Pan, Bake
44	W10289168	Box, Burner SI
45	W10162257	Duct, Cooktop
46	W10289172	Cover, Back
47	W10162249	Cover, Wire
48	W10162241	Channel, Rear
49	W10813366	Shield, Wire
50	W10686408	Kit, Reservoir (Steam Rack)
51	W10732648	Probe, Wireless Meat
		INSULATION
	4820F015-59	Insulation, Strap
	W10289173	Insulation, Wrap
	W10162240	Insulation, Back

# ESTUFA KSGB900ESS1




# ESTUFA KSGB900ESS1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10673618	Screw
2	W10552120	Assembly, Orifice (Right Front)
	W10552119	Assembly, Orifice (Right Rear)
	W10552121	Assembly, Orifice (Left Rear)
	W10552122	Assembly, Orifice (Left Front)
	W10552124	Assembly, Orifice (Center)
3	W10295996	Bracket, Saddle Valve
4	W10432252	Tube, Gas Supply
5	W10432517	Harness, Switch Spark
6	W10496872	Electrode (Right Rear)
	W10496870	Electrode (Right Front & Center)
	W10464799	Electrode (Left Rear)
	W10496874	Electrode (Left Front)
7	W10826727	Assembly, Manifold

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10566057	Valve, Gas (Right Rear & Center)
	W10566062	Valve, Gas (Right Front)
	W10831591	Valve, Gas (Left Rear)
	W10432224	Valve, Gas Duel (Left Front)
9	W10224921	Bracket, Aegis
10	W10439242	Burner, Broiler
11	W10680035	Burner, Bake
12	W10554066	Valve, Regulator
13	W10324262	Igniter, Bake
14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)
15	W10583216	Fitting, Broil Burner
16	W10333842	Electrode, Broil

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10434277	Orifice (Right Front)
	W10657949	Orifice (Right Rear)
	W10256132	Orifice (1.2K) (Left Front)
	W10566082	Orifice (Left Front)
	W10657947	Orifice (8K) (Center)
	W10515054	Orifice (Left Rear)
18	3196178	Screw
19	3196385	Screw
20	3400016	Screw
21	3601P336-45	Baffle, Broil Burner
22	W10575401	Clip, Spring (Electrode)
23	W10140571	Seal, Switch Shaft
		Following Parts Not Illustrated
	W10681410	Kit, LP Conversion
	W10681410	Kit, LP Conversion (Burners)
	W10566535	Kit, LP Conversion (Bake/Broil)

# ESTUFA KSGB900ESS1






# ESTUFA KSGB900ESS1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10541911	Bracket, Glass Upper Handle
2	8533988	Screw
3		Assembly, Outer Door
	W10634271	Stainless
4	W10826568	Liner, Door
5	W10813616	Glass, Inner
6	Assembly, Door HandleW10551000	Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10031780	Screw
8	W10813140	Support, Glass
9		Scoop, Door
	W10551024	Stainless
10	W10885519	Hinge, Door (Active)
11	W10319024	Washer, Door
12	W10813139	Hinge, Support Rail
13	W10031790	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14		Badge
	W10518672	Grey
15	W10327235	Screw

# ESTUFA KSGB900ESS1



# ESTUFA KSGB900ESS1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Drawer Handle
	W10551000	Stainless
2	W10757442	Drawer, Bake
3	W10550987	Seal, Drawer
4		Panel, Drawer Front
	W10541954	Stainless
5	W10541946	Slide, Drawer (Left)
	W10541945	Slide, Drawer (Right)
6	W10327235	Screw
7	8533988	Screw
8	W10634260	Enclosure, Warming
9	W10551025	Cover, Gas Valve
10	W10634259	Cover, Wire

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10586204	Sensor
12	W10541944	Element, Bake
13	W10551019	Cover, Side
14	3823F017-45	Spacer, Handle
15	W10551018	Insulation, Drawer Front
16	W10550982	Insulation, Drawer
17	W10541947	Panel, Front Inner
18	W10729897	Fuse, Thermal
19	W10550984	Insulation, Drawer Side
20	W10550985	Retainer, Side Insulation
21	3196560	Screw
22	W10602493	Rack, Bake Drawer
23	W10551011	Insulation, Bake Drawer Bottom

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10655446	Shield, Corner
		FOLLOWING PARTS NOT ILLUSTRATED
	W10550983	Insulation, Retainer Bake Drawer
	W10541960	Insulation, Drawer Top

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	31463A	Protectant, Cooktop
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	WA906B	Scraper, Cooktop
	242905	Kit, Canning Unit
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10432545	Kit, Grill
	W10432544	Griddle
	W10432019	Alt Cleaning Kit Assembly, Trim (5/8")
	W10675026	Black
	W10675027	White
	W10675028	Stainless (1 1/8")
	W10731886	Black
	W10731885	White
	W10731887	Stainless Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless