

PARTS LIST

for

KitchenAid®

6 QT. STAND MIXER


COSTCO – BOWL LIFT

MODELS:

KSM6573CWH1 (White)
KSM6573COB1 (Onyx Black)
KSM6573CER1 (Empire Red)
KSM6573CCU1 (Contour Silver)




FOR CUSTOMER SATISFACTION ALWAYS USE



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------



Colors Subject To Change.
 Any Color Not Listed is
 No Longer Available.
 If Additional Colors Are Added,
 This Page Will Be Updated.

1		Motor Housing
	9703311	White
	9705296	Onyx Black
	9705300	Empire Red
	W10327951	Contour Silver
2		Trim Band
	W10410026	Dark Platinum
3		Lower Gearcase
	W10234488	White
	W10410012	Onyx Black
	W10410011	Empire Red
	W10410010	Contour Silver
4		Planetary
	W10420628	White
	W10410018	Onyx Black
	W10419426	Empire Red
	W10410016	Contour Silver
5		Bowl Support and Pins
	9707633	White
	9707876	Onyx Black
	9707883	Empire Red
	W10410004	Contour Silver
6		Column and Pins
	9703673	White
	9705320	Onyx Black
	9705324	Empire Red
	W10328003	Contour Silver
7		Base & Foot Assembly
	9703690	White
	9705344	Onyx Black
	9705348	Empire Red
	W10328017	Contour Silver



Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing
2	9703315	Cap, Attachment Hub, Hinged
3	**	Band, Trim
4	W10351843	Screw
5	W10305968	Holder, Control
6	**	Lower Gearcase
7	W10234493	Gear, Ring & Plate to Planetary
8	3400617	Screw
9	3400814	Screw
10	W10234504	Motor, 120 V Assy w/Transmission
11	3400200	Screw
12	W10409930	Control Assembly
13	W10234531	Pin, Groove
14		Cord, Power
	W10234520	White
	W10338492	Black
15	**	Planetary Assembly
16	9703438	Clip, Retaining
17	9706090	Washer
18	W10234643	Gear, Pinion
19	9707223	Pin, Retaining
20	8533910	Washer
21	9708191	Shaft, Agitator
22	9703680	Clip, Retaining
23		Thumb Screw
	W10417014	Chrome
24	9704677	Pin, Groove

**Refer To Page 3
Color Variation Parts



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10410027	Use & Care Guide
	W10493222	Repair Parts List
3	W10177650	Bowl, 6 Qt.
4	240185	Pin, Bowl Locating
5	9703474	Latch, Bowl Spring
6	3400018	Screw
7	* *	Bowl Support
8	* *	Base and Foot Assembly
9	9708649	Foot, Rubber
10	9703307	Clip
11	9706787	Rod, Bowl Lift
12	9237	Spring 13
	9703439	Washer
14	8533907	Nut
15	* *	Column Assembly
16	W10401173	Beater, Flat
17	W10335442	Hook, Dough
18	9706885	Arm, Bowl Lift
19	9704309	Whip, Wire
20	9703426	Cam, Adjusting
21	3400863	Screw
22	9706788	Handle, Bowl Lift
23	3400200	Screw

* *Refer To Page 3
Color Variation Parts

ACCESSORY PARTS

Illus. No.	Part No.	DESCRIPTION
	4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)
	4164749	Food Grinder (FG-A)
W10318099	Grain Mill (KGM0)	
	4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)
	4164750	Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A)
	4164774	Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A)
	241675	Food Tray (FT)
	4164748	Juicer (JE)
	4164803	Sausage Stuffer Kit (SSA)
	4176597	Grease, Planetary
	8212519	Ice Cream Maker (KICA0WH0)
KPEXTA	Pasta Extruder with 6 Discs	