

KitchenAid®

**6 QT. STAND MIXER
COSTCO - BOWL LIFT**

MODELS:

KSM6573CWH2 (White)

KSM6573COB2 (Onyx Black)

KSM6573CER2 (Empire Red)


KSM6573CCU2 (Contour Silver)

4KSM6573CWH2 (White)

4KSM6573COB2 (Onyx Black)

4KSM6573CER2 (Empire Red)


4KSM6573CCU2 (Contour Silver)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing
	9703311	White
	9705296	Onyx Black
	9705300	Empire Red
	W10327951	Contour Silver
2		Trim Band
	W10410026	Dark Platinum
3		Lower Gearcase
	W10234488	White
	W10410012	Onyx Black
	W10410011	Empire Red
	W10410010	Contour Silver

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Planetary
	W10420628	White
	W10410018	Onyx Black
	W10419426	Empire Red
	W10410016	Contour Silver
5		Bowl Support and Pins
	9707633	White
	9707876	Onyx Black
	9707883	Empire Red
	W10410004	Contour Silver

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Column and Pins
	9703673	White
	9705320	Onyx Black
	9705324	Empire Red
	W10328003	Contour Silver
7		Base and Foot Assembly
	9703690	White
	9705344	Onyx Black
	9705348	Empire Red
	W10328017	Contour Silver




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing (Refer to Color Variation Parts Page)	8	3400617	Screw	16	9703438	Ring, Retaining
2	9703315	Cover, Attachment Hub	9	3400814	Screw	17	9706090	Washer
3		Trim Band (Refer to Color Variation Parts Page)	10	W10517938	Motor, 120 Volt Assembly	18	W10234643	Gear, Pinion
4	W10351843	Screw	11	3400200	Screw	19	9707223	Pin, Retaining
5	W10305968	Holder, Control	12	W10409930	Control Assembly	20	8533910	Washer
6		Lower Gearcase (Refer to Color Variation Parts Page)	13	W10234531	Pin, Groove	21	9708191	Shaft, Agitator
7	W10234493	Gear, Ring and Plate Assembly	14		Cord, Power	22	9703680	Clip, Retaining
				W10234520	White	23		Thumb Screw
				W10338492	Black	24	W10417014	Chrome
			15		Planetary Assembly (Refer to Color Variation Parts Page)		9704677	Pin, Groove

1



Literature Parts





BATIDORA KSM6573CWH2

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	9708649	Foot	20	9703426	Cam, Adjusting
	W10410027	Use and Care Guide, U.S.	10	9703307	Ring, Retaining	21	3400863	Screw
3	W10177650	Bowl, 6 Qt.	11	9706787	Rod, Bowl Lift	22	9706788	Handle, Bowl Lift
4	240185	Pin, Retaining Bowl	12	9237	Spring, Lift Rod	23	3400200	Screw
5	9703474	Clip, Bowl Retainer	13	9703439	Washer			
6	3400018	Screw	14	8533907	Nut			
7		Bowl Support and Pins (Refer to Color Variation Parts Page)	15		Column and Pins (Refer to Color Variation Parts Page)			
8		Base and Foot Assembly (Refer to Color Variation Parts Page)	16	W10401173	Beater, Flat			
			17	W10335442	Hook, Dough			
			18	9706885	Arm, Bowl Lift			
			19	9704309	Whip, Wire			