


KitchenAid®

**8 QT. STAND MIXER
COMMERCIAL - BOWL LIFT**

MODELS:


KSM8990WH0 (White)
KSM8990NP0 (Nickel Pearl)
KSM8990OB0 (Onyx Black)
KSM8990ER0 (Empire Red)
KSM8990DP0 (Dark Pewter)
KSM8990ES0 (Espresso)
KSM8990SL0 (Silver)




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	
1		Motor Housing	
	9703311	White	
	9708749	Nickel Pearl	
	9705296	Onyx Black	
	9705300	Empire Red	
	9708711	Dark Pewter/Slate	
	W10453625	Espresso	
	9709571	Silver	
	2		Trim Band
		W10540366	Dark Platinum
3		Lower Gearcase	
	W10307855	White	
	W10527047	Nickel Pearl	
	W10535254	Onyx Black	
	W10524029	Empire Red	
	W10567055	Dark Pewter/Slate	
	W10609124	Espresso	
	W10540257	Silver	

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	
4		Planetary	
	W10540185	Chrome	
5		Bowl Support and Pins	
	9703674	White	
	9708760	Nickel Pearl	
	9705356	Onyx Black	
	9705360	Empire Red	
	9708722	Dark Pewter/Slate	
	W10453636	Espresso	
	W10327840	Silver	
	6		Column and Pins
		9703673	White
9708763		Nickel Pearl	
9705320		Onyx Black	
9705324		Empire Red	
9708725		Dark Pewter/Slate	
W10453639	Espresso		
	9709585	Silver	

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7		Base & Foot Assembly
	9703690	White
	9708766	Nickel Pearl
	9705344	Onyx Black
	9705348	Empire Red
	9708728	Dark Pewter/Slate
	W10453644	Espresso
	9709588	Silver



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing (Refer to Color Variation Parts Page)	8	3400617	Screw	16	9703438	Ring, Retaining
2	W10394928	Cap, Attachment Hub, Hinged	9	3400814	Screw	17	9706090	Washer
3		Trim Band (Refer to Color Variation Parts Page)	10	W10517938	Motor, 120 Volt Assembly	18	W10234643	Gear, Pinion
4	W10351843	Screw	11	3400200	Screw	19	9707223	Pin, Retaining
5	W10305968	Holder, Control	12	W10487697	Control Assembly, 120 Volt	20	8533910	Washer
6		Lower Gearcase (Refer to Color Variation Parts Page)	13	W10307854	Guard, Switch	21	9708191	Shaft, Agitator
7	W10234493	Gear, Ring and Plate Assembly	14		Cord, Power	22	9703680	Clip, Retaining
				W10308001	Orange	23		Thumb Screw
			15		Planetary Assembly (Refer to Color Variation Parts Page)	24	9704677	Pin, Groove
						25	W10234531	Pin, Groove



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	9708649	Foot	20	9703426	Cam, Adjusting
	W10581080	Use and Care Guide	10	9703307	Ring, Retaining	21	3400863	Screw
2	W10439369	Plug, Foot	11	W10598835	Rod, Bowl Lift	22	W10598836	Handle, Bowl Lift
3	W10508588	Bowl, 8 Quart	12	9237	Spring, Lift Rod13	23	9706814	Screen, Vent
4	240185	Pin, Retaining Bowl		9703439	Washer	24	3400200	Screw
5	W10504114	Clip, Bowl Retainer	14	8533907	Nut			
6	3400018	Screw	15		Column and Pins (Refer to Color Variation Parts Page)			
7		Bowl Support and Pins (Refer to Color Variation Parts Page)	16	W10376294	Beater, Flat (Stainless)			
8		Base and Foot Assembly (Refer to Color Variation Parts Page)	17	W10462785	Hook, Dough (Stainless)			
			18	9706885	Arm, Bowl Lift			
			19	W10600940	Whip, Wire			