




REFRIGERADOR KSSC42QVS00


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	2318189	Tray, Drip Filter	31		Extension Arm,
	W10161714	Use & Care Guide	12	3400525	Screw			Door Closer
	W10163488	Energy Guide	13	4396841	Filter, Water		2307857	Right
	W10159832	Service & Wiring Sheet	14	489399	Screw		2302765	Left
	2306424	Icemaker and Ingredient Care Center Service Sheet	15	3400230	Screw, Door Stop	32		Grille Bottom, Front
	2318069	Main Control Service Sheet	16	2257644	Hinge (Top)		2325185B	Black
	2316565	Installation Instructions	17	2318190	Bracket, Mtg (Water Filter)	33	2005921	Screw
2		Cabinet (Not A Serviceable Part)	18	489464	Screw	34		Bracket, Support Base (Front)
3	2260503B	Button, Filter	19	2004994	Lock, Adjustable Bushing		2006616	Left
4	W10138054	Roller, Front & Rear (4)	20	2300082	Bushing		2006556	Right
5		Support, Leveler Assembly	21	2004514	Clip, Conduit Spring, Door Closure	35	1157158	Screw
	2318194	Refrigerator Side	22			36	2006617	Bracket, Support Base (Rear) (2)
	2318193	Freezer Side		2221242	Right Side	37	2006346	Washer
6		Cap, Water Filter		2004517	Left Side	38	2266880	Bushing, Extension Arm
7	2260518B	Black	23	486194	Screw	39	1163283	Screw
8	2307640	Mounting Stud, Grille	24	2005008	Retaining Ring, Adjustable Bushing	40		Connector, Water Tube
9	2307584	Grommet, Crossover Tube	25	W10129069	Wire Clip (5)		2209709	5/16-1/4"
10	2005783	Cam, Door Closer	26	2006342	Gap, Cover Assembly (Bottom)		2300868	1/4"
	2260526	Housing, Water Filter	27			41	8281163	Screw
				2006780	Freezer Side	42		Switch, Rocker Arm
				2006779	Refrigerator Side		1118894	Refrigerator Door Side
			28	2302876	Bushing, Adjustable		1115373	Freezer Door Side
			29	8533913	Screw 1/4-20 x 5/8	43	2215938	Cover, Switch (2)
			30		Skirt-Grille, Bottom	44	487415	Screw (2)
				2209025B	Black	45		Bracket, Switch
							2221097	Right
							2221096	Left
						46	2215612	Cover, Rear



REFRIGERADOR KSSC42QVS00




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
2		Screw
	1163283	Stainless Steel
3	2316687	Cabinet, Trim (Bottom)
4	486194	Screw
5	2314017	Cabinet, Trim Top
6		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
7	W10121451	Nutsert (4)
8	2005925	Seal-Trim, Side
9	489464	Screw



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	2302868	Wire, Shelf
2	2302883	Shelf, Fixed (2)
3	2259082	Basket
4	2256270	Front, Basket
5		Slide, Basket
	2259317	Right Side
	2259318	Left Side
6	8533928	Screw




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2259077	Ladder, Shelf (2)
5	520965	Screw Support, Ladder (8)
6	2006475	Screw
7	487539	Screw
8	2302937	Thermistor
9	2302986	Lid, Meat Pan Baffle
10	W10169528	Baffle Control Assembly
11	2171846	Release Valve
12	2310205	Jumper, Air Baffle
13	488357	Screw
14	486194	Screw
15	2221296	Air Baffle Assembly
16	2327509	Reservoir
17	488280	Screw
18	2309222	Diffuser Assembly
19	2317105	Cover, Thermistor
20	2188820	Thermistor
21	2302992	Spacer, Air-Baffle
22	2309087	Cover, Diffuser
23	2259412	Seal, Air Duct (Round Hole)
24	2259398	Seal, Air Duct (Square Hole)
25	2003577	Guard, Air Return
26	W10159487	Diverter, Crisper Cover



REFRIGERADOR KSSC42QVS00




Illus. No.	Part No.	DESCRIPTION
1	2316545	Control Box
2	2317000	Clip, Box
3	2310390	Wire, Jumper
4	2307592	Bracket, Control Box
5	2307595	Shield, Control Box
6	487539	Screw (2)
7	2306086	Display, Ingredient Care Center
8	2223857	Socket, Light
9	2326255	Light Bulb (2)
10	8281185	Screw



Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly
	2316737S	Stainless Steel
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10121229	Cover, Unit Front
6	487415	Screw
7	2310194	Wire Assembly
8	2317923S	Badge, Kitchen Aid
9	489348	Clamp
10	2004333	Nut
11	2215910	Grommet-Flexible




REFRIGERADOR KSSC42QVS00



Illus. No.	Part No.	DESCRIPTION
1	2222592	Shelf Assembly
2	2179404	Rack, Wine
3	2302842	Assembly, Meat Pan Cover
4	2302835	Assembly, Crisper Cover
5	2257582	Trim, Glass Rear
6	2252412	Crisper Pan (2)
7		Slide, Meat Pan
	2302954	Left Side
	2302955	Right Side
8	2302831	Trim, Glass Front
9	2256254	Trim, Glass Rear
10	2256248	Front, Crisper Pan
11	2252255	Trim, Glass Side Crisper Pan
12	2256250	Trim, Glass Side Meat Pan
13		Spacer, Crisper
	2256222	Right Side (2)
	2256223	Left Side (2)
14		Slide, Crisper
	2302956	Right Side
	2302957	Left Side
15		Spacer, Meat Pan
	2256243	Left Side
	2256244	Right Side
16		Screw
	8533929	Right Side- (8-18 x 1.375)
	8533928	Left Side- (8-18 x .750)
17	2256369	Pan Assembly Meat
18	2256366	Front, Meat Pan



REFRIGERADOR KSSC42QVS00




Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor
2	2198665	Tube, P.C.Board
3	2169142	Fan Blade
4	2223733	Retainer, Fan Motor
5	2302817	Gasket, Cover
6	2223986	Grommet
7	486194	Screw
8	2259464	Wedge, AirDuct
9	488500	Screw, Ground
10	2223857	Socket, Light (2)
11	488937	Clamp, Nylon
12	2326255	Light Bulb
13	489214	Screw
14	2182120	Scroll, Fan
15	2259465	Wedge, AirDuct
16	2307774	Air Duct
17	2198643	Lens
18		Block, Fan Scroll
	2209480	Right
	2209066	Left

Illus. No.	Part No.	DESCRIPTION
19	2215650	Cover, Emitter
20		Liner (Not A Serviceable Part)
21	2259025	Cover, Air Outlet
22	2307751	Light Shield
23	W10158003	Cover, Evaporator
24	2302850	Support, Air Duct
25	487539	Screw
26	2198635	Spring
27	2309283	Deflector, Air Duct
28	1112260	Support, Evaporator
29	2196483	Shelf, Stud (20)
30	8281158	Screw
31		Evaporator, Cover Rail
	2221107	Left Side
	2259355	Right Side

Illus. No.	Part No.	DESCRIPTION
32	2220904	Gasket (2) Evaporator Cover
33	2259493	Cover, Receiver
34	W10139189	Harness, Evap Fan (Includes Item 45)
35	2306010	Thermistor
36	2317105	Cover, Thermistor
37	2006475	Screw
38	2259032	Ladder, Shelf
39	2259445	Support, Screw
40	2198634	Pin
41	2220398	P.C. Board Emitter
42	2198633	Flipper
43	2255563	Slide, Ice maker Shut Off
44	2255114	P.C. Board, Receiver
45	W10160570	Defrost, Bi-Metal
46	8281185	Screw



REFRIGERADOR KSSC42QVS00




BENITO JUÁREZ #1500 GPE ZIT00N, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM

www.denek.com

Illus. No.	Part No.	DESCRIPTION
1	2222965	Ice Bin
2	W10134774	Crusher Bin
3	W10140642	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (6)
6	2317248	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling, Top
17	8281164	Screw
18	3400065	Screw
19	2252265	Button, Bin
20	W10134783	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw (2)
23	8281163	Screw
24	2188919	Holder
25	2198628	Seal
26	2318030	Drive Shaft
27	2318011	Enclosure, Motor
28	2315546	Dispenser, Motor
29	2318028	Cover
30	2315559	Sleeve. Coupling
31	2317250	Divider-Chamber
32	2317243	Wiper




REFRIGERADOR KSSC42QVS00



Illus. No.	Part No.	DESCRIPTION
1	2252330	Refrigerator Door Panel (Includes Item #9)
2	2258951	Brace, Door Corner
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	489282	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10		Skin, Door
11	2307753	Stainless Steel Handle, Door
12	2316868	Stainless Steel Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
13	488568	Screw
14		Screw, 8-15 x .500
	8281250	Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	308544	Screw, Handle
17	2005030	Spacer, Door-Skin (Hinge Side)
18	2004934	Spacer, Door-Skin (Bottom)
19	2005326	Filler, Door
20		End Cap
	2222919	Right Side
	2222920	Left Side
21	2222922	Bin, Utility Center
22	2257616	Door, Utility Bin
23	2222773	Bin, Door (3)
24	2222770	Bin, Door
25	W10127710	Plate, Handle



REFRIGERADOR KSSC42QVS00




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door Panel (Includes Item #14)
	W10157903	Black
2	2302879	Hinge, Bottom
3	489282	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7		Handle, Door
8	2316868	Stainless Steel Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model Skin, Door
9	2307310	Stainless Steel Screw
10	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257385	Spacer, Door-Skin (Bottom)
14	2005030	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	2328901	Top
	2328902	Bottom
17	2258951	Brace, Door Corner
18	2222776	Bin, Door (3)
19	W10127710	Plate, Door




REFRIGERADOR KSSC42QVS00



Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	486194	Screw (3)
3	W10132946	Bracket, Motor
4	2305242	Connector, Door Bracket
5	2318021	Motor, Ice Door
6	2180353	Door, Ice
7	2318020	Support, Ice Door
8	4449745	Screw (2)
9	2305235	Spigot
10	2318017	Separator Assembly
11		Housing, Middle (Not Available Order Item 12)
12	2307675US	Housing Assembly
13	2305307GN	Water, Paddle Asy
14	2305306GN	Ice, Paddle Asy
15	2305219	Cover, Control
16	2321746	Electronic Control (Includes #15)
17	W10151236	User Interface Asy
18	2318062US	Tray, Housing
19	2305342	LED Assembly



REFRIGERADOR KSSC42QVS00



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com

Illus. No.	Part No.	DESCRIPTION
1	W1013344	Inverter Box
2	489373	Screw, Compressor Mounting (4)
3	2302967	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)
4	2318087	Housing, Control Board
5	2318054	Control Board
6	1100826	Grommet, Mounting
7	2309002	Support, Condenser
8	2307693	Tube, Transiton (Cond/Ht Loop) (Right)
9	2215676	Terminal Cover
10	2309001	Support, Condenser (Left)
11	W10789107	Control Board
12	2203075	Spacer (5)
13	2256328	Bracket, Inverter Box
15	1157158	Screw
16	2307998	Condenser
17	2309431	Grommet (2)
18	2310207	Wire, Jumper

Illus. No.	Part No.	DESCRIPTION
19	489399	Screw
20	2155774	Wire Tie
21	2317982	Drier
22	W10136614	Bracket, FanMotor (Condenser Fan)
23	2188875	Motor, Fan
24	W1013948	Blade, Fan
25	2003169	Orifice, Fan
26	8533993	Screw
27	2317031	Bracket, Vibration (Condenser)
28	2317030	Arm, Vibration (Condenser)
29	2307566	Tube, Transition (Condenser/Drier)
30	2194319	Tube, Process
31	486194	Screw
32	2309000	Cover, Condenser
33	2310251	Service Cord
34	2307684	Bracket, Mounting (Power Switch)
35	549193	Clamp, Cord
36	2266802	Switch, Power Disconnect
37	487294	Screw, Ground
38	W10129829	Wiring Harness, Unit Compartment

Illus. No.	Part No.	DESCRIPTION
39	2309432	Gasket, Condenser
40	2259350	Power Supply, Ingredient Care Center

Following Parts Not Illustrated and Optional Parts Not Included


978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

7.50 oz.
(R-134A)




REFRIGERADOR KSSC42QVS00



Illus. No.	Part No.	DESCRIPTION
1	W10139908	Damper, Heater
2	486194	Screw
3	W10157752	Bracket
4	2309076	Suction Tube
5	2309070	Tube, Connect (Drier/Restrictor)
6	2320615	Drain Pan Assy.
7	W10151288	Cover, Wiring
8	W10153595	Cover, Box
9	W10121371	Tube, Discharge
10	2188820	Thermistor
11	2306093	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater (2)
14	W10160981	Seal, Return Air
15	2220832	Gasket, Evaporator
16	2155774	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
19	9791833	Clip, Thermistor
20	W10160981	Bracket Assembly, Air Return



REFRIGERADOR KSSC42QVS00



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com

Illus No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2320601	Shield, Valve	17		Motor, (Not Serviceable Order Item 28)	30	489464	
2	2310191	Wire Assembly, Icemaker	18	628356	Cup-Water Fill	31	486194	
3	628379	Clip, Fuse Tube, Filter Inlet	19	627843	Ejector	32	2252228 B	
5	2320658	Water Tube	20	2198598	Ice Striper	100		Assembly
6	2302758	Seal Gasket	21	2194712	Support			
7	2317912	Tube, Filter Outlet	22	2315522	Retainer			
8	W10159842	Valve, Solenoid	23	628397	Thermostat (2)			
9	2221070	Clamp, Tube			Thermostat (Also Order 542639 Cement Alumilastic) Screw	Following Parts Not Illustrated (Optional Parts Only)		
10	2320559	Support, Valve	24	8533917				8537055 Cleaner, Stainless Steel
11	2198641	Bracket, Icemaker Cover	25	W10139199				W10134767 Ice Container Assembly
12	2305274	Clamp, Nylon Valve	26	489276				W10129081 Handle Kit for Previous Architect Series (Stainless)
13	2302756	Tube, Water Inlet	27	2317040				
14	2257538	Cover	28	626680	Module Assembly			
15	488500				17 & 29)			
16	W10122527		29	489136	Screw (2)			