


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	2318189	Tray, Drip Filter	32		Grille Bottom, Front
	W10303989	Use & Care Guide	12	3400525	Screw		2325185B	Black
	W10205643	Energy Guide	13	4396841	Filter, Water	33	W10004850	Screw
	W10159832	Service & Wiring Sheet	14	489399	Screw	34		Bracket, Support Base (Front)
	2306424	Icemaker and Ingredient Care Center Service Sheet	15	3400230	Screw, Door Stop		2006616	(LH)
	W10300878	Main Control Service Sheet	16	2257644	Hinge (Top)		2006556	(RH)
	W10379133	Installation Instructions	17	W10348782	Bracket, Mtg (Water Filter)	35	1157158	Screw
2		Cabinet (Not A Serviceable Part)	18	W10001250	Screw	36	2006617	Bracket, Support Base (Rear)
3	2260503B	Button, Filter	19	2004994	Lock, Adjustable Bushing	37	2006346	Washer
4	W10138054	Roller, Front & Rear	20	2300082	Bushing	38	2316859	Bushing, Extension Arm
5		Support, Leveler Assembly	21	2004514	Clip, Conduit	39	1163283	Screw
	W10138423	Refrigerator Side	22	2221242	Spring, Door Closure	40		Connector, Water Tube
	W10279275	Freezer Side	23	486194	Screw		W10271541	1/4"
6		Cap, Water Filter	24	2005008	Retaining Ring, Adjustable Bushing	41	8281163	Screw
	2260518B	Black	25	W10129069	Wire Clip	42		Switch, Rocker Arm
7	2307640	Mounting Stud, Grille	26	2006342	Gap, Cover Assembly (Bottom)		1118894	Refrigerator Door Side
8	2307584	Grommet, Crossover Tube	27		Hinge (Bottom)		1115373	Freezer Door Side
9	2005783	Cam, Door Closer		2006780	Freezer Side	43	2215938	Cover, Switch
10	W10121140	Housing, Water Filter	28	2302876	Bushing, Adjustable	44	487415	Screw
			29	8533913	Screw 1/4-20 x 5/8	45		Bracket, Switch
			30		Skirt-Grille, Bottom		2221097	(RH)
				2209025B	Black	46	2215612	Cover, Rear
			31		Extension Arm, Door Closer	47	2005032	Leveler
				2266882	(RH)	48	2006841	Ring
				2266881	(LH)	49	2307857	Cam Assembly
						50	W10167456	Wire Assembly RC/FC Light Switch




REFRIGERADOR KSSC42QVS03



Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
2		Screw
	1163283	Stainless Steel
3	2316687	Cabinet, Trim (Bottom)
4	486194	Screw
5	2314017	Cabinet, Trim Top
6		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
7	W10121451	Nutsert
8	2005925	Seal-Trim, Side
9	W10001250	Screw


BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM

www.denek.com



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed
3	2259082	Basket
4	2256270	Front, Basket
5		Slide, Basket
	2259317	(RH)
	2259318	(LH)
6	8533928	Screw






REFRIGERADOR KSSC42QVS03

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2259077	Ladder, Shelf
5	520965	Screw Support, Ladder
6	2006475	Screw
7	487539	Screw
8	2302937	Thermistor
9	2302986	Lid, Meat Pan Baffle
10	W10169528	Baffle Control Assembly
11	2317844	Thermistor Assy
12	2310205	Jumper, Air Baffle
13	8533929	Screw
14	486194	Screw
15	2221296	Air Baffle Assembly
16	2327509	Water Reservoir
17	W10141518	Screw
18	2309222	Diffuser Assembly
19	2317105	Cover, Thermistor
20	2188820	Thermistor
21	W10475010	Spacer, Air-Baffle
22	2309087	Cover, Diffuser
23	2259412	Seal, Air Duct (Round Hole)
24	2259398	Seal, Air Duct (Square Hole)
25	2003577	Guard
26	W10159487	Diverter




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	W10468940	Control Box
2	2317000	Clip, Box
3	2310390	Wire, Jumper
4	2307592	Bracket, Control Box
5	2307595	Shield, Control Box
6	487539	Screw
7	2306086	Display, Ingredient Care Center
8	W10191429	Socket, Light
9	2326255	Light Bulb
10	W10142283	Screw




Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly
	2316737S	Stainless Steel
2	W10188580	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10185625	Cover, Unit Front
6	2317923S	Badge, Kitchen Aid
7	2004333	Nut
8	2215910	Grommet-Flexible




Illus. No.	Part No.	DESCRIPTION
1	2222592	Shelf Assembly
2	2179404	Rack, Wine
3	2302842	Assembly, Meat Pan Cover
4	2302835	Assembly, Crisper Cover
5	W10407624	Crisper Pan
6		Slide, Meat Pan
	2302954	(LH)
	2302955	(RH)
7	2256248	Front, Crisper Pan
8		Spacer, Crisper
	2256222	(RH)
	2256223	(LH)
9		Slide, Crisper
	2302956	(LH)
	2302957	(RH)
10		Spacer, Meat Pan
	2256243	(LH)
	2256244	(RH)
11		Screw
	8533929	Right Side- (8-18 x 1.375)
	8533928	Left Side- (8-18 x .750)
12	W10407627	Pan Assembly Meat
13	2256366	Front, Meat Pan



REFRIGERADOR KSSC42QVS03




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor	19	2215650	Cover, Emitter	33	2259493	Cover, Receiver
2	2198665	Tube, P.C. Board	20		Liner (Not A Serviceable Part)	34	W10139189	Harness, Evap Fan (Includes Item 45)
3	2169142	Fan Blade	21	2259025	Cover, Air Outlet	35	2306010	Thermistor
4	2223733	Retainer, Fan Motor	22	2307751	Light Shield	36	2317105	Cover, Thermistor
5	2302817	Gasket, Cover	23	W10428000	Cover, Evaporator	37	2006475	Screw
6	W10449920	Grommet	24	2302850	Support, Air Duct	38	2259032	Ladder, Shelf
7	486194	Screw	25	487539	Screw	39	2259445	Support, Screw
8	2259464	Wedge, Air Duct	26	2198635	Spring	40	2198634	Pin
9	486194	Screw, Ground	27	2309283	Deflector, Air Duct	41	W10193840	P.C. Board Emitter
10	W10191429	Socket, Light	28	1112260	Support, Evaporator	42	2198633	Flipper
11	2221070	Clamp, Nylon	29	2196205	Shelf, Stud	43	2255563	Slide, Icemaker Shut Off
12	2326255	Light Bulb	30	W10191952	Screw	44	W10290817	P.C. Board, Receiver
13	489214	Screw	31		Evaporator, Cover Rail	45	W10160570	Defrost, Bi-Metal
14	2182120	Scroll, Fan		2221107	(LH)	46	W10142283	Screw
15	2259465	Wedge, Air Duct		2259355	(RH)	47	W10267707	Insulation, Sound
16	2307774	Air Duct	32	2220904	Gasket	48	2317844	Thermistor Assy
17	2198643	Lens			Evaporator Cover			
18		Block, Fan Scroll						
	2209480	(RH)						
	2209066	(LH)						






REFRIGERADOR KSSC42QVS03


Illus. No.	Part No.	DESCRIPTION
1	2222965	Ice Bin
2	W10395657	Ice Container Assembly
3	2252265	Button, Bin
4	W10134783	Latch, Bin
5	2198608	Spring, Latch
6	2198671	Screw
7	8281163	Screw
8	2188919	Holder
9	2198628	Seal
10	2318082	Drive Shaft
11	2318011	Enclosure, Motor
12	2315547	Dispenser, Motor
13	2318028	Cover
14	2315559	Sleeve. Coupling
15	W10254073	Rubber, Washer




Illus. No.	Part No.	DESCRIPTION
1	W10193490	Refrigerator Door Panel (Includes Item #9)
2	W10127710	Plate Door, Handle
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10		Skin, Door
11	2307753	Stainless Steel Handle, Door
12	2316868	Stainless Steel Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
13	488568	Screw
14		Screw, 8-15 x .500
	8281250	Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	308544	Screw, Handle
17	W10142296	Spacer, Door-Skin (Hinge Side)
18	2004934	Spacer, Door-Skin (Bottom)
20		End Cap
	W10323172	(RH)
	W10323173	(LH)
21	W10323036	Bin, Utility Center
22	2257616	Door, Utility Bin
23	W10323599	Bin, Door
24	W10323747	Bin, Door




Illus. No.	Part No.	DESCRIPTION
1	W10292446	Freezer Door Panel (Includes Item #6)
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7		Handle, Door
	2316868	Stainless Steel
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9		Skin, Door
	2307310	Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257385	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	2328901	Top
	2328902	Bottom
17	W10127710	Plate Door, Handle
18	W10323602	Bin, Door




Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	486194	Screw
3	W10132946	Bracket, Motor
4	2305242	Connector, Door Bracket
5	W10205979	Motor, Ice Door
6	2180353	Door, Ice
7	2318020	Support, Ice Door
8	4449745	Screw
9	2305235	Spigot
10	2318017	Separator Assembly
11		Housing, Middle (Not Available Order Item 12)
12	W10260622	Housing Assembly
13	2305307GN	Water, Paddle Asy
14	2305306GN	Ice, Paddle Asy
15	2305219	Cover, Control
16	2321746	Electronic Control (Includes #15)
17	W10151236	User Interface Asy
18	2318062US	Tray, Housing
19	2305342	LED Assembly
20	2305447	Clip, Wiring



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box	19	489399	Screw	39	2309432	Gasket, Condenser
2	489373	Screw, Compressor Mounting	20	2155774	Wire Tie	40	2259350	Power Supply, Ingredient Care Center
3	W10165563	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)	21	W10175593	Drier	Following Parts Not Illustrated and Optional Parts Not Included		
4	2318087	Housing, Control Board	22	W10414681	Bracket, Fan Motor (Condenser Fan)			
5	2318054	Control Board	23	2188875	Motor, Fan	978025		Valve, Access (1/4")
6	1100826	Grommet, Mounting	24	W10139483	Blade, Fan	978026		Valve, Access (5/16")
7	W10415668	Support, Condenser	25	W10415670	Orifice, Fan	978027		Valve, Access (3/8")
8	W10234131	Tube, Transiton (Cond/Ht Loop) (Right)	26	8533993	Screw	978028		Valve, Access (1/2")
9	2215676	Terminal Cover	27	2317031	Bracket, Vibration (Condenser)	978029		Valve, Access (5/8")
10	W10415666	Support, Condenser (Left)	28	2317030	Arm, Vibration (Condenser)	978030		Valve, Access (3/4")
11	W10789107	Control Board	29	2307566	Tube, Transition (Condenser/Drier)	876764		Valve, Access (3/16")
12	2203075	Spacer	30	2194319	Tube, Process	<u>REFRIGERANT CHARGE</u>		
13	2256328	Bracket, Inverter Box	31	486194	Screw	7.50 oz. (R-134A)		
14	487539	Screw	32	2309000	Cover, Condenser			
15	1157158	Screw	33	2310251	Service Cord			
16	2307998	Condenser	34	W10185556	Bracket, Mounting (Power Switch)			
18	2310207	Wire, Jumper	35	549193	Clamp, Cord			
			36	2266802	Switch, Power Disconnect			
			37	487294	Screw, Ground			
			38	W10178860	Wiring Harness, Unit Compartment			



Illus. No.	Part No.	DESCRIPTION
1	W10139908	Cover, Seal
2	486194	Screw
3	W10157752	Bracket
4	W10431124	Suction Tube Oil Trap
5	W10388653	Tube, Connect (Drier/Restrictor)
6	W10281063	Drain Pan Assy.
7	W10309012	Cover, Wiring
8	W10321048	Cover, Box
9	W10412488	Tube, Discharge
10	2188820	Thermistor
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
15	W10432308	Gasket, Evaporator
16	4389107	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
20	2215648	Dampener
21	W10160981	Bracket Assy



Illus. No.	Part No.	DESCRIPTION
1	2320601	Shield, Valve
2	2310191	Wire Assembly, Icemaker
3	628379	Clip, Fuse
4	W10296807	Tube, Filter Inlet
7	2317912	Tube, Filter Outlet
8	W10159842	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2198641	Bracket, Icemaker Cover
12	2208136	Clamp, Nylon Valve
13	W10357286	Fitting, Water
14	W10289690	Cover
15	W10141604	Screw
16	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)

Illus. No.	Part No.	DESCRIPTION
17		Motor, (Not Serviceable Order Item 28)
18	W10272168	Cup-WaterFill
19	627843	Ejector
20	W10272161	Ice Stripper
21	2194712	Support
22	2315522	Retainer
23	W10290336	Thermostat (Also Order 542639 Cement Alumilastic)
24	8533917	Screw
25	W10279391	Wire Assembly
26	489276	Screw
27	2317040	Cover, Icemaker
28	W10223929	Module Assembly (Includes Items 17 & 29)
29	489136	Screw
30	W10001250	Screw

Illus. No.	Part No.	DESCRIPTION
31	486194	Screw
32	2252228	Bracket, Icemaker Mounting
100	2320636	Complete Icemaker Assembly

Following Parts Not Illustrated (Optional Parts Only)

W10355016	Affresh Stainless Steel Cleaner
W10355010	Affresh Kitchen Appliance Cleaner
W10355049	Affresh Stainless Steel Wipes
REFDEODOR	Deodorizer Pack
W10129081	Handle Kit for Previous Architect Series (Stainless)