




REFRIGERADOR KSSC42QVS04

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10303989	Use & Care Guide
	W10205643	Energy Guide
	W10483315	Service & Wiring Sheet
	2306424	Icemaker and Ingredient Care Center Service Sheet
	W10469184	Main Control Service Sheet
	W10379133	Installation Instructions
2		Cabinet (Not Serviced)
3	2318189	Tray, Drip Filter
4	W10138054	Roller Assembly, Front & Rear
5		Support, Base Assy
	W10138423	Right Side
	W10279275	Left Side
6	2260518B	Cap, Water Filter
7	2307640	Mounting Bracket, Grille
8	2320509	Cam, Door Closer
9	W10121140	Housing, Water Filter


Illus. No.	Part No.	DESCRIPTION
10	2307584	Grommet, Crossover Tube (Left Side)
11	3400525	Screw
12	4396841	Filter, Water
13	8281164	Screw
14	W10189203	Screw
15	2257644	Hinge, Top
16	W10348782	Mounting Bracket, Filter
17	W10001250	Screw
18	2004994	Lock, Adjustable Bushing
19	2300082	Bushing
20	2221242	Door Closer Spring
21	3400230	Screw
22	2005008	Retaining Ring, Adjustable Bushing
23	2215612	Cover, Air Duct
24		Bracket, Switch
	2221097	Right Side
	2221096	Left Side
25		Hinge, Bottom
	2006780	Left Side
	2006779	Right Side
26	2302876	Adjustable Bushing
27	8533913	Screw
28	2209025B	Grille Skirt, Bottom

Illus. No.	Part No.	DESCRIPTION
29		Extension Arm
	2266882	Right Side
	2266881	Left Side
30	2325185B	Grille Base, Bottom
31	W10485630	Screw
32	487415	Screw
33	1163283	Screw
34	2006617	Bracket, Support Base (Rear)
35	2215938	Cover, Switch
36	2316859	Bushing, Extension Arm
37	W10167456	Wire Assembly, Light Switch
38	2260503B	Button, Filter
39		Switch, Rocker Arm
	1118894	Right Side
	1115373	Left Side
40	8281163	Screw
41	W10005050	Screw
42	W10271541	Connector, Water Tube
43	2004514	Clip, Conduit
44		Bracket, Support
	2006616	Left
	2006556	Right
45	W10141604	Screw



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	W10132472	Cabinet, Trim (Right Side)
2	W10001250	Screw
3	1163283	Screw
4	2316687	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314017	Cabinet Trim (Top)
7	W10132541	Cabinet Trim (Left Side)
8	W10121451	Insert
9	2005925	Trim Seal, Side




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed
3	2259082	Basket
4	2256270	Front, Basket
5		Slide, Basket
	2259317	Right Side
	2259318	Left Side
6	8533928	Screw







REFRIGERADOR KSSC42QVS04






REFRIGERADOR KSSC42QVS04

<u>Illus. No.</u>	<u>Part No.</u>	<u>DESCRIPTION</u>
1		Liner (Not Serviced)
2	2306010	Thermistor
3	2208970	Air Duct
4	487539	Screw
5	2259077	Ladder, Shelf
6	520965	Support, Screw
	2006475	Screw
8	2309087	Cover, Diffuser
9	2302937	Thermistor
10	W10475010	Spacer, Assembly
11	W10169528	Baffle Control Assembly
12	2327509	Reservoir
13	2188820	Thermistor
14	8533929	Screw
15	486194	Screw
16	2317844	Thermistor Assy
17	2221296	Air Baffle Assy
18	2309222	Diffuser Assembly
19	W10191429	Socket, Light
20	2307751	Shield, Light
21	2326255	Bulb, Light
22	W10468940	Control Box Assy
23	2317000	Clip, Control Box
24	8281163	Screw
25	2306086	UI Control Assy
26	W10142283	Screw
27		Spacer, Meat Pan
	2256244	Right Side
	2256243	Left Side
28		Slide, Meat Pan
	2302955	Right Side
	2302954	Left Side
29		Spacer, Crisper
	2256222	Right Side
	2256223	Left Side
30		Slide, Crisper
	2302957	Right Side
	2302956	Left Side
31		Screw
	8533929	Right Side
	8533928	Left Side
32	W10141518	Screw
33	2003577	Guard, Return Air
34	W101598487	Diverter, Crisper
35	2310205	Jumper, Air Baffle




Illus. No.	Part No.	DESCRIPTION
1	2222592	Shelf Assembly
2	W10407624	Crisper Pan Assy
3	2302842	Cover Assembly, Meat Pan
4	2302835	Cover Assembly, Crisper
5	W10407627	Meat Pan Assembly
6	2256248	Front, Crisper
7	2256366	Front, Meat Pan
8	2179404	Rack, Wine



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	W10321106	Top Grille Assembly
2	W10188580	Cover, Unit
3	1157158	Screw
4	2256466	Back Panel
5	W10185625	Cover, Unit Front
6	2317923S	Badge, Jenn-Air



Illus. No.	Part No.	DESCRIPTION
1	W10436861	Fan Motor
2	2198665	Circuit Board Tube
3	2169142	Fan Blade
4	W10260421	Retainer, Fan Motor
5	2302817	Gasket, Fan Scroll
6	W10321090	Grommet
7	486194	Screw
8	2259464	Wedge, Air Duct (Right)
9	487539	Screw
10	W10191429	Socket, Light
11	W10290817	Circuit Board, Receiver
12	2326255	Light Bulb
13	489214	Screw
14	2182120	Scroll, Fan
15	2259465	Wedge, Air Duct (Left)

Illus. No.	Part No.	DESCRIPTION
16	W10142283	Screw
17	2307774	Air Duct
18	2198643	Lens
19		Block, Fan Scroll
	2209480	Right
	2209066	Left
20	2215650	Cover, Emitter
21		Liner (Not Serviced)
22	W10160570	Defrost, Bi-Metal
23	2259025	Cover, Air Outlet
24	2307751	Light Shield
25	W10428000	Cover, Evaporator
26	2302850	Support, Air Duct
27	8281251	Screw
28	2198635	Spring
29	2255563	Slide, Icemaker Shut Off
30	1112260	Support, Evaporator


Illus. No.	Part No.	DESCRIPTION
31	W10173127	Stud, Shelf
32	8281163	Screw
33		Rail, Evaporator Cover
	2221107	Left Side
	2259355	Right Side
34	2220904	Gasket, Evaporator Cover
35	2259493	Cover, Receiver
36	W10139189	Harness, Evap Fan (Includes Item 22)
37	2306010	Thermistor
38	2317844	Thermistor Assy
39	2006475	Screw
40	2259032	Ladder, Shelf
41	2259445	Support, Screw
42	2198634	Pin
43	W10193840	Circuit Board, Emitter
44	2198633	Flipper





REFRIGERADOR KSSC42QVS04


Illus. No.	Part No.	DESCRIPTION
1	W10193490	Refrigerator Door (Includes Item 9)
2	2006346	Washer
3	2266854	Hinge Assembly, Top
4	2316804	Spacer, Hinge
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Utility Bin Gasket
9	2222811	Door Gasket, Magnetic
10	2307753	Skin, Door
11	2316868	Handle, Door
12	2309060	Spacer Assy, Door (Handle Side)
13	488568	Screw
14	8281250	Screw
15	2005433	Spacer, Door Skin (Top)
16	W10142296	Spacer Assy, Door (Hinge Side)
17	2004934	Spacer, Door Skin (Bottom)
18	2006342	Gap Cover, Bottom
19		Utility Bin Endcap W10323172 Right Side W10323173 Left Side
20	W10323036	Utility Center Bin
21	2257616	Lid, Utility Bin
22	W10323599	Door Bin
23	W10323747	Door Bin (Gallon)
24	W10127710	Plate, Door Handle
25	308544	Screw






REFRIGERADOR KSSC42QVS04

Illus. No.	Part No.	DESCRIPTION
1	W10292446	Freezer Door (Includes Item 7 And Dispenser Front Parts)
2	W10127710	Plate, Door Handle
3	2302879	Hinge, Bottom
4	W10162602	Screw
5	2266854	Hinge, Top
6	2316804	Spacer, Hinge
7	2222814	Door Gasket, Magnetic
8	2316868	Handle, Door
9	2309060	Spacer Assy, Door (Handle Side)
10	2307310	Skin, Door
11	8281250	Screw
12	2005433	Spacer, Door Skin (Top)
13	488568	Screw
14	2257385	Spacer, Door Skin (Bottom)
15	W10142296	Spacer Assy, Door (Hinge Side)
16	308544	Screw
17	2006342	Gap, Cover Bottom
18	W10323602	Bin, Door
20	2006346	Washer



Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	8281163	Screw
3	W10132946	Bracket, Motor
4	2305242	Connector, Door Bracket
5	W10205979	Motor, Ice Door
6	W10504458	Door, Ice
7	2318020	Support, Ice Door
8	4449745	Screw
9	2305235	Spigot
10	2318017	Separator Assembly
11		Housing, Middle (Not Available Order Item 12)
12	W10260622	Housing Assembly
13	2305307GN	Water Paddle Assy
14	2305306GN	Ice Paddle Assy
15	2305219	Cover, Control
16	2321746	Electronic Control (Includes Item 15)
17	W10151236	UI Assy, Dispenser
18	2318062US	Tray, Housing
19	2305342	LED Assembly




Illus. No.	Part No.	DESCRIPTION
1	W10449006	Inverter Box
2	489373	Screw
3	W10165563	Compressor
4	W10321056	Housing, Control Board
5	2309432	Gasket, Condenser
6	1100826	Grommet, Mounting
7	W10415668	Support, Condenser (Right)
8	2259350	Power Supply
9	2215676	Terminal Cover
10	W10415666	Support, Condenser (Left)
11	W10427079	Control Board
12	2203075	Spacer
13	2256328	Bracket, Inverter Box
14	W10356040	Electronic Control
15	1157158	Screw
16	2307998	Condenser
17	W10427091	Wire Assy, Unit
18	2310207	Wire, Jumper
19	489399	Screw
20	2155774	Wire Tie
21	W10175593	Drier

Illus. No.	Part No.	DESCRIPTION
22	W10414681	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Fan
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	487294	Screw
27	8533993	Screw
28	2317031	Bracket, Vibration (Condenser)
29	2317030	Arm, Vibration (Condenser)
30	2307566	Tube, Transition (Condenser/Drier)
31	2194319	Tube, Process
32	486194	Screw
33	2309000	Cover, Condenser
34	2310251	Service Cord
35	W10321055	Bracket, Mounting (Power Switch)
36	549193	Clamp, Cord
37	2266802	Switch, Power Disconnect
38	W10483905	Inverter Jumper
39	W10495645	Inverter Ground
40	2318054	Control Board


Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

7.50 oz.
(R-134A)



Illus. No.	Part No.	DESCRIPTION
1	W10160981	Bracket Assembly, Air Return
2	W10388653	Tube, Transition (Drier/Restrictor)
3	486194	Screw
4	W10157752	Bracket, Heater Mounting
5	W10431124	Suction Tube
6	W10281063	Drain Pan Assy
7	W10309012	Wire Cover Bottom
8	W10321048	Wire Cover Box
9	W10412488	Tube, Discharge
10	W10321050	Wire Shield Cover
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10413009	Grommet
15	W10139908	Seal, Return Air
16	W10432308	Gasket, Evaporator
17	2155774	Wire Tie
18	W10169509	Clip, Retainer
19	2320554	Support, Drain Pan
20	2215648	Dampener
21	304392	Screw
22	W10234131	Tube, Transition (Condenser/Heater)





Illus. No.	Part No.	DESCRIPTION
1	304392	Screw
2	2320601	Shield, Valve
3	628379	Clip, Fuse
4	W10296807	Tube, Filter Inlet
5	W10357286	Fitting, Water
6	487294	Screw
7	W10437853	Tube, Filter Outlet
8	W10159842	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2208136	Clip, Water Tube
12	W10141645	Screw
13	W10289690	Cover, Front
14	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)
15		Motor (Not Serviced, Order Item 26)
16	W10272168	Cup, Water Fill
17	627843	Ejector

Illus. No.	Part No.	DESCRIPTION
18	W10272161	Ice Stripper
19	2194712	Support
20	2315522	Retainer, Thermostat
21	W10290336	Thermostat (Also Order 542639 Cement Alumilastic)
22	W10001280	Screw
23	W10279391	Wire Assembly, Smart Valve
24	489276	Screw
25	2317040	Cover, Icemaker
26	W10223929	Module Assembly (Includes Items 15 & 27)
27	489136	Screw
28	W10129069	Clip, Tube
29	486194	Screw
30	2252228	Bracket, Icemaker Mounting
31	2310191	Wire Assembly, Icemaker

Illus. No.	Part No.	DESCRIPTION
32	W10001250	Screw
33	2198641	Bracket, Icemaker Cover
34	487539	Screw
100	W10277448	Complete Icemaker Assembly

**Following Parts Not Illustrated
(Optional Parts Only)**

W10355016	affresh Stainless Steel Cleaner
W10355049	affresh Stainless Steel Wipes
W10355010	affresh Kitchen Appliance Cleaner



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|-----------|------------------------|
| 1 | 2222965 | Ice Bin |
| 2 | W10134774 | Crusher Bin |
| 3 | 2252265 | Button, Bin |
| 4 | W10134783 | Latch, Bin |
| 5 | 2198608 | Spring, Latch |
| 6 | 2198671 | Screw |
| 7 | 8281163 | Screw |
| 8 | 2188919 | Clip, Shaft |
| 9 | 2198628 | Seal |
| 10 | 2318082 | Shaft, Motor Assembly |
| 11 | 2318011 | Enclosure, Motor |
| 12 | 2315547 | Dispenser, Motor |
| 13 | 2318028 | Cover |
| 15 | W10395657 | Ice Container Assembly |
| 16 | W10254073 | Washer, Rubber |