


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	2257644	Hinge, Top	32	487415	Screw
	W10303989	Use & Care Guide	16	W10348782	Bracket, Filter	33	1163283	Screw
	W10205643	Energy Guide	17	W10001250	Screw	34	2006617	Bracket, Support Base
	W10483315	Service & Wiring Sheet	18	2004994	Lock, Bushing	35	2215938	Cover, Switch
	2306424	Icemaker and Ingredient Care Center Service Sheet	19	W10484913	Bushing, Top Hinge	36	2316859	Bushing, Extension Arm
	W10469184	Main Control Service Sheet	20		Spring, Door Closure	37	W10167456	Assembly, RC Wire
	W10379133	Installation Instructions		2221242	Green	38		Button, Water Filter
2		Cabinet (Not Serviced)	21	3400230	Screw, Door Stop		2260503B	Black
3	2318189	Tray, Drip Filter	22	2005008	Retaining Ring, Adjustable Bushing	39		Switch, Rocker Arm
4	W10138054	Assembly, Roller	23	2215612	Cover, Air Duct		1118894	Switch, Rocker Arm(Ref)
5		Support, Base Assy	24		Bracket, Switch		1115373	Switch, Rocker Arm, Combination(Freezer)
	W10138423	Right Hand		2221097	Right Hand	40	8281163	Screw
	W10279275	Left Hand		2221096	Left Hand	41	W10005050	Screw
6		Cap, Water Filter	25		Hinge, Bottom	42	W10271541	Connector, Water Tube
	2260518B	Black		2006780	Refrigerator	43	2004514	Clip
7	2307640	Mounting Bracket, Grill		2006779	Freezer	44		Bracket, Support
8	2320509	Stop, Door	26	2302876	Bushing, Extension Arm		2006616	Left Hand
9	W10121140	Housing, Water Filter	27	8533913	Screw		2006556	Right Hand
10	2307584	Grommet, Crossover Tube	28		Skirt-Grille, Bottom	45	W10141604	Screw
11	3400525	Screw		2209025B	Black	46	2005032	Leveler, Adjustable
12	W10121146	Filter, Water	29		Extension Arm			
13	8281164	Screw		2266882	Right Hand			
14	W10485630	Screw		2266881	Left Hand			
			30		Grille, Bottom			
				2325185B	Black			
			31	W10485630	Screw			






REFRIGERADOR KSSC42QVS05

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10132472	Trim, Cab Side (Right)
2	W10001250	Screw
3	1163283	Screw
4	2316687	Cabinet Trim, Bottom

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	486194	Screw
6	2314017	Trim, Top Cab
7	W10132541	Trim, Cab Side (Left)


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10121451	Insert, Blind Threaded
9	2005925	Trim, Side Seal



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	
1		Liner (Not Serviced)	18	2309222	Diffuser Assembly	29		Spacer, Crisper	
2	2306010	Thermistor	19	W10191429	Socket, Light		2256222	Right Hand	
3	2208970	Air Duct	20	2307751	Light Shield	30	2256223	Left Hand	
4	487539	Screw	21	2326255	Bulb, Light			Slide, Crisper	
5	2259077	Ladder, Shelf	22	W10468940	Control Box Assembly		2302957	Right Hand	
6	520965	Support, Ladder	23	2317000	Clip, Control Box	31	2302956	Left Hand	
	2006475	Screw	24	8281163	Screw			Screw	
8	2309087	Cover, Diffuser	25	2306086	Display Board, Ingredient Care Center		8533929	Stainless	
9	2302937	Thermistor Assembly	26		Screw			Left Hand	
10	W10475010	Assembly, Spacer	27	W10142283	White		8533928	Stainless	
11	W10169528	Baffle, Control Assembly			Spacer, Meat Pan	32	W10141518	Screw	
12	2327509	Reservoir, Water			2256244	Right Hand	33	2003577	Guard, Air Return
13	2188820	Thermistor, RC			2256243	Left Hand	34	W10159487	Diverter, Crisper Cover
14		Screw	28		Slide, Meat Pan	35	2310205	Harness, Air Baffle	
	8533929	Stainless			2302955	Right Hand			
15	486194	Screw			2302954	Left Hand			
16	2317844	Assembly, Thermistor							
17	2221296	Air Baffle Assembly							



REFRIGERADOR KSSC42QVS05



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com



REFRIGERADOR KSSC42QVS05



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan
2	2198665	Tube, Circuit Board
3	2169142	Blade, Fan
4	W10260421	Retainer, Fan Motor
5	2302817	Gasket, Cover
6	W10321090	Grommet, Motor
7	486194	Screw
8	2259464	Wedge, Right Air Duct
9	487539	Screw
10	W10191429	Socket, Light
11	W10290817	P.C. Board Receiver
12	2326255	Bulb, Light
13	489214	Screw
14	2182120	Fan Scroll
15	2259465	Wedge, Left Air Duct
16		Screw
	W10142283	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	2307774	Air Duct
18	2198643	Lens, Receiver
19		Block, Fan Scroll
	2209480	Right Hand
	2209066	Left Hand
20	2215650	Cover, Emitter
21		Liner (Not Serviced)
22	W10160570	Bi-Metal, Defrost
23	2259025	Cover, Air Outlet
24	2307751	Light Shield
25	W10428000	Cover, Evaporator
26	2302850	Support, Air Duct
27	8281251	Screw
28	2198635	Spring, Door
29	2255563	Slide, Icemaker Shut Off
30	1112260	Support, Evaporator

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
31	W10173127	Stud Assembly
32	8281163	Screw
33		Rail, Evaporator Cover
	2221107	Left Hand
	2259355	Right Hand
34	2220904	Gasket, Evaporator Cover
35	2259493	Cover, Receiver
36	W10482187	Harness, Bi-Metal Wire
37	2306010	Thermistor
38	2317844	Assembly, Thermistor
39	2006475	Screw
40	2259032	Ladder, Shelf
41	2259445	Support, Ladder Screw
42	2198634	Pin, Door
43	W10193840	P.C. Board, Emitter
44	2198633	Flipper Shut Off



REFRIGERADOR KSSC42QVS05





REFRIGERADOR KSSC42QVS05

Illus.
No. **Part No.** **Description**


- 1 2222965 Ice Bin
- 2 W10134774 Crusher Bin
- 3 2252265 Button, Bin
- 4 W10134783 Latch, Bin
- 5 2198608 Spring, Latch IDI Motor

Illus.
No. **Part No.** **Description**


- 6 2198671 Screw
- 7 8281163 Screw
- 8 2188919 Clip, Shaft
- 9 2198628 Seal
- 10 2318082 Drive Shaft

Illus.
No. **Part No.** **Description**

- 11 2318011 Enclosure, Motor
- 12 2315547 Motor, Dispenser
- 13 2318028 Cover
- 15 W10395657 Ice Container Assembly
- 16 W10254073 Washer




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222592	Shelf Assembly	5	W10407627	Pan Assembly Meat	7	2256366	Front, Meat Pan
2	W10407624	Crisper Pan	6	2256248	Front, Crisper Pan	8	2179404	Rack, Wine
3	2302842	Meat Pan Cover Assembly						
4	2302835	Assembly, Crisper Cover						




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed
3	2259082	Basket
4	2256270	Front, Basket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259317	Right Hand
	2259318	Left Hand


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Screw
	8533928	Stainless



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10193490	Door Assembly, Refrigerator	12	2309060	Spacer Assembly, Door Handle Side	22	W10323599	Bin, Door-Shallow
2	2006346	Washer, Extension Arm	13	488568	Screw	23	W10323747	Shelf, Door (Gallon)
3	W10485980	Assembly, Top Hinge	14		Screw	24	W10127710	Plate, Handle Door
4	2316804	Spacer, Door Hinge Bottom	15	8281250	Stainless	25	308544	Screw
5	W10162602	Screw	16	2005433	Spacer, Door Skin Top			
6	2302878	Hinge Assembly, Bottom	17	W10142296	Spacer, Door			
7	2222796	Rail, Lid	18	2004934	Spacer, Door Skin Bottom			
8	2222982	Gasket, Utility Bin	19	W10482554	Cover, Bottom Gap			
9	2222811	Door Gasket, Magnetic			Utility Bin Endcap			
10	W10523739	Skin, Door		W10323172	Right Hand			
11	2316868	Door Handle Stainless		W10323173	Left Hand			
			20	W10323036	Bin, Utility Center			
			21	2257616	Door, Utility Bin			



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10292432	Door Assembly, Freezer	8		Door Handle	14	2257385	Spacer, Door-Skin (Bottom)
2	W10127710	Plate, Handle Door		2316868	Stainless	15	W10142296	Spacer, Door
3	2302879	Assembly, Bottom Hinge Leaf	9	2309060	Spacer Assembly, Door Handle Side	16	308544	Screw
4	W10162602	Screw	10	W10523759	Skin, Door	17	W10482554	Cover, Bottom Gap
5	W10485980	Assembly, Top Hinge	11		Screw	18	W10323602	Bin, Door
6	2316804	Spacer, Door Hinge Bottom		8281250	Stainless	20	2006346	Washer, Extension Arm
7	2222814	Door Gasket, Magnetic	12	2005433	Spacer, Door Skin Top			
			13	488568	Screw			




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2	8281163	Screw
3	W10542660	Bracket, Motor
4	W10546285	Assembly, Motor & Bracket
5	W10205979	Motor, Ice Door
6	W10504458	Door, Ice
7	W10542663	Support, Ice Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	4449745	Screw
9	2305235	Assembly, Spigot
10	2318017	Assembly, Separator
11		Housing, Middle (Not Available Order Item 12)
12	W10260622	Housing Assembly
13	2305307GN	Pad, Water
14	2305306GN	Pad, Ice

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	2305219	Cover, Control
16	2321746	Assembly, UI Control Cover
17	W10151236	Assembly, User Interface
18	2318062US	Assembly, Drip Tray
19	2305342	Assembly, LED



REFRIGERADOR KSSC42QVS05






REFRIGERADOR KSSC42QVS05

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10321106	Top Grille Assembly
2	W10188580	Cover, Unit

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	1157158	Screw
4	2256466	Panel, Back
5	W10185625	Unit Cover, Front


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Nameplate
	2317923S	Grey



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10449006	Inverter Box Assembly
2	489373	Screw
3	W10165563	Compressor (Also Order 876765 Tube Kit)
4	W10321056	Housing, Control Board
5	2309432	Gasket, Condenser
6	1100826	Grommet
7		Support, Condenser
	W10415668	Right Hand
	W10415666	Left Hand
8	2259350	Power Supply, Ingredient Care Center
9	2215676	Cover, Terminal
11	W10427079	Board, Control
12	2203075	Spacer Box Box
13	2256328	Bracket, Inverter Mounting
14	W10356040	Control, Electronic
15	1157158	Screw
16	2307998	Condenser

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10427091	Assembly, Unit Wire
18	2310207	Wire Assembly
19	489399	Screw
20	2155774	Tie, Wire
21	W10175593	Drier
22	W10414681	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Condenser
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	487294	Screw
27	8533993	Screw
28	2317031	Assembly, Bracket
29	2317030	Assembly, Arm
30	2307566	Tube, Drier Transition
31	2194319	Tube, Process
32	486194	Screw
33	2309000	Cover, Condenser
34	2310251	Service Cord
35	W10321055	Bracket, Mounting (Power Switch)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
36	549193	Clamp, Power Cord
37	2266802	Switch, Power Disconnect
38	W10483905	Jumper, Inverter
39	W10495645	Ground, Inverter
40	2318054	Control, Electronic
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		7.50 oz. (R-134A)




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10160981	Bracket, Air Return Assembly
2	W10388653	Tube, Connect Drier Restrictor
3	486194	Screw
4	W10157752	Bracket, Heater
5	W10306442	Tube, Oil Trap Suction
6	W10281063	Drain Pan Assembly
7	W10309012	Cover, Wiring
8	W10321048	Cover, Wire Box

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10412488	Tube, Discharge
10	W10321050	Shelf, Wiring Cover
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10413009	Grommet Air Return
15	W10139908	Cover, Evap Seal
16	W10432308	Gasket, Evaporator
17	2155774	Tie, Wire

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10169509	Clip, Heat Exchanger
19	2320554	Support, Drain Pan
20	2215648	Dampener
21	304392	Screw
22	W10234131	Tube, Heat Loop Transition



REFRIGERADOR KSSC42QVS05



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	304392	Screw
2	2320601	Shield, Water Valve
3	628379	Clip, Thermal Fuse
4	W10296807	Tube, Filter Inlet
5	W10357286	Fitting, Water
6	487294	Screw
7	W10437853	Tube, Filter Outlet
8	W10159842	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2208136	Clip, Water Tube
12	W10141645	Screw
13	W10289690	Cover, Icemaker
14	W10122527	Mold & Heater Assembly

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15		Motor (Not Serviced, Order Item 26)
16	W10272168	Cup, Water Fill
17	627843	Ejector
18	W10272161	Stripper, Ice
19	2194712	Support, Housing
20	2315522	Retainer, Thermostat
21	W10290336	Thermostat
22	W10001280	Screw
23	W10279391	Wire Assembly, Smart Valve
24	489276	Screw
25	W10504753	Cover, Icemaker
26	W10223929	Assembly, Module
27	489136	Screw
28	W10129069	Clip, Harness

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
29	486194	Screw
30	2252228	Bracket, Icemaker Mounting
31	W10508659	Assembly, Icemaker Wire
32	W10001250	Screw
33	2198641	Bracket, Ice Maker Cover
34	487539	Screw
100	W10277448	Complete Icemaker Assembly
		Following Parts Not Illustrated
	W10355016	SS Cleaner
	W10355049	SS Cleaning Wipes
	W10355010	Kitchen & Appliance Cleaner