



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	2257644	Hinge, Top	33	1163283	Screw
	W10303989	Use & Care Guide	16	W10348782	Bracket, Filter	34	2006617	Bracket, Base Support
	W10205643	Energy Guide	17	W10001250	Screw	35	2215938	Cover, Switch
	W10483315	Service & Wiring Sheet	18	2004994	Lock, Bushing	36	2316859	Bushing, Extension Arm
	2306424	Icemaker and Ingredient Care Center Service Sheet	19	W10484913	Bushing, Top Hinge	37	W10167456	Assembly, RC Wire
	W10469184	Main Control Service Sheet	20	2221242	Spring, Door Closure (Green)	38		Button, Water Filter
	W10555563	Installation Instructions	21	3400230	Screw		2260503B	Black
2		Cabinet (Not Serviced)	22	2005008	Retaining Ring, Adjustable Bushing	39	1118894	Switch, Rocker Arm (Refrigerator)
3	2318189	Tray, Filter Drip	23	2215612	Cover, Air Duct		1115373	Switch, Rocker Arm, Combination (Freezer)
4	W10138054	Assembly, Roller	24		Bracket, Switch	40	8281163	Screw (Stainless)
5		Support, Base Assy		2221097	Right Hand	41	W10005050	Screw
	W10138423	Right Hand	25	2221096	Left Hand	42	W10271541	Connector, Union
	W10279275	Left Hand			Hinge, Bottom	43	2004514	Clip
6		Cap, Water Filter		2006780	Right Hand	44		Bracket, Support
	2260518B	Black	26	2006779	Left Hand		2006616	Left Hand
7	2307640	Mounting Bracket, Grill	27	2302876	Bushing, Adjustable		2006556	Right Hand
8	2320509	Stop, Door	28	8533913	Screw	45	W10141604	Screw
9	W10121140	Housing, Water Filter	29		Skirt-Grille, Bottom	46	2005032	Leveler, Adjustable
10	2307584	Grommet, Crossover Tube		2209025B	Black	48	2314064	Tube, Drain
11	3400525	Screw			Extension Arm			
12	W10121146	Filter, Water		2266882	Right Hand			
13	8281164	Screw (Stainless)		2266881	Left Hand			
14	W10485630	Screw	30		Grille, Bottom			
				2325185B	Black			
			31	W10485630	Screw			
			32	487415	Screw			




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cab Side (Right)
	W10132472	Aluminum
2	W10001250	Screw
3	1163283	Screw
4		Trim, Bottom Cab
	2316687	Aluminum

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	486194	Screw
6		Trim, Top Cab
	2314017	Aluminum
7		Trim, Cab Side (Left)
	W10132541	Aluminum

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10121451	Insert, Blind Threaded
9	2005925	Seal, Side Trim




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not Serviced)	18	2309222	Assembly, Air Diffuser	30		Slide, Crisper
2	2306010	Thermistor	19	W10191429	Socket, Light		2302957	Right Hand
3	2208970	Air Duct	20	2307751	Light Shield		2302956	Left Hand
4	487539	Screw (Stainless)	21	2326255	Bulb, Light	31		Screw
5	2259077	Ladder, Shelf	22	W10468940	Control Box Assembly			Right Hand
6	520965	Support, Ladder	23	2317000	Clip, Control Box		8533929	Screw (Stainless)
7	2006475	Screw (White)	24	8281163	Screw (Stainless)			Left Hand
8	2309087	Cover, Air Diffuser	25	2306086	Assembly, UI	32	W10141518	Screw
9	2302937	Thermistor Assembly	26	W10142283	Screw (White)	33	2003577	Guard, Air Return
10	W10475010	Assembly, Spacer	27		Spacer, Meat Pan	34	W10159487	Diverter, Crisper Cover
11	W10169528	Assembly, Control Baffle		2256244	Right Hand	35	2310205	Assembly, Meat Pan
12	2327509	Reservoir, Water		2256243	Left Hand			Wire
13	2188820	Thermistor	28		Slide, Meat Pan			
	8533929	Screw (Stainless)		2302955	Right Hand			
15	486194	Screw		2302954	Left Hand			
16	2317844	Assembly, Thermistor	29		Spacer, Crisper			
17	2221296	Air Baffle Assembly		2256222	Right Hand			
				2256223	Left Hand			



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan
2	2198665	Tube, Circuit Board
3	2169142	Blade, Fan
4	W10260421	Retainer, Fan Motor
5	2302817	Gasket, Cover
6	W10321090	Grommet, Motor
7	486194	Screw
8	2259464	Wedge, Right Air Duct
9	487539	Screw (Stainless)
10	W10191429	Socket, Light
11	W10290817	P.C. Board Receiver
12	2326255	Bulb, Light
13	489214	Screw
14	2182120	Fan Scroll
15	2259465	Wedge, Left Air Duct
16	W10142283	Screw (White)
17	2307774	Air Duct

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18	2198643	Lens, Receiver
19		Block, Fan Scroll
	2209480	Right Hand
	2209066	Left Hand
20	2215650	Cover, Emitter
21		Liner (Not Serviced)
22	W10160570	Bi-Metal, Defrost
23	2259025	Cover, Air Outlet
24	2307751	Light Shield
25	W10428000	Cover, Evaporator
26	2302850	Support, Air Duct
27	8281251	Screw (White)
28	2198635	Spring, Door
29	2255563	Slide, Icemaker Shut Off
30	1112260	Support, Evaporator
31	W10173127	Assembly, Shelf Stud

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
32	8281163	Screw (Stainless)
33		Rail, Evaporator Cover
	2221107	Left Hand
	2259355	Right Hand
34	W10581988	Gasket, Evaporator Cover
35	2259493	Cover, Receiver
36	W10482187	Harness, Bi-Metal Wire
37	2306010	Thermistor
38	2317844	Assembly, Thermistor
39	2006475	Screw (White)
40	2259032	Ladder, Shelf
41	2259445	Support, Ladder Screw
42	2198634	Pin, Door
43	W10193840	P.C. Board, Emitter
44	2198633	Flipper Shut Off
45	2317105	Cover, Thermistor




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222965	Ice Bin
2	W10134774	Crusher Bin
3	2252265	Button, Bin
4	W10134783	Latch, Bin
5	2198608	Spring, Latch IDI Motor
6	2198671	Screw (Stainless)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	2188919	Clip, Shaft
9	2198628	Seal
10	2318082	Drive Shaft
11	2318011	Enclosure, Motor
12	2315547	Motor, Dispenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	2318028	Cover
15	W10395657	Ice Container Assembly
16	W10254073	Washer



REFRIGERADOR KSSC42QVS06





REFRIGERADOR KSSC42QVS06


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222592	Shelf Assembly
2	W10407624	Crisper Pan
3	2302842	Meat Pan Cover Assembly
4	2302835	Assembly, Crisper Cover

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10407627	Pan Assembly Meat
6	2256248	Front, Crisper Pan

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	2256366	Front, Meat Pan
8	2179404	Rack, Wine



REFRIGERADOR KSSC42QVS06



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM

www.denek.com




REFRIGERADOR KSSC42QVS06

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed
3	2259082	Basket, Freezer
4	2256270	Front, Basket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259317	Right Hand
	2259318	Left Hand
6	8533928	Screw (Stainless)




REFRIGERADOR KSSC42QVS06





REFRIGERADOR KSSC42QVS06


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10600342	Door Assembly, Refrigerator	10		Skin, Door	18	W10482554	Cover, Bottom Gap
2	2006346	Washer, Extension Arm		W10523739	Stainless	19		Utility Bin Endcap
3	W10485980	Assembly, Top Hinge	11		Door Handle		W10323172	Right Hand
4	2316804	Spacer, Door Hinge Bottom	12	2309060	Spacer, Handle Side Door		W10323173	Left Hand
5	W10162602	Screw	13	488568	Screw (Stainless)	20	W10323036	Bin, Utility Center
6	2302878	Hinge Assembly, Bottom	14	8281250	Screw (Stainless)	21	2257616	Door, Utility Bin
7	2222796	Rail, Lid	15	2005433	Spacer, Door Skin Top	22	W10323599	Bin, Door-Shallow
8	2222982	Gasket, Utility Bin	16	W10142296	Spacer, Door	23	W10323747	Shelf, Door (Gallon)
9	2222811	Door Gasket, Magnetic	17	2004934	Spacer, Door Skin Bottom	24	W10127710	Plate, Handle Door
						25	308544	Screw




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10292458	Door Assembly, Freezer
2	W10127710	Plate, Handle Door
3	2302879	Assembly, Bottom Hinge
4	W10162602	Screw
5	W10485980	Assembly, Top Hinge
6	2316804	Spacer, Door Hinge Bottom
7	2222814	Door Gasket, Magnetic
8	2316868	Door Handle Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	2309060	Spacer, Handle Side Door
10	W10523759	Stainless Skin, Door
11	8281250	Screw (Stainless)
12	2005433	Spacer, Door Skin Top
13	488568	Screw (Stainless)
14	2257385	Spacer, Door-Skin (Bottom)
15	W10142296	Spacer, Door
16	308544	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10482554	Cover, Bottom Gap
18	W10323602	Bin, Shallow
20	2006346	Washer, Extension Arm




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	9	2305235	Assembly, Spigot	15	2305219	Cover, Control
2	8281163	Screw (Stainless)	10	2318017	Assembly, Separator	16	2321746	Assembly, UI Control Cover
3	W10542660	Bracket, Motor	11		Housing, Middle (Not Available Order Item 12)	17	W10151236	Assembly, UI
4	W10546285	Assembly, Motor & Bracket	12	W10260622	Assembly, Housing	18		Housing, Tray
5	W10205979	Motor, Ice Door	13		Water, Paddle Assembly		2318062US	Universal Silver
						19	2305342	Assembly, LED
6	W10504458	Door, Ice		2305307GN	Universal Silver			
7	W10542663	Support, Ice Door	14		Ice, Paddle Assembly			
8	4449745	Screw		2305306GN	Universal Silver			



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Top Grille Assembly
	W10321106	Stainless
2	W10624563	Cover, Unit

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	1157158	Screw
4	2256466	Panel, Unit Back
5	W10185625	Unit Cover, Front


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Nameplate
	2317923S	Stainless



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10449006	Inverter Box Assembly
2	489373	Screw
3	W10173296	Compressor
4	W10321056	Housing, Control Board
5	W10587113	Grommet
6	1100826	Grommet
7		Support, Condenser
	W10525179	Right Hand
8	2259350	Board, Power Supply
9	2215676	Cover, Terminal
10		Support, Condenser
	W10525177	Left Hand
11	W10427079	Board, Control
12	2203075	Spacer
13	2256328	Bracket, Inverter Mounting
14	W10356040	Control, Electronic
15	1157158	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10591457	Condenser
17	W10427089	Wire Assembly, Unit
18	2310207	Assembly, Condenser Fan Wire
19	W10483905	Jumper, Inverter
20	2155774	Tie, Wire
21	W10175593	Drier
22	W10414681	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Condenser
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	487294	Screw
27	8533993	Screw
28	2266802	Switch, Power Disconnect
29	W10495645	Ground, Inverter
30	W10624944	Tube, Drier Transition
31	W10528578	Tube, Process
32	486194	Screw
33	W10525175	Top Cover, Condenser

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
34	2310251	Service Cord
35	W10321055	Bracket, Mounting (Power Switch)
36	549193	Clamp, Power Cord
37	W10625011	Tube, Heat Loop Transition
38	2318054	Control, Electronic
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		7.25 oz. (R-134A)



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10160981	Bracket, Air Return Assembly
2	W10388653	Tube, Transition (Drier/Restrictor)
3	486194	Screw
4	W10157752	Bracket, Heater
5	W10306442	Tube, Oil Trap Suction
6	W10281063	Drain Pan Assembly
7	W10309012	Cover, Wiring
8	W10321048	Cover, Wire Box

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10412488	Tube, Discharge
10	W10321050	Shelf, Wiring Cover
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10413009	Grommet Air Return
15	W10139908	Cover, Evap Seal
16	W10432308	Gasket, Evaporator
17	2155774	Tie, Wire

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10169509	Clip, Heat Exchanger
19	2320554	Support, Drain Pan
20	2215648	Dampener
21	304392	Screw
22	W10234131	Tube, Heat Loop Transition



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	304392	Screw
2	2320601	Shield, Water Valve
3	628379	Clip, Thermal Fuse
4	W10296807	Tube, Filter Inlet
5	W10357286	Fitting, Water
6	487294	Screw
7	W10437853	Tube, Filter Outlet
8	W10159842	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2208136	Clip, Water Tube
12	W10141645	Screw
13	W10289690	Cover, Icemaker
14	W10122527	Assembly, Mold and Heater

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15		Motor (Not Serviced, Order Item 26)
16	W10272168	Cup, Water Fill
17	627843	Ejector
18	W10272161	Stripper, Ice
19	2194712	Support, Housing
20	2315522	Retainer, Thermostat
21	W10290336	Thermostat
22	W10001280	Screw
23	W10279391	Wire Assembly, Smart Valve
24	489276	Screw
25	W10504753	Cover, Icemaker
26	W10223929	Assembly, Module
27	489136	Screw
28	W10129069	Clip, Tube

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
29	486194	Screw
30	2252228	Bracket, Icemaker Mounting
31	W10508659	Assembly, Icemaker Wire
32	W10001250	Screw
33	2198641	Bracket, Icemaker Cover
34	487539	Screw (Stainless)
100	W10277448	Complete Icemaker Assembly Following Parts Not Illustrated
	W10355016	SS Cleaner
	W10355049	SS Cleaning Wipes
	W10355010	Kitchen and Appliance Cleaner