



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	W10485630	Screw	33	486194	Screw
	W10303989	Use and Care Guide	15	2257644	Hinge, Top	34	2006617	Bracket, Base Support
	W10703420	Energy Guide	16	W10674648	Bracket, Filter	35	2215938	Cover, Switch
	W10483315	Service and Wiring Sheet	17	W10001250	Screw	36	2316859	Bushing, Extension Arm
	2306424	Icemaker and Ingredient Care Center Service Sheet	18	2004994	Lock, Bushing	37	W10167456	Assembly, Light Switch Wire
	W10469184	Main Control Service Sheet	19	W10484913	Bushing, Top Hinge	38		Button, Water Filter
	W10555563	Installation Instructions	20	2221242	Spring, Door Closure (Green)		2260503B	Black
2		Cabinet (Not Serviced)	21	3400230	Screw	39	1118894	Switch, Rocker Arm
3	2318189	Tray, Filter Drip	22	2005008	Ring, Bushing Retaining		1115373	Switch, Rocker Arm Combination (Freezer)
4	W10138054	Assembly, Roller	23	2215612	Cover, Air Duct	40	8281163	Screw (Stainless)
5		Assembly, Support Base	24		Bracket, Switch	41	W10005050	Screw
	W10138423	Right Hand		2221097	Right Hand	42	W10271541	Connector, Union
	W10279275	Left Hand	25	2221096	Left Hand	43	W10663352	Clip
6		Cap, Water Filter			Hinge, Bottom	44		Bracket, Support
	2260518B	Black		2006780	Right Hand		2006556	Right Hand
7	2307640	Bracket, Grill Mounting	26	2302876	Bushing, Adjustable		2006616	Left Hand
8	2320509	Stop, Door	27	8533913	Screw	45	W10141604	Screw
9	W10121140	Housing, Water Filter	28	W10188549	Skirt, Grille (Bottom)	46	2005032	Leveler, Adjustable
10	2307584	Grommet, Crossover Tube	29		Extension Arm	47		Assembly, Light Switch Cam
11	3400525	Screw		2266882	Right Hand		2307857	Right Hand
12	W10121146	Filter, Water		2266881	Left Hand		W10121046	Left Hand
13	8281164	Screw (Stainless)	30	W10182717	Grille Bottom (Front)	48	2314064	Tube, Drain
			31	W10485630	Screw			
			32	487415	Screw			



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side (Right)	5	2005925	Seal, Side Trim	7		Trim, Cabinet Side (Left)
	W10132472	Aluminum	6		Trim, Top Cabinet		W10132541	Aluminum
2	W10001250	Screw		2314017	Aluminum	8	W10121451	Insert, Blind Threaded
3	486194	Screw						
4		Trim, Bottom Cabinet						
	2316687	Aluminum						




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not Serviced)
2	2306010	Thermistor
3	2208970	Duct, Air
4	487539	Screw (Stainless)
5	2259077	Ladder, Shelf
6	520965	Support, Ladder
7	2006475	Screw (White)
8	2309087	Cover, Air Diffuser
9	2302937	Thermistor
10	W10475010	Assembly, Spacer
11	W10604726	Assembly, Control Baffle
12	W10645131	Reservoir, Water
13	2188820	Thermistor
14	8533929	Screw (Stainless)
15	486194	Screw
16	2317844	Assembly, Thermistor
17	2221296	Assembly, Air Baffle

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18	2309222	Assembly, Air Diffuser
19	W10191429	Socket, Light
20	2307751	Shield, Light
21	2326255	Bulb, Light
22	W10691183	Assembly, Control Box
23	2317000	Clip, Control Box
24	8281163	Screw (Stainless)
25	W10604724	Assembly, User Interface
26	W10142283	Screw (White)
27		Spacer, Meat Pan
	2256244	Right Hand
	2256243	Left Hand
28		Slide, Meat Pan
	W10714541	Right Hand
	2302954	Left Hand


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
29		Spacer, Crisper
	2256222	Right Hand
	2256223	Left Hand
30		Slide, Crisper
	2302957	Right Hand
	W10714543	Left Hand
31		Screw
		Right Hand
	8533929	Screw (Stainless)
		Left Hand
	8533928	Screw (Stainless)
32	W10141518	Screw
33	2003577	Guard, Air Return
34	W10159487	Diverter, Crisper Cover
35	2310205	Assembly, Meat Pan Wire





<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	18	2198643	Lens, Receiver	32	8281163	Screw (Stainless)
2	2198665	Tube, Circuit Board	19		Block, Fan Scroll	33		Rail, Evaporator Cover
3	2169142	Blade, Fan		2209480	Right Hand		2259355	Right Hand
4	W10260421	Retainer, Fan Motor		2209066	Left Hand		2221107	Left Hand
5	2302817	Gasket, Scroll Assembly	20	2215650	Cover, Emitter	34	2220904	Gasket, Evaporator Cover
6	W10321090	Grommet, Motor	21		Liner (Not Serviced)	35	2259493	Cover, Receiver
7	486194	Screw	22	W10160570	Bi-Metal, Defrost	36	W10482187	Harness, Bi-Metal Wire
8	2259464	Wedge, Right Air Duct	23	2259025	Cover, Air Outlet	37	2306010	Thermistor
9	487539	Screw (Stainless)	24	2307751	Shield, Light	38	2317844	Assembly, Thermistor
10	W10191429	Socket, Light	25	W10581992	Assembly, Evaporator Cover	39	2006475	Screw (White)
11	W10290817	Receiver, Circuit Board	26	2302850	Support, Air Duct	40	2259032	Ladder, Shelf
12	2326255	Bulb, Light	27	W10581988	Gasket, Evaporator Cover	41	2259445	Support, Ladder
13	489214	Screw	28	2198635	Spring, Door	42	2198634	Pin, Door
14	2182120	Scroll, Fan	29	2255563	Slide, Icemaker Shut Off	43	W10193840	Board, Emitter Circuit
15	2259465	Wedge, Left Air Duct	30	1112260	Support, Evaporator	44	2198633	Flipper, Shut Off
16	W10142283	Screw (White)	31	W10173127	Assembly, Shelf Stud	45	2317105	Cover, Thermistor
17	2307774	Duct, Air						






<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222965	Bin, Ice
2	W10134774	Bin, Crusher
3	2252265	Button, Bin
4	W10134783	Latch, Bin
5	2198608	Spring, Latch
6	2198671	Screw (Stainless)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	2188919	Clip, Shaft
9	2198628	Seal
10	2318082	Shaft, Drive
11	2318011	Enclosure, Motor

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	2315547	Motor, Dispenser
13	2318028	Cover
14	W10254073	Washer
15	W10395657	Assembly, Ice Container



# REFRIGERADOR KSSC42QVS10






# REFRIGERADOR KSSC42QVS10

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222592	Assembly, Shelf
2	W10407624	Pan, Crisper
3	2302842	Assembly, Meat Pan Cover
4	2302835	Assembly, Crisper Cover

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10407627	Assembly, Meat Pan
6	2256248	Front, Crisper Pan

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	2256366	Front, Meat Pan
8	2179404	Rack, Wine






# REFRIGERADOR KSSC42QVS10


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175905	Shelf, Wire
2	2302883	Shelf, Fixed
3	2259082	Basket, Freezer
4	2256270	Front, Basket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259317	Right Hand
	2259318	Left Hand
6	8533928	Screw (Stainless)






<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10600342	Assembly, Refrigerator Door	11		Handle, Door	19		Endcap, Utility Bin
2	2006346	Washer, Extension Arm		2316868	Stainless		W10323172	Right Hand
3	W10485980	Assembly, Top Hinge	12	2309060	Spacer, Handle Side Door		W10323173	Left Hand
4	2316804	Spacer, Door Hinge Bottom	13	488568	Screw (Stainless)	20	W10323036	Bin, Utility Center
5	W10162602	Screw	14	8281250	Screw (Stainless)	21	2257616	Door, Utility Bin
6	2302878	Assembly, Bottom Hinge	15	2005433	Spacer, Door Skin Top	22	W10323599	Bin, Shallow Door
7	2222796	Rail, Lid	16	W10142296	Spacer, Hinge Side Door	23	W10323747	Bin, Gallon Door
8	2222982	Gasket, Utility Bin	17	2004934	Spacer, Door Skin Bottom	24	W10127710	Plate, Handle Door
9	W10694211	Gasket, Door	18	W10482554	Cover, Bottom Gap	25	308544	Screw
10		Skin, Door						
	W10523739	Stainless						




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Freezer Door (Includes Dispenser Parts)	8		Handle, Door	14	2257385	Spacer, Door Skin Bottom
2	W10127710	Plate, Handle Door	9	2316868	Stainless	15	W10142296	Spacer, Hinge Side Door
3	2302879	Assembly, Bottom Hinge	10	2309060	Spacer, Handle Side Door Skin, Door	16	308544	Screw
4	W10162602	Screw		W10523759	Stainless	17	W10482554	Cover, Bottom Gap
5	W10485980	Assembly, Top Hinge	11	8281250	Screw (Stainless)	18	W10323602	Bin, Shallow
6	2316804	Spacer, Door Hinge Bottom	12	2005433	Spacer, Door Skin Top	19	2006346	Washer, Extension Arm
7	W10694214	Gasket, Door	13	488568	Screw (Stainless)			



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2	8281163	Screw (Stainless)
3	W10542660	Bracket, Motor
4	W10546285	Assembly, Motor and Bracket
5	W10205979	Motor, Ice Door
6	W10504458	Door, Ice
7	W10542663	Support, Ice Door
8	4449745	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	2305235	Assembly, Spigot
10	2318017	Assembly, Separator
11		Housing, Middle (Not Available Order Item 12)
12	W10260622	Assembly, Housing
13		Assembly, Water Paddle
	2305307GN	Universal Silver
14		Assembly, Ice Paddle
	2305306GN	Universal Silver

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	2305219	Cover, Control
16	2321746	Assembly, User Interface Control Cover
17	W10151236	Assembly, User Interface
18		Housing, Tray
	2318062US	Universal Silver
19	2305342	Assembly, LED






# REFRIGERADOR KSSC42QVS10

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille
	W10321106	Stainless
2	W10545068	Cover, Unit

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	1157158	Screw
4	2256466	Panel, Unit Back
5	W10694109	Cover, Unit Front

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Nameplate
	2317923S	Stainless
7	2215910	Grommet, Flexible






<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645666	Assembly, Inverter Box
2	489473	Screw
3	W10653005	Compressor
4	W10321056	Housing, Control Board
5	W10587113	Grommet
6	1100826	Grommet
7		Support, Condenser
	W10525179	Right Hand
8	2259350	Board, Power Supply
9	2215676	Cover, Terminal
10		Support, Condenser
	W10525177	Left Hand
11	W10427079	Board, Control
12	2203075	Spacer
13	2256328	Bracket, Inverter Mounting
14	W10356040	Control, Electronic
15	1157158	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10591457	Condenser
17	W10427091	Assembly, Unit Wire
18	2310207	Assembly, Condenser Fan Wire
19	W10483905	Jumper, Inverter
20	2155774	Tie, Wire
21	W10175593	Drier
22	W10414681	Bracket, Fan Motor
23	2188875	Motor, Condenser
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	487294	Screw
27	W10146359	Screw
28	2266802	Switch, Power Disconnect
29	W10495645	Ground, Inverter
30	W10624944	Tube, Drier Transition
31	W10528578	Tube, Process
32	486194	Screw
33	W10525175	Top Cover, Condenser


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
34	2310251	Cord, Power
35	W10321055	Bracket, Control Assembly
36	549193	Clamp, Power Cord
37	W10648264	Tube, Heat Loop Transition
38	2318054	Control, Electronic
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		6.75 oz. (R-134A)



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10160981	Assembly, Air Return Bracket
2	W10388653	Tube, Transition (Drier/Restrictor)
3	486194	Screw
4	W10157752	Bracket, Heater
5	W10648568	Tube, Oil Trap Suction
6	W10281063	Assembly, Drain Pan
7	W10309012	Cover, Wiring

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10321048	Cover, Wire Box
9	W10499596	Tube, Discharge
10	W10321050	Shelf, Wiring Cover
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10413009	Grommet, Air Return
15	W10139908	Cover, Evaporator Seal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10432308	Gasket, Evaporator
17	2155774	Tie, Wire
18	W10169509	Clip, Heat Exchanger
19	2320554	Support, Drain Pan
20	2215648	Dampener
21	304392	Screw



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	304392	Screw
2	2320601	Shield, Water Valve
3	628379	Clip, Thermal Fuse
4	W10296807	Tube, Filter Inlet
5	W10357286	Fitting, Water
6	487294	Screw
7	W10683737	Tube, Filter Outlet
8	W10159842	Valve, Inlet
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2208136	Clip, Water Tube
12	W10141645	Screw
13	W10289690	Cover, Icemaker
14	W10122550	Assembly, Mold and Heater
15		Motor (Not Serviced, Order Item 26)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10272168	Cup, Water Fill
17	626753	Ejector
18	W10272164	Stripper, Ice
19	2194712	Support, Housing
20	2315522	Retainer, Thermostat
21	W10290336	Thermostat
22	W10001280	Screw
23	W10279391	Assembly, Smart Valve Wire
24	489276	Screw
25	W10504753	Cover, Icemaker
26	W10223929	Assembly, Module and Motor
27	489136	Screw
28	W10129069	Clip, Wire
29	486194	Screw
30	2252228	Bracket, Icemaker Mounting

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
31	W10508659	Assembly, Icemaker Wire
32	W10001250	Screw
33	2198641	Bracket, Icemaker Cover
34	487539	Screw (Stainless)
100	W10277448	Complete Icemaker Assembly Following Parts Not Illustrated
	W10355016	SS Cleaner
	W10355049	SS Cleaning Wipes
	W10355010	Kitchen and Appliance Cleaner