


Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10303989	Use & Care Guide
	W10205644	Energy Guide
	W10159832	Service & Wiring Sheet
	2306424	Icemaker and Ingredient Care Center Service Sheet
	W10300878	Main Control Service Sheet
	W10379133	Installation Instructions
2		Cabinet (Not A Serviceable Part)
3	2260503B	Button, Filter
4	W10138054	Roller, Front & Rear
5		Support, Leveler Assembly
	W10138423	Refrigerator Side
	W10279275	Freezer Side
6	2005032	Leveler, Adjustable Ring,
7	2006841	Retaining Flexible Cap, Water Filter
	2260518B	Black
9	2307640	Mounting Stud, Grille
10	2307584	Grommet, Crossover Tube
11	2005783	Cam, Door Closer
12	W10121140	Housing, Water Filter

Illus. No.	Part No.	DESCRIPTION
13	2318189	Tray, Drip Filter
14	3400525	Screw
15	4396841	Filter, Water
16	489399	Screw
17	3400230	Screw, Door Stop
18	2257644	Hinge (Top)
19	W10348782	Bracket, Mtg (Water Filter)
20	W10001250	Screw
21	2004994	Lock, Adjustable Bushing
22	2300082	Bushing
23	W10001250	Screw
24	2221242	Spring, Door Closure
25	486194	Screw
26	2005008	Retaining Ring, Adjustable Bushing
27	W10129069	Wire Clip
28	2006342	Gap, Cover Assembly (Bottom)
29		Hinge (Bottom)
	2006780	Freezer Side
	2006779	Refrigerator Side
30	2302876	Bushing, Adjustable
31	8533913	Screw 1/4-20 x 5/8
32		Skirt-Grille, Bottom
	2209026B	Black Extension Arm, Door Closer
33		(RH)
	2266882	(LH)

Illus. No.	Part No.	DESCRIPTION
34		Grille Bottom, Front
	2325186B	Black
35	W10004850	Screw
36		Bracket, Support Base (Front)
	2006616	(LH)
	2006556	(RH)
37	1157158	Screw
38	2006617	Bracket, Support Base (Rear)
39	2006346	Washer
40	2316859	Bushing, Extension Arm
41	1163283	Screw
42		Connector, Water Tube
	W10271541	1/4"
43	8281163	Screw
44		Switch, Rocker Arm
	1118894	Refrigerator Door Side
	1115373	Freezer Door Side
45	2215938	Cover, Switch
46	487415	Screw
47		Bracket, Switch
	2221097	(RH)
	2221096	(LH)
48	2215612	Cover, Rear
49	W10167456	Wire Assembly RC/FC Light Switch
50		Cam Assembly
	2307857	(RH)
	2302765	(LH)




REFRIGERADOR KSSC48QVS03



Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
3		Screw
	1163283	Stainless Steel
4	2316688	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314018	Cabinet, Trim Top
7		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
8	W10121451	Screw
9	2005925	Seal-Trim, Side
10	W10001250	Screw

BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM


www.denek.com



Illus. No.	Part No.	DESCRIPTION
	1 W10175906	Wire, Shelf
3	2302884	Shelf, Fixed
4	2259083	Basket
5	2256271	Front, Basket
6		Slide, Basket
	2259317	(RH)
	2259318	(LH)
7	8533928	Screw



REFRIGERADOR KSSC48QVS03



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com




REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2003577	Guard, Air Return
5	2259077	Ladder, Shelf
6	520965	Screw Support, Ladder
7	2006475	Screw
8	487539	Screw
9	2302937	Thermistor
10	2302986	Lid, Meat Pan Baffle
11	W10169528	Baffle Control Assembly
12	2317844	Thermistor Assy
13	2310205	Jumper, Air Baffle
14	8533929	Screw
15	486194	Screw
17	2221296	Air Baffle Assembly
18	2327509	Water Reservoir
19	W10141518	Screw
21	2309222	Diffuser Assembly
22	2317105	Cover, Thermistor
23	2188820	Thermistor
24	W10475010	Spacer, Air-Baffle
25	2309087	Cover, Diffuser
27	2259412	Seal, Air Duct (Round Hole)
28	2259398	Seal, Air Duct (Square Hole)



REFRIGERADOR KSSC48QVS03




Illus. No.	Part No.	DESCRIPTION
1	W10468941	Control Box
2	2317000	Clip, Box
3	2310390	Wire, Jumper
4	2324973	Bracket, Control Box
5	2307596	Shield, Control Box
6	487539	Screw
7	2306086	Display, Ingredient Care Center
8	W10191429	Socket, Light
9	2326255	Light Bulb
10	W10142283	Screw

BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM

www.denek.com




REFRIGERADOR KSSC48QVS03



Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly
	2316738S	Stainless Steel
2	W10188580	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10185625	Cover, Unit Front
6	2317923S	Badge, Kitchen Aid
7	2004333	Nut
8	2215910	Grommet, Flexible



REFRIGERADOR KSSC48QVS03






REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
1	2222593	Shelf Assembly
2	2179404	Rack, Wine
3	2302843	Assembly, Meat Pan Cover
4	2302836	Assembly, Crisper Cover
5	W10407625	Crisper Pan
6		Slide, Meat Pan
	2302954	(LH)
	2302955	(RH)
7	2256249	Front, Crisper Pan
8		Spacer, Crisper
	2256222	(RH)
	2256223	(LH)
9		Slide, Crisper
	2302956	(LH)
	2302957	(RH)
10		Spacer, Meat Pan
	2256243	(LH)
	2256244	(RH)
11		Screw
	8533929	Right Side- (8-18 x 1.375)
	8533928	Left Side- (8-18 x .750)
12	W10407628	Pan Assembly Meat
13	2256367	Front, Meat Pan



REFRIGERADOR KSSC48QVS03




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com

Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor
2	2198665	Tube, P.C. Board
3	2169142	Fan Blade
4	2223733	Retainer, Fan Motor
5	2302817	Gasket, Cover
6 W		Grommet
7	486194	Screw
8	2259464	Wedge, Air Duct
9	W10141604	Screw, Ground
10	W10191429	Socket, Light
11	2221070	Clamp, Nylon
12	2326255	Light Bulb
13	489214	Screw
14	2182120	Scroll, Fan
15	2259465	Wedge, Air Duct
16	2307775	Air Duct
17	2198643	Lens
18		Block, Fan Scroll
	2209482	(RH)
	2209066	(LH)

Illus. No.	Part No.	DESCRIPTION
19	2215650	Cover, Emitter
20		Liner (Not A Serviceable Part)
21	2259025	Cover, Air Outlet
22	2307751	Light Shield
23	W10428001	Cover, Evaporator
24	2302851	Support, Air Duct
25	487539	Screw
26	2198635	Spring
27	W10267707	
28	1112260	Support, Evaporator Shelf, Stud
29	2196205	Shelf, Stud
30	W10191952	Screw
31		Evaporator, Cover Rail
	2221107	(LH)
	2259355	(RH)

Illus. No.	Part No.	DESCRIPTION
32	2220904	Gasket
		Evaporator Cover
33	2259493	Cover, Receiver
34	W10139189	Harness, Evap Fan (Includes Item 45)
35	2306010	Thermistor
36	2317105	Cover, Thermistor
37	2006475	Screw
38	2259032	Ladder, Shelf
39	2259445	Support, Screw
40	2198634	Pin
41	W10193840	P Emitter
42	2198633	Flipper
43	2255563	Slide, Icemaker Shut Off
44	W10290817	P.C. Board, Receiver
45	W10160570	Defrost, Bi-Metal
46	W10142283	Screw
47	2317844	Thermistor Assy






REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
1	2222970	Ice Bin
2	W10395656	Ice Container Assembly
3	2252265	Button, Bin
4	W10134785	Latch, Bin
5	2198608	Spring, Latch
6	2198671	Screw
7	8281163	Screw
8	2188919	Holder
9	2198628	Seal
10	2318082	Drive Shaft
11	2318011	Enclosure, Motor
12	2315547	Dispenser, Motor
13	2318028	Cover
14	2315559	Sleeve. Coupling
15	W10254073	Rubber, Washer



REFRIGERADOR KSSC48QVS03






REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
1	W10193491	Refrigerator Door Panel (Includes Item #9)
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222797	Rail, Lid
8	2222983	Gasket, Utility Bin
9	2222812	Door Gasket, Magnetic
10		Skin, Door
	2307754	Stainless Steel
11		Handle, Door
	2316868	Stainless Steel
12		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
14	488568	Screw
15		Screw, 8-15 x .500
	8281250	Stainless Steel
16	2005433	Spacer, Door-Skin (Top)
17	308544	Screw, Handle
18	W10142296	Spacer, Door-Skin (Hinge Side)
19	2004935	Spacer, Door-Skin (Bottom)
21		End Cap
	W10323172	(RH)
	W10323173	(LH)
22	W10127710	Plate, Door-Handle
25	W10323037	Bin, Utility Center
26	2257617	Door, Utility Bin
27	W10323600	Bin, Door
30	W10323748	Bin, Door



REFRIGERADOR KSSC48QVS03



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM

www.denek.com




REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
1	W10292433	Freezer Door (Includes #6)
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222812	Door Gasket, Magnetic
7		Handle, Door
	2316868	Stainless Steel
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9		Skin, Door
	2307311	Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257386	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	2328903	Top
	2328904	Bottom
17	W10127710	Plate, Door Handle
18	W10323603	Bin, Door



REFRIGERADOR KSSC48QVS03



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
www.denek.com




REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	486194	Screw
3	W10132946	Bracket, Motor
4	2305242	Connector, Door Bracket
5	W10205979	Motor, Ice Door
6	2180353	Door, Ice
7	2318020	Support, Ice Door
8	4449745	Screw
9	2305235	Spigot
10	2318017	Separator Assembly
11		Housing, Middle (Not Available Order Item 12)
12	W10260622	Housing Assembly
13	2305307GN	Water, Paddle Asy
14	2305306GN	Ice, Paddle Asy
15	2305219	Cover, Control
16	2321746	Electronic Control (Includes #15)
17	2318042	User Interface Asy
18	2318062US	Tray, Housing
19	2305342	LED Assembly
20	2305447	Clip, Wiring



REFRIGERADOR KSSC48QVS03





REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box	22	W10414681		41	2259350	Power Supply, Ingredient Care Center
		Mounting	23	2188875	Motor, Fan			
3	W10173296	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)	24	W10139483	Blade, Fan			
			25	W10415670	Orifice, Fan			
4	2318087	Housing, Control Board	27	8533993	Screw			
			28	2317031	Bracket, Vibration (Condenser)			
5	2318054	Control Board	29	2317030	Arm, Vibration (Condenser)			
6	1100826	Grommet, Mounting	30	2307566	Tube, Transition (Condenser/Drier)			
7	W10415668	Support, Conenser	31	2194319	Tube, Process			
8	W10234133	Tube, Transiton (Cond/Ht Loop) (Right)	32	486194	Screw			
9	2215676	Terminal Cover	33	2309000	Cover, Condenser			
10	W10415666	Support, Condenser (Left)	34	2310251	Service Cord			
11	W10789107	Control Board	35	W10185556	Bracket, Mounting (Power Switch)			
12	2203075	Spacer	36	549193	Clamp, Cord			
	2256328	Bracket, Inverter Box	37	2266802	Switch, Power Disconnect			
14	486194	Screw	38	487294	Screw, Ground			
15	1157158	Screw	39	W10178860	Wiring Harness, Unit Compartment			
16	2307998	Condenser	40	2309432	Gasket, Condenser			
18	2310207	Wire, Jumper						
19	489399	Screw						
20	2155774	Wire Tie						

Following Parts Not Illustrated and Optional Parts Not Included

- 978025 Valve, Access (1/4")
- 978026 Valve, Access (5/16")
- 978027 Valve, Access (3/8")
- 978028 Valve, Access (1/2")
- 978029 Valve, Access (5/8")
- 978030 Valve, Access (3/4")
- 876764 Valve, Access (3/16")

REFRIGERANT CHARGE

7.75 oz.
(R-134A)




REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION
2	486194	Screw
3	W10157752	Bracket
4	W10431124	Suction Tube Oil Trap
5	W10388653	Tube, Connect (Drier/Restrictor)
6	W10281063	Drain Pan Assy.
7	W10309012	Cover, Wiring
8	W10321048	Cover, Box
9	W10412485	Tube, Discharge
10	2188820	Thermistor
11	W10427993	Evaporator
12	W10140162	Heater, Defrost
13	1113048	Clamp, Heater
14	W10139908	Seal, Return Air
15	W10432308	Gasket, Evaporator
16	4389107	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
20	W10160981	Bracket Assembly, Air Return
21	W10001250	Screw
22	2215648	Dampener



REFRIGERADOR KSSC48QVS03





REFRIGERADOR KSSC48QVS03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	2320601	Shield, Valve	21		Motor, (Not Serviceable Order Item 32)	33	489136	Screw
3	2310191	Wire Assembly, Icemaker	22	W10272168	Cup-Water Fill	34	W 10141645	Screw
5	628379	Clip, Fuse	23	627843	Ejector	35	486194	Screw
6	W10296807	Tube, Filter Inlet	24	W10272161	Ice Stripper	36	2252228	Bracket, Icemaker Mounting
9	2317912	Tube, Filter Outlet	25	2194712	Support	100	2320636	Complete Icemaker Assembly
10	W10159842	Valve, Solenoid	26	2315522	Retainer Thermostat	Following Parts Not Illustrated (Optional Parts Only)		
12	2221070	Clamp, Tube	27	W10290336	Thermostat (Also Order 542639 Cement Alumilastic)		W10355016	Affresh Stainless Steel Cleaner
13	2320559	Support, Valve	28	8533917	Screw		W10355010	Affresh Kitchen Appliance Cleaner
14	2198641	Bracket, Icemaker Cover	29	W10279391	Wire Assembly		W10355049	Affresh Stainless Steel Wipes
15	2208136	Clamp, Nylon Valve	30	489276	Screw		REFDEODOR	Deodorizer Pack
17	W10357286	Fitting, Water	31	2317041	Cover, Icemaker			
18	W10289690	Cover	32	W10223929	Module Assembly (Includes Items 21 & 33)			
19	W10141604	Screw						
20	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)						