


KitchenAid®


48" BUILT IN REFRIGERATOR

MODELS:

KSSC48QVS06 (Stainless)




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	16	2257644	Hinge, Top	35	1157158	Screw
	W10303989	Use & Care Guide	17	W10348782	Bracket, Filter	36	2006617	Bracket, Base Support
	W10205644	Energy Guide	18	W10001250	Screw	37	2006346	Washer, Extension Arm
	W10483315	Service & Wiring Sheet	19	2004994	Lock, Bushing	38	2316859	Bushing, Extension Arm
	2306424	Icemaker and Ingredient Care Center Service Sheet	20	W10484913	Bushing, Top Hinge	39	1163283	Screw
	W10469184	Main Control Service Sheet	21	2004514	Clip	40	W10271541	Connector, Union
	W10555563	Installation Instructions	22	2221242	Spring, Door Closure (Green)	41	8281163	Screw (Stainless)
2		Cabinet (Not A Serviceable Part)	23	486194	Screw	42	1118894	Switch, Rocker Arm (Refrigerator)
3		Button, Water Filter	24	2005008	Retaining Ring, Adjustable Bushing		1115373	Switch, Rocker Arm, Combination(Freezer)
	2260503B	Black	25	W10129069	Clip, Tube	43	2215938	Cover, Switch
4	W10138054	Assembly, Roller	26	W10482554	Cover, Bottom Gap	44	487415	Screw
5		Support, Leveler Assembly	27		Hinge (Bottom)	45		Bracket, Switch
	W10138423	Right Hand		2006780	Right Hand		2221097	Right Hand
	W10279275	Left Hand		2006779	Left Hand		2221096	Left Hand
6		Cap, Water Filter	28	2302876	Bushing, Adjustable	46	2215612	Cover, Air Duct
	2260518B	Black	29	8533913	Screw	47	2005032	Leveler, Adjustable
7	2307640	Mounting Bracket, Grill	30		Skirt, Grille Bottom	48	2006841	Ring, Retainer
8	2307584	Grommet, Crossover Tube		2209026B	Black	49		Cam Assembly
9	2320509	Stop, Door	31		Extension Arm, Door Closer		2307857	Right Hand
10	W10121140	Housing, Water Filter		2266882	Right Hand	50	W10167456	Assembly, RC Wire
11	2318189	Tray, Filter Drip		2266881	Left Hand			
12	3400525	Screw	32		Grille Bottom, Front			
13	W10121146	Filter, Water		2325186B	Black			
14	489399	Screw	33	W10485630	Screw			
15	3400230	Screw	34		Bracket, Support Base (Front)			
				2006616	Left Hand			
				2006556	Right Hand			




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cab Side (Right)
	W10132472	Aluminum
2	1163283	Screw
3		Trim, Bottom Cab
	2316688	Aluminum

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4	486194	Screw
5		Trim, Top Cab
	2314018	Aluminum
6		Trim, Cab Side (Left)
	W10132541	Aluminum

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10121451	Insert, Blind Threaded
8	2005925	Seal, Side Trim
9	W10001250	Screw




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	11	2317844	Assembly, Thermistor	20	2188820	Thermistor
2	2306010	Thermistor	12	2310205	Assembly, Meat Pan Wire	21	W10475010	Assembly, Spacer
3	2208970	Air Duct	13	8533929	Screw (Stainless)	22	2309087	Cover, Air Diffuser
4	2259077	Ladder, Shelf	14	486194	Screw	24	2259398	Seal, Air Duct
5	520965	Support, Ladder	15	2221296	Air Baffle Assembly	25	2003577	Guard, Air Return
6	2006475	Screw (White)	16	2327509	Reservoir, Water	26	W10159488	Diverter, Crisper Cover
7	487539	Screw (Stainless)	17	W10141518	Screw			
8	2302937	Thermistor Assembly	18	2309222	Assembly, Air Diffuser			
9	2302986	Lid, Baffle	19	2317105	Cover, Thermistor			
10	W10169528	Assembly, Control Baffle						



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan
2	2198665	Tube, Circuit Board
3	2169142	Blade, Fan
4	W10260421	Retainer, Fan Motor
5	2302817	Gasket, Cover
6	W10321090	Grommet, Motor
7	486194	Screw
8	2259464	Wedge, Right Air Duct
9	2317844	Assembly, Thermistor
10	W10191429	Socket, Light
11	2221070	Clamp, Tube
12	2326255	Bulb, Light
13	489214	Screw
14	2182120	Fan Scroll
15	2259465	Wedge, Left Air Duct
16	2307775	Air Duct
17	2198643	Lens, Receiver
18		Block, Fan Scroll
	2209482	Right Hand
	2209066	Left Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	2215650	Cover, Emitter
20		Liner (Not A Serviceable Part)
21	2259025	Cover, Air Outlet
22	2307751	Light Shield
23	W10428001	Cover, Evaporator
24	2302851	Support, Air Duct Duct
25	487539	Screw (Stainless)
26	2198635	Spring, Door
27	2309284	Deflector, Air Duct
28	1112260	Support, Evaporator
29	2196205	Stud, Shelf
30	W10191952	Screw
31		Evaporator, Cover Rail
	2221107	Left Hand
	2259355	Right Hand
32	2220904	Gasket, Evaporator Cover
33	2259493	Cover, Receiver
34	W10482187	Harness, Bi-Metal Wire


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
35	2306010	Thermistor
36	2317105	Cover, Thermistor
37	2006475	Screw (White)
38	2259032	Ladder, Shelf
39	2259445	Support, Ladder Screw
40	2198634	Pin, Door
41	W10193840	P.C. Board, Emitter
42	2198633	Flipper Shut Off
43	2255563	Slide, Icemaker Shut Off
44	W10290817	P.C. Board Receiver
45	W10160570	Bi-Metal, Defrost
46	W10142283	Screw (White)



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222970	Ice Bin
2	W10395656	Ice Container Assembly
3	2252265	Button, Bin
4	W10134785	Latch, Bin
5	2198608	Spring, Latch IDI Motor
6	2198671	Screw (Stainless)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	2188919	Clip, Shaft
9	2198628	Seal
10	2318030	Drive Shaft
11	2318011	Enclosure, Motor
12	2315547	Motor, Dispenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	2318028	Cover
14	2315559	Bearing Sleeve
15	W10254073	Washer






REFRIGERADOR KSSC48QVS06

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10468941	Control Box
2	2317000	Clip, Control Box
3	2310390	Wire, Jumper
4	2324973	Bracket, Control Box

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	2307596	Shield, Control Box
6	487539	Screw (Stainless)
7	2306086	Assembly, UI


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10191429	Socket, Light
9	2326255	Bulb, Light
10	W10142283	Screw (White)



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222593	Shelf Assembly, Fixed
2	2179404	Rack, Wine
3	2302843	Meat Pan Cover Assembly
4	2302836	Assembly, Crisper Cover
5	W10407625	Crisper Pan
6		Slide, Meat Pan
	2302954	Left Hand
	2302955	Right Hand
7	2256249	Front, Crisper Pan

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Spacer, Crisper
	2256222	Right Hand
	2256223	Left Hand
9		Slide, Crisper
	2302956	Left Hand
	2302957	Right Hand
10		Spacer, Meat Pan
	2256243	Left Hand
	2256244	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	8533929	Screw (Stainless)
		Right Hand
	8533928	Screw (Stainless)
		Left Hand
12	W10407628	Pan Assembly Meat
13	2256367	Assembly, Meat Pan Front






REFRIGERADOR KSSC48QVS06

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175906	Wire, Shelf
2	2302884	Shelf, Fixed
3	2259083	Basket, Freezer
4	2256271	Assembly, Basket Front


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259317	Right Hand
	2259318	Left Hand
6	8533928	Screw (Stainless)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10193491	Refrigerator Door Assembly
2	W10127710	Plate, Handle Door
3	W10485980	Assembly, Top Hinge
4	2316804	Spacer, Door Hinge Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2257617	Door, Utility Bin
8	2222983	Gasket, Utility Bin
9	2222812	Door Gasket, Magnetic

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10		Skin, Door
	W10523740	Stainless Door, Handle
11		2316868 Stainless
12	2309060	Spacer, Handle Side Door
13	488568	Screw (Stainless)
14	8281250	Screw (Stainless)
15	2005433	Spacer, Door Skin Top
16	308544	Screw
17	W10142296	Spacer, Door


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18	2004935	Spacer, Door (Bottom)
20		End Cap
	W10323172	Right Hand
	W10323173	Left Hand
21	W10323037	Bin, Utility Center
22	2257617	Door, Utility Bin
23	W10323600	Bin, Door-Shallow
24	W10323748	Shelf, Door (Gallon)



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10292433	Freezer Door Panel
2	2302879	Assembly, Bottom Hinge
3	W10162602	Screw
4	W10485980	Assembly, Top Hinge
5	2316804	Spacer, Door Hinge Bottom
6	2222810	Gasket, Door
7		Door, Handle
	2316868	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	2309060	Spacer, Handle Side Door
9	W10523761	Skin, Door
10	8281250	Screw (Stainless)
11	2005433	Spacer, Door Skin Top
12	488568	Screw (Stainless)
14	W10142296	Spacer, Door
15	308544	Screw


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16		Filler, Door
	2328903	Top
	2328904	Bottom
17	W10127710	Plate, Handle Door
18	W10323603	Bin, Shallow



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2	486194	Screw
3	W10542660	Bracket, Motor
4	W10546285	Assembly, Motor & Bracket
5	W10205979	Motor, Ice Door
6	W10504458	Door, Ice
7	W10542663	Support, Ice Door
8	4449745	Screw
9	2305235	Assembly, Spigot

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	2318017	Assembly, Separator
11		Housing, Middle (Not Available Order Item 12)
12	W10260622	Assembly, Housing
13		Water, Paddle Assembly
	2305307GN	Universal Silver
14		Ice, Paddle Assembly
	2305306GN	Universal Silver
15	2305219	Cover, Control


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	2321746	Assembly, UI Control Cover
17	W10151236	Assembly, UI
18		Tray, Housing
	2318062US	Universal Silver
19	2305342	Assembly, LED
20	2305447	Clip, Wiring




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10321107	Top Grille Assembly
2	W10624563	Cover, Unit
3	486194	Screw
4	2256466	Panel, Unit Back

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10185625	Unit Cover, Front
6		Nameplate
	2317923S	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	2004333	Nut
8	2215910	Grommet, Flexible




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10449006	Inverter Box Assembly	18	2310207	Assembly, Condenser Fan Wire	36	2266802	Switch, Power Disconnect
2	489373	Screw	19	W10483905	Jumper, Inverter	37	487294	Screw
3	W10173296	Compressor	20	2155774	Tie, Wire	38	W10427091	Assembly, Unit Wire
4	W10321056	Housing, Control Board	21	W10175593	Drier	39	W10587113	Grommet
5	2318054	Control, Electronic	22	W10414681	Bracket, Fan Motor (Condenser Fan)			Following Parts Not Illustrated
6	1100826	Grommet	23	2188875	Motor, Condenser		978025	Valve, Access
7		Support, Condenser	24	W10139483	Blade, Fan		978026	Valve, Access
	W10525179	Right Hand	25	W10415670	Orifice, Fan		978027	Valve, Access
	W10525177	Left Hand	26	8533993	Screw		978028	Valve, Access
8	W10625011	Tube, Heat Loop Transition	27	W10495645	Ground, Inverter		978029	Valve, Access
9	2215676	Cover, Terminal	28	2259350	Board, Power Supply		978030	Valve, Access
11	W10427079	Board, Control	29	W10624944	Tube, Drier Transition		876764	Valve, Access
12	2203075	Spacer	30	W10528578	Tube, Process			REFRIGERANT CHARGE
13	2256328	Bracket, Inverter Mounting	31	486194	Screw			7.25 oz. (R-134A)
14	487539	Screw (Stainless)	32	W10525175	Top Cover, Condenser			
15	1157158	Screw	33	2310251	Service Cord			
16	W10591457	Condenser	34	W10321055	Bracket, Mounting (Power Switch)			
17	W10356040	Control, Electronic	35	549193	Clamp, Power Cord			



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10139908	Cover, Evaporator Seal
2	486194	Screw
3	W10157752	Bracket, Heater
4	W10306442	Tube, Oil Trap Suction
5	W10388653	Tube, Transition (Drier/Restrictor)
6	W10281063	Drain Pan Assembly
7	W10309012	Cover, Wiring

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10321048	Cover, Wire Box
9	W10412485	Tube, Discharge
10	2188820	Thermistor
11	W10427993	Evaporator
12	W10140162	Heater, Defrost
13	1113048	Clamp, Heater
14	W10321050	Shelf, Wiring Cover
15	W10432308	Gasket, Evaporator

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	4389107	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
20	2215648	Dampener
21	W10160981	Bracket, Air Return Assembly



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	2320601	Shield, Water Valve
2	W10508659	Assembly, Icemaker
3	628379	Wire Clip, Thermal Fuse
4	W10296807	Tube, Filter Inlet
7	W10437853	Tube, Filter Outlet
8	W10159842	Valve, Solenoid
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2198641	Bracket, Icemaker Cover
12	2208136	Clip, Water Tube
13	W10357286	Fitting, Water
14	W10289690	Cover, Icemaker

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10141604	Screw
16	W10122527	Assembly, Mold and Heater
17		Motor, (Not Serviceable Order Item 28)
18	W10272168	Cup, Water Fill
19	627843	Ejector
20	W10272161	Stripper, Ice
21	2194712	Support, Housing
22	2315522	Retainer, Thermostat
23	W10290336	Thermostat
24	W10001280	Screw
25	W10279391	Wire Assembly, Smart Valve
26	489276	Screw
27	W10504754	Cover, Icemaker

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
28	W10223929	Assembly, Module
30	W10001250	Screw
31	486194	Screw
32	2252228	Bracket, Icemaker Mounting
100	W10277448	Complete Icemaker Assembly Following Parts Not Illustrated
	W10355016	SS Cleaner
	W10355010	Kitchen and Appliance Cleaner
	W10355049	SS Cleaning Wipes
	REFDEODOR	Deodorizer Pack