


Lavadora Maytag LA612

ALL MODELS **BASE, PUMP, MOTOR & COMPONENTS**





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	Y015408	SCREW, BEARING INSERT
2	Y015627	SCREW, HEX HD CAP 5/16 X 5/8
3	Y015629	BOLT, GRINDING CHAMBER-DRAI
4	Y052734	NUT
5	Y052740	NUT
6	Y052785	NUT,BRACE TO DAMPER
7	Y053241	SET SCREW, PULLEY
8	Y054866	LOCK WASHER
9	Y054867	WASHER, LOCK
10	285655	HOSE CLAMP - 1-5/8 INCH
11	200730	AGITATOR SHAFT
12	W10175939	BOLT & GASKET ASSY.(SHORT)
13	200813	GEAR CASE COVER ASSEMBLY
14	200816	PULLEY, MOTOR (W/SET SCREW)
15	12002353	MOTOR - TWO SPEED 120-60
16	202203	PUMP AS PAK
17	WP3367052	CLAMP, HOSE
18	202718	TENSION SPRINGS
19	203193	GEAR HOUSING W/STUDS & TUBE
20	203274	BASE WITH DAMPER PADS
21	203438	TRANS & CENTER ASSM. LG TUB
22	203725	DAMPER W/BOLT & CLIP
23	203956	DAMPER PAD KIT (W/POLY LUBE)
24	204807	GRND.WIRE,SUPP.PLTE TO TOP CVR
25	205000	GLIDE KIT (4 W/POLY LUBE)
27	205131	SWITCH, MOTOR START
28	205132	SWITCH, MOTOR START
29	205133	MOTOR EXTERNAL START SWITCH



Lavadora Maytag LA612

Guía	N.P.	Descripción
30	205134	MOTOR EXTERNAL START SWITCH
31	W10175938	BOLT & GASKET ASSEMBLY (LONG)
32	205811	COUNTERWEIGHT
33	205908	LOWER MOTOR MOUNT
34	205999	MOTOR MOUNT ASSM COMPLETE
35	206504	MOTOR EXTERNAL START SWITCH
36	206505	SWITCH, MOTOR START
37	210172	LOCK WASHER
38	WP489128	SCREW, GROUND WIRE TO BASE--NA
39	210385	NUT, LOCK
40	210684	FOOT, RUBBER
41	211028	DEFLECTOR,WATER (DRIVE TUBE)
42	211100	WASHER, CUSHION
43	211880	SCREW, HEX HD No.10 X 1/2 INC
44	211949	NUT, EYEBOLT
45	212979	WASHER, TUB BRACE
46	213044	CENTER SHAFT
47	213045	DRAIN HOSE-TUB TO PUMP
48	213053	BRACE, TUB
49	213054	CENTERING SPRING - 3 USED
50	213073	WASHER, DOUBLE
51	W11129403	EYE BOLT FOR CENTER SPRING

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas


Lavadora Maytag LA612

ALL MODELS

CABINET, WATER VALVE, HOSES & FRONT PANEL

ACCESSORY HOSES

- 2-582B 4 ft. Straight Ends
- 2-672 5 ft. 90° Elbow
- 2-688 6 ft. 90° Elbow
- 2-681 10 ft. 90° Elbow
- 2-2861 Box of (25) 5 ft. straight end hoses,
(25) gaskets, (25) screens





Lavadora Maytag LA612


Guía	N.P.	Descripción
1	Y013783	GASKET, INLET HOSE
2	Y014874	SCREW
3	285655	HOSE CLAMP - 1-5/8 INCH
4	200672	INLET HOSE ASSY.
5	350021	INLET HOSE, HOT 10 FT.
6	200688	INLET HOSE, HOT 6 FT.
7	Y200832	CAPACITOR
8	12001413	SCREEN WASHER, INLET HOSE
9	201575	HOSE CLAMP
10	202860	INLET HOSE ASSY.
11	89503	CARTON OF 25 HOSE, 5`
12	203237	No.17 WIRE WITH TERMINAL
14	203319L	(ALMOND)
15	204439	SCREW & FSTNER ASSY(FRT.PANEL)
16	205613	WATER VALVE
17	89503	HOSE, INLET ASSY.
18	206103	CAPACITOR KIT
19	206638	SIPHON BREAK(W/CLAMP)
20	211149	CLIP, CAPACITOR
21	211294	SCREW
22	211878	PLATE, ACCESS
23	212276	SCREW
24	22001650	FASTENER, PANEL
26	212998L	FRONT PANEL-ALMOND
27	213007	SCREW, CABINET
28	W10346892	SCREW
29	27001200	SCREW,CBNT.TO FRNT OF BASE--NA
30	213846	GUARD, BELT



Lavadora Maytag LA612

Guía	N.P.	Descripción
31	214337	SCREEN, VALVE
32	22002331	SPACER, FRONT PANEL
33	208847	SIPHON BREAK ELBOW
34	214765	GASKET, SIPHON BREAK
35	22001448	HOSE,PUMP TO SIPHON BREAK
36	214812	BRACKET,WATER VALVE
37	215058	PAD, CABINET BUMPER
38	22003410	HOSE, DRAIN
39	Y313561	SCREW----NA

ALL MODELS **CLUTCH, BRAKE & BELTS**






Lavadora Maytag LA612


Guía	N.P.	Descripción
1	Y038315	TOOL, BRAKE PKG ASSY
2	Y053241	SET SCREW, PULLEY
3	22003441	BALL BEARING, RADIAL
4	200816	PULLEY, MOTOR (W/SET SCREW)
5	200835	BEARING, BRAKE ROTOR
6	6-2011900	ROTOR, BRAKE (W/FACING)
7	201190	BRAKE ASSEMBLY
8	211000	SCREW,HEX HEAD (BRAKE DRUM)
9	211038	CAP, OIL RETAINER
10	6-2011900	RETAINER, BRAKE SPRING
11	6-2011900	SPRING, BRAKE
12	6-2011900	GASKET, BRAKE DRUM
13	6-2011900	DRUM, BRAKE
14	6-2011900	HOUSING, BRAKE
15	WP6-2301530	PULLEY, DRIVE
16	211089	LUG, STOP
17	2203555	WASHER, LOCK
18	12112425	V BELT, PUMP
19	12112425	V BELT,DRIVE PULLEY
20	912618	SCREW,STOP LUG(CENTER SHAFT)
21	213325	CLIP, RETAINER
22	3934714	SCREW, RETAINING CLIP

Lavadora Maytag LA612


MODEL A612-A612S CONTROL PANEL



A612



A612S





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	205033	TIMER MOTOR 120-60
2	206216	WATER TEMPERATURE SWITCH
3	206217	SPEED CONTROL SWITCH
4	22206223	INFINITE WATER LEVEL SWITCH
5	206225	TIMER
8	206567	CONTROL PANEL
10	210932	SCREW, No.8 X 9/16 CTSK
11	211065	SPRING, TIMER KNOB
12	WPW10139210	SCREW, No.8 X 5/16 INCH
13	211605	RETAINER, TIMER KNOB
14	67006908	SCREW-TEMP. SWITCH TO PANEL
15	3400014	SCREW-TIMER TO CONTROL PANE
16	214809	BACK UP PLATE
17	214815	END CAP F/CONTROL PANEL-LH
18	214816	END CAP F/CONTROL PANEL-RH
19	214872	PALNUT, END CAP
20	214894	FASTENER, END CAP
21	214897	PAD, CONTROL PANEL
22	22001571	TIMER DIAL INDICATOR
23	215162	TIMER KNOB
24	215164	CAP FOR KNOB

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Maytag LA612

ALL MODELS

ORBITAL TRANSMISSION


SERIES 10

A382	A590
A390	A612
A412	A612S
A482	A613
A484	A712
A490	A882
A506	A883
A512	A884
A512S	

A104	A212
A105	A212S
A112	A282
A183	A283
A190	A284
A211	A312

2-6708
Transmission Complete
Regular Tub

2-6707
Transmission Complete
Large Tub





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	W10841140	SILASTIC,ADH.SEALANT
2	206478	SCREW & WASHER FOR AGITATOR
4	206624	HOUSING, TRANSMISSION
5	W10841093	HOUSING, TRANSMISSION
6	206628	COVER, TRANSMISSION
7	Y206629	PIN, COLLAR
9	6-2097750	TRANSMISSION, ORBITAL
10	W10841093	TRANSMISSION
11	6-2097820	ASSEMBLY, AGITATOR SHAFT
12	206713	GEAR, BEVEL
13	206822	DISPENSER, LINT FILTER
14	207427	LINT FILTER - DISPENSER
15	207538	AGITATOR W/LOCK SCREW/O-RIN
16	207228	AGITATOR W/LOCK SCREW/O`RIN
17	210690	SEAL, RUBBER
18	WP6-2301530	PULLEY, DRIVE
19	211089	LUG, STOP
20	22003555	WASHER, LOCK
21	912618	SCREW,STOP LUG(CENTER SHAFT)
22	WP6-2114830	WASHER, SPLINED
23	215394	WASHER, BEVEL GEAR
24	215395	PLATE, CLUTCH
25	W10221114	PINION
26	215410	CENTER SHAFT - LARGER




Lavadora Maytag LA612

Guía	N.P.	Descripción
27	215411	SHAFT, CENTER
28	215415	COLLAR, LOWER
29	215417	SCREW, TRANSMISSION COVER
30	215533	DISPENSER CUP
31	215581	SPRING, AGITATOR SHAFT

MODELS A212S-A312S-A512S-A612S

SUDS SAVER COMPONENTS





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	52366	COTTER KEY, 1/8 X 7/8
2	52690	HEX. NUT, No.10-32
3	67006380	SCREW
4	285655	HOSE CLAMP - 1-5/8 INCH
5	200736	SUDS RETURN HOSE
6	200806	SOLENOID
7	200828	VALVE ARM ASSEMBLY
8	285655	HOSE CLAMP - 1-1/2 INCH
9	201112	SIPHON BREAK KIT
10	201168	DIVERTER VALVE
11	202504	DIVERTER VALUE COVER/FLAPPER
12	3367052	CLAMP, HOSE
13	204313	BODY FOR DIVERTER VALVE
14	204316	DIAPHRAGM AND ARM
15	211083	FLAPPER
16	211085	RETURN SPRING
17	211087	SOLENOID LINK
18	211111	HOSE COUPLING
19	211170	SUDS HOSE, UPPER
20	211171	SUDS RETURN HOSE-LOWER
21	211388	SHIELD
22	211448	CLAMP
23	211516	VALVE BRACKET
24	211518	HOSE
25	211704	DRAIN HOSE
26	212056	STRAINER




Lavadora Maytag LA612

Guía	N.P.	Descripción
27	213855	PIN, PIVOT
28	213856	RETAINER
29	214332	SCREW
30	8182296	SCREW
31	910091	SLOTTED HEX HEAD SCREW
32	911266	SCREW, STRAINER TO PUMP

Lavadora Maytag LA612

ALL MODELS TOP COVER, CONSOLE & LID SWITCH

PRIOR TO
 SERIES 11





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	Y201808	CONVERTER
2	204445	SCREW & FASTENER ASY.
3	204968	PLUNGER & BRACKET ASSEMBLY
4	WP204590	CORD, POWER
5	205415	SWITCH, LID (W/O TUB LIGHT)
7	205537L	TOP COVER-ALMOND----NA
11	205635L	CONSOLE (ALM)
13	205997	NON-BLEACH CONVERSION KIT
16	206231	WIRE HARNESS
19	489128	SCREW, GROUND WIRE TO BASE--NA
20	211294	SCREW
21	211500	WASHER, BRACKET TO TOP COVER
22	211726	HINGE, BALL
23	248562	WIRE CONNECTOR
24	211881	GROMMET, CORD
26	212073L	LID-ALMOND
27	212716	BUMPER, LID
28	213501	SCREW, No.6-20 X 1-1/8 INCH
29	213718	LID SWITCH PLUNGER
30	213720	SPRING
31	214436	GASKET
32	214805	PIN FOR UNBALANCE LEVER
33	214813	LEVER FOR LID SWITCH
34	214898	COVER FOR LID SWITCH
35	214987	MOISTURE BARRIER FOR SWITCH




Lavadora Maytag LA612

Guía	N.P.	Descripción
36	215075	FASTENER,CNTRL PNL TO CONSOLE
37	215236	UNBALANCE LEVER
39	215578	BLEACH INLET ALMOND
41	215580	CUP, BLEACH (ALM.)
42	301548	CLAMP, GROUND (W/SCREW)
43	311155	GROUND WIRE
44	Y312140	WIRE CONNECTOR
45	Y313559	SCREW
46	410635	FASTENER
47	W10756178	SCREW
48	911267	SCREW, PUMP COVER

Lavadora Maytag LA612

ALL MODELS TOP COVER, CONSOLE & LID SWITCH

SERIES 11





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	Y201808	CONVERTER
2	204445	SCREW & FASTENER ASY.
3	204968	PLUNGER & BRACKET ASSEMBLY
4	204590	CORD, POWER
5	205415	SWITCH, LID (W/O TUB LIGHT)
7	205635L	CONSOLE (ALM)
9	205997	NON-BLEACH CONVERSION KIT
10	206231	WIRE HARNESS
11	WP489355	SCREW
13	207170L	TOP COVER ASSY ALM----NA
16	207172L	TOP COVER ASSY ALM----NA
17	WP489128	SCREW, GROUND WIRE TO BASE--NA
18	211294	SCREW
19	211500	WASHER, BRACKE TO TOP COVER
20	211726	HINGE, BALL
23	248562	WIRE CONNECTOR
24	211881	GROMMET, CORD
26	212073L	LID-ALMOND
27	212716	BUMPER, LID
28	213501	SCREW, No.6-20 X 1-1/8 INCH
29	213718	LID SWITCH PLUNGER
30	213720	SPRING
31	204968	BRACKET F/LID SWITCH PLUNGE
32	214436	GASKET
33	214805	PIN FOR UNBALANCE LEVER
34	214813	LEVER FOR LID SWITCH
35	214898	COVER FOR LID SWITCH



Lavadora Maytag LA612

Guía	N.P.	Descripción
36	214987	MOISTURE BARRIER FOR SWITCH
37	215075	FASTENER,CNTRL PNL TO CONSOLE
38	215236	UNBALANCE LEVER
40	215578	BLEACH INLET ALMOND
42	215580	CUP, BLEACH (ALM.)
43	22001678	BRACKET,SWITCH & FUSE
44	215700	LID SWITCH PLUNGER
45	215704	UNBALANCE LEVER
46	301548	CLAMP, GROUND (W/SCREW)
47	311155	GROUND WIRE
48	Y312140	WIRE CONNECTOR
48	Y313559	SCREW
49	410635	FASTENER
50	W10786178	SCREW
51	911267	SCREW, PUMP COVER

Distribuidor Autorizado

SurteRápido.com


Venta de Refacciones Electrodomesticas

Lavadora Maytag LA612

ALL MODELS

TRANSMISSION

PRIOR TO SERIES 10





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	Y014827	WASHER-CENTER SHAFT
2	Y014839	COLLAR-DRIVE SHAFT
3	Y015629	BOLT, GRINDING CHAMBER-DRAI
4	15639	DOWEL PIN
5	Y015902	SPRING FOR AGITATOR
6	Y052740	NUT
7	Y056080	TRANS LUBE - AUTO, 34 OZ.
8	200730	AGITATOR SHAFT
9	200813	GEAR CASE COVER ASSEMBLY
10	201463	PITMAN WITH WRIST PIN
12	203193	GEAR HOUSING W/STUDS & TUBE
14	203438	TRANS & CENTER ASSM. LG TUB
15	204967	GEAR KIT-POWER FIN AGITATOR
16	205811	COUNTERWEIGHT
17	2078423	SEAL, LIP (CENTER SHAFT)
18	210054	PINION
19	210172	LOCK WASHER
20	210183	GROOV-PIN, 1/4 X 1-1/4
21	210286	SEAL
22	210315	PINION
23	22210632	GASKET
24	210670	SEGMENT
25	210690	SEAL, RUBBER
26	211089	LUG, STOP
27	WP22003555	WASHER, LOCK




Lavadora Maytag LA612

Guía	N.P.	Descripción
28	WP912618	SCREW,STOP LUG(CENTER SHAFT)
29	WP6-2114830	WASHER, SPLINED
30	211484	LUG WASHER
31	211486	SCREW, 3/8-16 X 1/2 INCH
32	211487	GROOV-PIN
34	213044	CENTER SHAFT

ALL MODELS

TUB AGITATOR, MOUNTING STEM & SEAL

SERIES 04





Lavadora Maytag LA612

Guía	N.P.	Descripción
1	A04298	SEAL, AGITATOR DRIVE SHAFT
2	Y015666	WASHER,RETAINING(CENTER SEAL)-
3	Y015667	RETAINING RING
4	Y054867	WASHER, LOCK
5	W10175939	BOLT & GASKET ASSY.(SHORT)
6	6-2040130	BEARING, TUB
7	200846	CLAMP - TUB COVER
8	WPW10548433	CLAMP, SPRAY ARM HOSE
10	6-2095720	SEAL AND SPRING
11	WP596669	HOSE CLAMP
12	WP596669	HOSE CLAMP - 1-1/16 INCH
14	6-2095720	MOUNTING STEM
15	203156	INNER TUB
16	203265	LINT FILTER-DISPENSER
18	203323	AGITATOR - TURQUOISE
19	6-2095720	MOUNTING STEM REPAIR KIT
20	204013	TUB BEARING REPAIR KIT
22	WP489503	CLAMP - 15/16``
23	W10175938	BOLT & GASKET ASSEMBLY (LONG)
24	205484	OUTER TUB
26	205529	NUT & BOLT KIT FOR TUB CLAM
27	205613	WATER VALVE
28	206381	TUB COVER
29	206478	SCREW & WASHER FOR AGITATOR
30	WP206680	INJECTOR HOSE KIT
31	WP6-2110472	NUT, CLAMPING (INNER TUB)
32	211100	WASHER, CUSHION
33	211130	LINER, TUB BEARING



Lavadora Maytag LA612

Guía	N.P.	Descripción
34	211210	WASHER, CLAMPING NUT (STAINLESS)
35	211232	SEAL
36	22001423	SET SCREW, MTG. STEM
37	WP285655	CLAMP, 1-1/16"
38	212815	DISPENSER CUP
39	WP22001619	AIR DOME AND TUBE
41	WP213013	HOSE, INJECTOR
42	WP213015	INJECTOR NOZZLE
43	WP216201	VALVE FOR INJECTOR SUB
44	WP213045	DRAIN HOSE-TUB TO PUMP
45	WP214433	TUBE, INLET TO TUB
45	214434	SPOUT, DEFLECTOR
46	WP214725	CAP FOR SPOUT-OUTER TUB
47	WP596669	SPRING HOSE CLAMP
48	WP285655	SPRING CLAMP FOR HOSE
49	215232	UNBALANCE BUMPER
50	WP215233	SEAL FOR INJECTOR TUBE
51	Y215234	INJECTOR FILL HOSE
52	WP215235	INJECTOR TUBE
53	WP215447	SLEEVE FOR INJECTOR
54	WP1163839	SCREW
55	312620	SEMS SCREW, No.10-16 X 1/2"