



Guía	Descripción	# de parte
1	LINT CHUTE ASSEMBLY	686215
2	Washer-Support	WP3388703
3	NUT	98460
5	Screw, 8/18 x 3/8	WP90767
6	Cycling Thermostat - Limit 135/155	WP694674
7	Thermal Cut-Off Kit	279769
8	Dryer Thermal Fuse	WP3392519
10	Dryer Blower wheel	WP694089
11	Housing, Blower	WP8577230
12	CLIP	279771
14	BOX	695547
15	High Limit Thermostat	WP3390291
16	Thermostat Heater	61894
17	Heating Element	WP4391960
17A	Heating Element	WP4391960
18	Heating Element Connection Wire Kit	279457
19	Blower Motor Shaft Seal	WP3394196
21	Screw	WP488729
23	HOSE, DIFFERENTIAL	686577
41	Roller Support Tri-Ring	WPW10512946
42	Drum Roller Shaft - Left Side	WPW10359270
43	Drum Support Roller Shaft - Right Side	WPW10359269
44	Rear Drum Support Roller Kit	349241T
45	USE WPL 686769	686770
46	Roller Shaft Washer	WP348197
47	Nut	WP358160
48	BULKHEAD	279793
62	Drum Front Bearing Ring	WP3394509
63	SCREW, BAFFLE MOUNTING (6)	690372
66	Rear Drum Seal with Adhesive	239087
67	DRUM	697760
68	Dryer Drum Baffle	WP342847
69	BRACKET	3976435
70	Support Roller Clip	WP90296
73	Lint Trap Housing Seal	WP339956
74	Screw	WP681414
75	SHIELD	W11233063



Guía	Descripción	# de parte
1	CLIP, WIRE	353253
2	Screw	WP681414
3	Screw	WP693995
4	Hinge Bumper	238614
5	Cover, Terminal Block	8558833
6	Screw - #10 - 32x1/2	486146
7	PANEL-REAR	347736
10	Lid Switch	W10820036
11	Screw, 6-20 x 1 1/16	WP98129
13	Cover Screw	WP308685
14	SPRNG-DOOR	237979
16	Leveling Foot	49621
17	Dryer Door Switch Actuator Spring/Lever	WP691581
19	Clip, Ground	WP98234
20	Front Top Lock	WP18776
22	Single Hex Head Screw	WP489069
23	Felt Clip Kit	279220
24	Door Catch Kit	279570
26	CLIP	W11252547
27	Screw, 8-18 x 3/8	WP694091
28	HINGE-DOOR	687905
28A	HINGE-DOOR	687906
29	Terminal and Wire Kit	279318
31	Wire Harness Clip	WP98997
33	Door Catch Kit	279570
35	REAR, DOOR	695954
37A	Door Handle	WP348721
37B	Door Handle - Bisque	WP3977746
38	Bearing and Seal Kit	279264
39	CLIP- STRAIN RELIEF	689180
40	Cover Screw	WP308685
41	BLOCK-TERM	279320
42	Terminal Block Screw Kit	279393
45	Single Access Panel Spring Retainer/Clip	WP3388229
48	Single Access Panel Clip	WP297092
51	Hinge, Top (2)	WP8066217
53	Idler Pulley Assembly	WP691366
56	Multi Rib Belt - 92-1/4"	341241
57	Base, Motor	WP348780

Guía	Descripción	# de parte
58	Cap Screw	3400500
59	Motor Pulley - 60 Hz.	WP8066184
61	Drive Motor with Pulley	279827
62	Drive Motor with Pulley	279827
63	Clamp-Motor	WP660658
64	WIRE	690236
67	Door Gasket	WP3390733
87	Screw	WP681414



Guía	Descripción	# de parte
1	PANEL-REAR	8066156
3	USE WPL 304795	355326
4	USE WPL 285653	63789
5	Timer Power Resistor	279872
6	Nut	WP358473
7	WIRE, JUMPER	696098
8	STOP	358472
9	USE WPL 285653	63795
10	Lint Filter with Handle	339392
11	NOT AVAILABLE	N/P
12	Lint Screen Hinge - Right Side	WPW10044470
12A	Lint Screen Hinge - Left Side	WPW10044480
13	8-18 X .625 TR CR AB	W11693756
14	Screw, Console	WP388326
21	Dryer Timer	695760
29	Screw	WP681414
31	Harness, Wiring	697061
39	Push-to-Start Switch	348314
48	KNOB	3387900
53	BRACKET	3394061
54	PANEL-CNTL	3387692
62	Knob Spring-Clip	WP688805
67	Nut	WP689559
72	WIRE	690853
76	Buzzer, Mini	WP694419
79	SWTCH-TEMP	696321
81	KNOB-CNTRL	3387894
83	Rack, Literature	63020