


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ1

TOP AND CONSOLE

TOP AND CONSOLE		
1	Panel, Rear Console	3397545
2	Switch, Finish Guard	3354285
3	Clip, Harness	3394427
4	Cap, End (L.H.) (White)	3358528
	Cap, End (L.H.) (Almond)	3358529
5	Connector (Timer)	3397269
6	Clip	688805
7	Housing, Connector (Motor)	3395683
8	Cap, End (R.H.) (White)	3358513
	Cap, End (R.H.) (Almond)	3358514
9	Buzzer, Mini	694419
10	Handle & Lint Screen Assembly	349639
11	Cover, Lint Screen (White)	688150
	Cover, Lint Screen (Almond)	689310
12	Hinge, R.H.	339229
	Hinge, L.H.	339230
13	Screw, 8-18 x 5/8	688983
14	Wire, Jumper (Guard/On-Off)	3397695
15	Screw, Hex Head	693995
16	Top (White)	3396022
	Top (Almond)	3396023
17	Wire, Jumper (Black)	3401684
18	Switch, Temperature	3399639
19	Clip, Grounding	357572
21	Timer Assembly (60 Hz.)	3406701
22	Connector, 2-Position (Gas Valve)	3403499
23	Connector, 3-Position (Gas Valve)	3403498

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1

TOP AND CONSOLE

TOP AND CONSOLE		
29	Screw, 8-18 x 5/16	3390646
30	Nut, Push-In (2)	357213
31	Harness, Wiring	3406617
32	Wire-Jumper Assembly (Temperature)	3396029
39	Relay, Push-To-Start	3398095
40	Connector (PTS Relay)	3401144
48	Timer Knob Assembly (White)	3396146
	Timer Knob Assembly (Almond)	3396149
49	Knob, Push To Start (White)	3950759
	Knob, Push To Start (Almond)	3950760
50	Receptacle, 2-Way	717252
51	Connector 6-Circuit	3347243
52	Terminal, Female	94614
53	Bracket, Control	3396293
54	Panel, Control (White)	3399053
	Panel, Control (Almond)	3399054
70	Connector (Door Switch)	353425
72	Wire, Ground	690853
76	Screw, Console	388326

Distribuidor Autorizado



Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1

CABINET

1	Screw, 10-32 x 1/2 (External Ground)	697776
2	Screw, 10-16 x 1/2	343641
3	Clamp, Motor (W/Shield)	3404162
4	Bumper	238614
5	Cover, Block	3396795
6	Screw, Hex Washer Head	693995
7	Panel, Rear	3396805
10	Door Switch Assembly	3406101
11	Screw, 6-20 x 7/8	697773
13	Screw, 8-15 x 3/8	694091
14	Spring, Door (2)	692495
15	Screw, 10-16 x 1/2	3357011
16	Foot, Dryer	3392100
	Foot - Optional	279810
18	Cabinet (In No`s. 5, 7, 16, 29 & 57) Wh	3399585
	Cabinet (In No`s. 5, 7, 16, 29 & 57) Alm	3399586
19	Clip, Ground (2)	98234
20	Lock, Front Top (2)	690363
21	Panel Front (White)	3395197
	Panel Front (Almond)	3395198
23	Clip, Felt Pad (2)	685203
24	Catch, Door Assembly	3398175
25	Seal, Door	3390731
26	Clip, Hinge (2)	337189
27	Screw	342043
28	Hinge, R.H.	692498
	Hinge, L.H.	692501

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1

CABINET

29	Clip, Front Panel	3394083
33	Strike, Panel	696144
35	Door, Rear	695737
36	Door, Front (White)	3393549
	Door, Front (Almond)	3393550
37	Handle, Door (White)	690270
	Handle, Door (Almond)	690271
38	Seal & Bearing Assembly	3406129
45	Cord, Power	344020
49	Plug, Front Panel (White)	3394975
	Plug, Front Panel (Almond)	3394976
51	Hinge, Top (2)	238088
53	Idler & Pulley Assembly	691366
56	Belt, Drive	660996
57	Base, Motor	348780
58	Bolt, 5/16-18 x 3/4	3400500
59	Pulley, 60 Hz.	3401143
62	Motor Assembly 60 Hz.	3395652
63	Clamp, Motor	660658
64	Valve, Gas 60 Hz. (Complete)	3401775
65	Ignitor	686590
66	Lock Screw & Washer (8-32 x 5/8)	3393909
67	Burner Assembly, 60 Hz.	3402844
68	Clamp, Pipe	341029
69	Kit, Conversion Type 1, 2 & 3 To Type 4 (LPG)	694572
70	Coil, 60 HZ. Split (3 Terminal)	694539
71	Coil, 60 Hz. (2 Terminal) (Main)	694540

Distribuidor Autorizado



Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ1

CABINET

72	Screw, Bracket Mounting (8-32 X 1/2) 2	694421
73	Bracket, Coil	694538
74	Leak Limiter	694424
75	Screw, Regulator Adjustment	694423
76	Spring, Regulator	694422
79	Plug, Pipe	239822

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ1

BULKHEAD

BULKHEAD		
1	Lint Chute Assembly	348368
2	Screw, 8-18 x 3/4``	3400800
3	Washer-Support	3388703
4	Seal, Lint Chute	347139
5	Screw, 8 x 3/8	90767
6	Bracket, Drum Light	3404232
7	Fuse, Thermal	3392519
8	Screw	339554
9	Thermostat, Internal-Bias	3387134
10	Wheel, Blower (Includes Illus. No. 21)	694089
11	Housing, Blower	3405016
12	Clip	3398161
13	Screw, 10-16 x 1/2	343641
14	Box, Heater	685458
15	Thermostat, 205~F (96~C)	3403140
16	Support, Heater Box	348484
17	Collar, Funnel	348516
18	Funnel, Burner	347389
19	Socket Assembly	3403634
20	Bulb	3406124
21	Seal, Blower	3394196
22	Lens, Drum Light	3402729
23	Screw, 10-12 x 1/2	3357011
24	Bracket, Bulkhead	3406022
41	Ring, Tri	690997
42	Shaft, L.H.	3399506
43	Shaft, R.H.	3399507

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ1

BULKHEAD

BULKHEAD		
44	Roller, Support	3397588
46	Washer, Support	348197
47	Nut, 3/8-16	3359452
48	Bulkhead	3403493
49	Sensor, Radiant	338906
62	Ring, Bearing	692526
63	Screw, 11-16 x 7/8	97787
66	Seal, Rear Drum	3406130
67	Drum Assembly	695587
68	Baffle, Drum (2)	692490
69	Bracket, Support	3394133
70	Clip	90296
71	Baffle, Drum (1)	3403636
73	Seal	339956
75	Shield, Exhaust	696302

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ1

BURNER ASSEMBLY

1	Burner Assembly 60 Hz.	3402844
2	Tube, Burner	688617
3	Bracket, Ignitor	694298
4	Ignitor	686590
5	Screw & Washer (8-32 x 5/8)	3393909
6	Screw, 10-16 x 1/2	343641
7	Base, Burner	693986
8	Screw, 8-18 x 3/8 (2)	3387057
9	Orifice, Burner (Type 1)	234826
	Orifice, Burner (Type 2)	15775
	Orifice, Burner (Type 3)	15419
	Orifice, Burner (Type 4 (Butane))	229742
	Orifice, Burner (Type 4 (Propane))	234868
10	Valve, 60 Hz.	3401775
11	Screw, 8-32 x 1/2 (2)	694421
12	Bracket, Coil	694538
13	Coil, 60 Hz. (2 Terminal) (Main)	694540
14	Coil, 60 Hz. (Split) (3 Terminal)	694539
15	Leak Limiter	694424
16	Screw, Regulator Adjustment	694423
17	Spring, Regulator	694422
20	Plug, Pipe	239822
21	Pipe, Gas Supply	233273
22	Elbow Union Assembly	3406052
23	Pipe, Tail	3393767
24	Nut, Compression	233076
25	Clamp, Pipe	341029
	Conversion Kit (Type 1, 2 & 3) L.P.G.	694572