


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3



Distribuidor Autorizado



Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3

TOP AND CONSOLE

TOP AND CONSOLE		
1	Panel, Rear Console	3397545
2	Switch, Finish Guard	3354285
3	Clip, Harness	3394427
4	Cap, End (L.H.) (White)	3358528
	Cap, End (L.H.) (Almond)	3358529
5	Connector (Timer)	3397269
7	Housing, Connector (Motor)	3395683
8	Cap, End (R.H.) (White)	3358513
	Cap, End (R.H.) (Almond)	3358514
9	Buzzer, Mini	694419
10	Handle & Lint Screen Assembly	349639
11	Cover, Lint Screen (White)	688150
	Cover, Lint Screen (Almond)	689310
12	Hinge, R.H.	339229
	Hinge, L.H.	339230
13	Screw, 8-18 x 5/8	688983
14	Wire, Jumper (Guard/On-Off)	3397695
15	Screw, Hex Head	693995
16	Top (White)	3396022
	Top (Almond)	3396023
17	Wire, Jumper (Black)	3401684
18	Switch, Temperature	3399639
20	Screw, Grounding	3400859
21	Timer Assembly (60 Hz.)	3976580
22	Connector, 2-Position (Gas Valve)	3403499
23	Connector, 3-Position (Gas Valve)	3403498

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ3

TOP AND CONSOLE

29	Screw, 8-18 x 5/16	3390646
30	Nut, Push-In (2)	357213
31	Harness, Wiring	3394301
32	Wire-Jumper Assembly (Temperature)	3396029
39	Relay, Push-To-Start	3398095
40	Connector (PTS Relay)	3401144
48	Timer Knob Assembly (White)	3406143
	Timer Knob Assembly (Almond)	3406144
49	Knob, Push To Start (White)	3950759
	Knob, Push To Start (Almond)	3950760
50	Receptacle, 2-Way	717252
51	Connector 6-Circuit	3347243
52	Terminal, Female	94614
53	Bracket, Control	8054298
54	Panel, Control (White)	3976756
	Panel, Control (Almond)	3976757
70	Connector	3936144
76	Screw, Console	388326

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3

CABINET

CABINET		
1	Screw, 10-32 x 5/8 (External Ground)	697776
2	Screw, 10-16 x 1/2	343641
3	Clamp, Motor (W/Shield)	3404162
4	Bumper	238614
5	Cover, Block	3396795
6	Screw, Hex Washer Head	693995
7	Panel, Rear	3396805
10	Door Switch Assembly	3406107
11	Screw, 6-20 x 7/8	697773
13	Screw, 8-18 x 3/8	694091
14	Spring, Door (2)	692495
15	Screw, 10-16 x 1/2	3357011
16	Foot, Dryer	3392100
	Foot - Optional	279810
18	Cabinet (White)	3399585
	Cabinet (Almond)	3399586
19	Clip, Ground (2)	98234
20	Lock, Front Top (2)	690363
21	Panel Front (White)	3395197
	Panel Front (Almond)	3395198
23	Clip, Felt Pad (2)	685203
24	Catch, Door Assembly	3389441
25	Seal, Door	3390731
26	Clip, Hinge (2)	337189
27	Screw, 10-32 x 3/8	342043
28	Hinge, R.H.	692498

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ3

CABINET

CABINET		
	Hinge, L.H.	692501
29	Clip, Front Panel	3394083
33	Strike, Panel	696144
35	Door, Rear	695737
36	Door, Front (White)	3393549
	Door, Front (Almond)	3393550
37	Handle, Door (White)	690270
	Handle, Door (Almond)	690271
38	Seal & Bearing Assembly	3406129
45	Cord, Power	344020
49	Plug, Front Panel (White)	3394975
	Plug, Front Panel (Almond)	3394976
51	Hinge, Top (2)	238088
53	Idler & Pulley Assembly	691366
56	Belt, Drive	660996
57	Base, Motor	348780
58	Bolt, 5/16-18 x 3/4	3400500
59	Pulley, 60 Hz.	3394341
62	Motor Assembly 60 Hz.	3976707
63	Clamp, Motor	660658
64	Valve, Gas 60 Hz. (Complete)	3401775
65	Ignitor	686590
66	Lock Screw & Washer (8-32 x 5/8)	3393909
67	Burner Assembly, 60 Hz.	3402844
68	Clamp, Pipe	341029
69	Kit, Conversion Type 1, 2 & 3	694572

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool LGR7646EZ3

CABINET

70	Coil, 60 HZ. Split (3 Terminal)	694539
71	Coil, 60 Hz. (2 Terminal) (Main)	694540
72	Screw, Bracket Mounting (8-32 X 1/2) 2	694421
73	Bracket, Coil	694538
74	Leak Limiter	694424
75	Screw, Regulator Adjustment	694423
76	Spring, Regulator	694422
79	Plug, Pipe	239822

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ3

BULKHEAD

BULKHEAD		
1	Lint Chute Assembly	348368
2	Screw, 8-18 x 5/8	489463
3	Washer-Support	3388703
4	Seal, Lint Chute	347139
5	Screw, 8-18 x 3/8	90767
6	Bracket, Drum Light	3404232
7	Fuse, Thermal	3392519
8	Drum Hole Plug	3977358
9	Thermostat, Internal-Bias	3387134
10	Wheel, Blower (Includes Illus. No. 21)	694089
11	Housing, Blower	3405016
12	Clip	3398161
13	Screw, 10-16 x 1/2	343641
14	Box, Heater	3394343
15	Thermostat, 205~F (96~C)	3403140
18	Funnel, Burner	8066049
19	Socket Assembly	3403634
20	Bulb	3406124
21	Seal, Blower	3394196
22	Lens, Drum Light	3402729
23	Screw, 8-18 x 1/2	487909
24	Bracket, Bulkhead	3406022
25	Screw, 8-18 x 3/8	693995
41	Ring, Tri	690997
42	Shaft, L.H.	3399506
43	Shaft, R.H.	3399507

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ3

BULKHEAD

BULKHEAD		
44	Roller, Support	3397588
46	Washer, Support	348197
47	Nut, 3/8-16	3359452
48	Bulkhead	3403493
49	Sensor, Radiant	338906
62	Ring, Bearing	692526
63	Screw, 11-16 x 3/4	97787
66	Seal, Rear Drum	3406130
67	Drum Assembly	695587
68	Baffle, Drum (2)	692490
69	Bracket, Support	3976434
70	Clip	90296
71	Baffle, Drum (1)	3403636
73	Seal	339956
75	Shield, Exhaust	696302

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool LGR7646EZ3

BURNER ASSEMBLY

1	Burner Assembly 60 Hz. (White Rodgers)	3402844
2	Tube, Burner	688617
3	Bracket, Ignitor	694298
4	Ignitor	686590
5	Screw & Washer (8-32 x 5/8)	3393909
7	Base, Burner	693986
8	Screw, 8-18 x 3/8 (2)	3387057
9	Orifice, Burner (Type 1)	234826
	Orifice, Burner (Type 2)	15775
	Orifice, Burner (Type 3)	15419
	Orifice, Burner (Type 4 (Butane))	229742
	Orifice, Burner (Type 4 (Propane))	234868
10	Valve, 60 Hz.	3401775
11	Screw, 8-32 x 1/2 (2)	694421
12	Bracket, Coil	694538
13	Coil, 60 Hz. (2 Terminal) (Main)	694540
14	Coil, 60 Hz. (Split) (3 Terminal)	694539
15	Leak Limiter	694424
16	Screw, Regulator Adjustment	694423
17	Spring, Regulator	694422
20	Plug, Pipe	239822
21	Pipe, Gas Supply	233273
22	Elbow Union Assembly	3406052
23	Pipe, Tail	3393767
24	Nut, Compression	233076
25	Clamp, Pipe	341029
	Conversion Kit to Type L.P.G.	694572