



COPETE / BACKSPLASH
 GABINETE Y CUBIERTA / CABINET & COVER

LMA1043PBS2



COPETE / BACKSPLASH
 GABINETE Y CUBIERTA / CABINET & COVER


LMA1043PBS2



Lavadora Mabe LMA1043PBS2(TNT)

PARTES PARA TINA / TUB, BASKET & AGITATOR

LMA1043PBS2





Lavadora Mabe LMA1043PBS2(TNT)

Guía	Componente	Descripción
6	189D3208P002	CABLE TOMACORRIENTE
11	323B1472P002	UNIVALVULA
12	323B1472P001	UNIVALVULA
15	189D1455P004	MANGUERA ENTRADA DE AGUA
18	109B8787P014	ABRAZADERA
20	189D3388P008	OVERLAY LMA1043PBS2
21	189D3330P004	PAINEL DE CONTROLE
27	228C2084P003	PRESOSTATO
30	189D3983G002	ARNES GABINETE
30	189D3983G009	ARNES GABINETE
36	323B2380G002	ENS. PERILLA ROTATORIA
39	323B2381G002	ENS. PERILLA CONTROL
45	175D4683G001	MANGUERA LLENADO
63	189D5318P001	PROTECTOR TARJETA
66	189D5218P001	PROTECTOR BASE TARJETA
69	T08G04R05	TARJETA TNT
69	T08G12R13	TARJETA TNT
72	189D2761G005	BOTON SELECTOR
72	189D2761G009	BOTON SELECTOR
75	189D3831G003	ARNES CUBIERTA
78	189D3652G002	ARNES PRESOSTATO
81	189D3653G005	ARNES SELECTOR
84	228C1256G005	SELECTOR PROGRAMA
87	228C1256G002	SELECTOR 5 PROGRAMAS
93	189D2564G001	ENS. GABINETE
93	189D2564G003	ENS. GABINETE
96	228C2081P001	PATA



Lavadora Mabe LMA1043PBS2(TNT)

Guía	Componente	Descripción
96	228C1202P001	PATA
99	228C2107P002N	ENS. BLOCAPUERTAS
99	253C1215P001	ENS. BLOCAPUERTAS
108	189D2637P001	TAPA MANGUERA
110	323B1440P002	TAPA DESPACHADOR IGUAZU
111	228C2206G001	MANGUERA
114	189D2969P003F	CUBIERTA IGUAZU 24"
117	189D3110G004	TAMPA
173	189D2917G001	ENS. TINA
173	233D1434G001	ENS. TINA
176	189D3624P001F	COPLA AGITADOR LOW COS
179	189D3745G001	ENS. AGITADOR
182	189D1180P001C	TAPA FSD COMPRADA
185	189D3916G009	ENS. VARILLA
188	189D3916G010	ENS. VARILLA
197	228C2372P001	ROTULA
200	228C2113P001	SELLO TINA
203	323B2127P001	ARANDELA
206	189D1021G001	ARO BALANCE ENS.
209	189D1007P001	CANASTA
212	189D3533P001C	FONDO CANASTA FLOTADOR
212	189D3533P001L	FONDO CANASTA FLOTADOR
212	233D2211G001	FONDO CANASTA
218	228C2160P001	TUERCA AMAZ IZQ.
221	189D3651P001	CUBIERTA TINA
227	189D1626P002C	COPA SUAVIZANTE AZUL
227	189D1626P005	COPA SUAVIZANTE AZUL



Lavadora Mabe LMA1043PBS2(TNT)

Guía	Componente	Descripción
233	189D1893P001C	RETARDANTE DE FLUJO
242	228C2089P001	TAPON CAJA PRESOSTATO
245	323B2098P001	O-RING
248	323B2099P001	CLIP TAPON PRESOSTATO
251	189D3590G001	ENS. FLOTADOR
254	228C2415P001	EMBRAGUE FIJO
303	228C2110P001	SOPORTE TARJETA
303	253C1058P001	SOPORTE TARJETA
303	253C1142P003	SOPORTE TARJETA
312	228C1259P001	CAPACITOR
315	323B1365P001	BOTON MONTAJE
318	228C2090P001	SELLO BOMBA
321	189D4153P002	ENS. MOTOR
324	189D2652P001	POLEA TRANSMISION
327	228C2115P003	BANDA UNIFICADA
327	228C2115P004	BANDA UNIFICADA
330	323B2052P001	ARANDELA DE FRICCION
333	323B2000P001	ANILLO DE RETENCION
336	189D3593G002	ENS. TX CON SOPORTE LC
339	323B1279P002	OPRESOR POLEA
345	323B2167P001	REFUERZO MOTOR
366	189D4087P002	BOMBA DE DESAGUE
366	233D2229P001	BOMBA DE DESAGUE
369	189D2645G002C	POLEA MOTOR AMAZONA ENS
369	189D2645G002L	POLEA MOTOR AMAZONA ENS
372	228C2112P001	ESPACIADOR MOTOR
372	253C1092P002	ESPACIADOR MOTOR



Lavadora Mabe LMA1043PBS2(TNT)

Guía	Componente	Descripción
381	323B1390P001	ABRAZADERA BOMBA
384	228C2076P003	TARJETA SENSOR
384	253C1058P001	TARJETA SENSOR
384	253C1142P003	TARJETA SENSOR
456	8911238P041	TORNILLO FONDO CANASTA
480	323B1193P001	TORNILLO
492	323B1346P001	TORNILLO C/GROMET COPLÉ
492	323B1346P004	TORNILLO C/GROMET COPLÉ