




TOP AND CABINET PARTS

For Models: LSQ9200LQ0, LSQ9200LT0
 (Designer White) (Biscuit)

AUTOMATIC WASHER



Literature Parts




Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	LIT4313896	Manual, (Washer) Do-It-Yourself
1	LIT3955499	Literature Parts (Wiring Diagram)
1	LIT3955554	Literature Parts (Energy Guide)
1	LIT3955869	Literature Parts (Use & Care Guide)
1	LIT3956025	Literature Parts (Installation Instructions)
2	8271378	Top (White)
2	8271380	Top (Biscuit)
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push-In (2)
5	3954357	Cabinet (Biscuit)
5	63424	Cabinet (White)
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3976348	Cabinet - Sound Damper
8	3356311	Screw & Washer, Lid Switch (2)
11	3949237	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	91770	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19	3954489	Lid (White)
19	3954491	Lid (Biscuit)
20	358684	Strike, Lid Switch
22	9724509	Bumper, Lid (2)
28	3390631	Screw, 10-16 x 3/8 (5)
30	3357011	Screw, 10-16 x 1/2
31	90016	Clip, Harness
32	3362952	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

For Models: LSQ9200LQ0, LSQ9200LT0
(Designer White) (Biscuit)





Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	3976300	WASHER, WATER INLET HOSE (4)
2	3400073	Screw, Ground
3	89503	Hose, Water Inlet (2) ((Blue Coupler))
3	89503	Hose, Water Inlet (2) ((Red Coupler))
4	9740848	Screw
5	8318255	Strap, Console (2)
6	3357978	Panel, Rear
7	62747	Pad, Rear Panel
8	3357090	Extension, Drain Hose (21 Inches)
8	285664	Hose, Drain (4 Ft.)
8	285666	Hose, Drain (9 Ft.) (Not Included)
9	3951702	Timer, Control (60 Hz.)
10	3351614	Screw
11	90767	Screw, 8-18 x 3/8
12	3366847	Switch, Water Level
13	3948608	Bracket, Control
14	3948063	Cord, Power
15	285777	Strain Relief, Power Cord
16	W10820038	Cap, End (L.H.) (White)
16	279965	Cap, End (L.H.) (Blscuit)
17	8318046	Clip, Capacitor
18	285805	Valve, Water Mixing
19	3976286	Shield, Capacitor
20	694419	Buzzer, Mini
21	370451	Clamp, Hose
22	3357328	Hose, Vacuum Break
23	371503	Clamp, Hose
24	3360977	Break, Vacuum




Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
26	8572717	Capacitor, Motor Start
27	356138	Clamp, Hose
28	3976395	Clamp, Hose
30	616099	Clamp, Hose
31	285655	Clamp, Hose
32	285871	Hose, Pump To Tub (Includes No.30)
33	8055003	Clip, Harness & Pressure Hose
35	661614	Switch, Water Temperature
36	3400818	Screw, Timer Mounting
37	8528333	Switch, Rotary
39	3955400	Panel, Console (White)
39	3955401	Panel, Console (Biscuit)
44	W10807860	Knob, Timer (White)
44	3957822	Knob, Timer (Biscuit)
45	3957849	Dial, Timer (White)
45	8271370	Dial, Timer (Biscuit)
47	3957799	Knob, Control (White)
47	8271348	Knob, Control (Biscuit)
49	388326	Screw, 8-18 x 1.25 (Panel to Top)
50	62863	Screw, 10-16 x 3/8
51	W10820038	Cap, End (R.H.) (White)
51	279965	Cap, End (R.H.) (Biscuit)
58	3357331	Clamp, Drain Hose
59	8539874	Shield, Suds
60	3955492	Harness, Wiring (For Detail See Parts Page)
61	3357027	Nozzle-Drain Hose
62	8317940	Drain Hose Assembly

AGITATOR, BASKET AND TUB PARTS

For Models: LSQ9200LQ0, LSQ9200LT0
 (Designer White) (Biscuit)






Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	63580	Dispenser
2	358237	Screw & Washer (5-16-24 x 1)
3	3348752	Clothes Mover
4	3347288	Agitator
5	8528150	Tub Ring & Gasket
6	3359585	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3363663	CAM, DRIVEN
10	3366877	Dog, Agitator Clutch
11	3363661	Bearing, Driven Cam
12	21366	Nut, Spanner
13	8526016	Basket & Balance Ring (Also Order No.14)
14	8522271	Filter Plug
15	8519788	Balance Ring
16	63849	Tub
17	389140	Block, Basket Drive
18	383727	GASKET, CENTERPOST
19	3347780	Hose, Pressure Switch
20	3348117	Agitator (Complete)
22	3350389	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal-Inner Cap
26	3949550	Washer

MACHINE BASE PARTS

For Models: LSQ9200LQ0, LSQ9200LT0
 (Designer White) (Biscuit)






Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	3400076	Screw, Bracket Mounting (10-32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	SPRING, SUSPENSION (3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (I: 6, 7, 8, 9, 16, 17,18, 26.)
21	3359452	Nut, Lock (3/8-16) (2)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LSQ9200LQ0, LSQ9200LTO
 (Designer White) (Biscuit)






Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	388952	Brake & Drive Tube (Complete)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	285785	Clutch (Complete)
6	285790	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360629	Gearcase (Complete)
10	3400516	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor & Isolation
15	3355454	Clip, Anti-Rattle
16	3400516	Screw
17	W10086010	Retainer, Motor (2)
18	W10838408	Shield, Tub To Motor
19	661600	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3946532	Shield, Motor

BRAKE AND DRIVE TUBE PARTS

For Models: LSQ9200LQO, LSQ9200LTO
 (Designer White) (Biscuit)



BD-315-A




Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	W10820043	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal. Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	TUBE, BASKET DRIVE (ILLUS. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
9	62703	``T`` Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	285790	Driver, Brake Cam
16	285208	LUBRICANT
16	90368	Ring, Retaining

GEARCASE PARTS

For Models: LSQ9200LQ0, LSQ9200LT0
 (Designer White) (Biscuit)



GC-215-C



Lavadora Whirlpool LSQ9200LTO

Guía	N.P.	Descripción
1	3360629	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	SEALER, GASKET (.20 FL. OZ.) (6 ML)
5	63320	Pinion, Spin (Includes Item 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate