




## **UNDERCOUNTER DISHWASHER**

### **MODELS:**


MDB4949SDE1 (Black)  
MDB4949SDH1 (White)  
MDB4949SDM1 (Stainless)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10741197	Installation Instructions
	W10599490	Energy Guide
	W10599529	Use & Care Guide
	W10610054	Tech Sheet, English
	W10610057	Tech Sheet, French
2		Arm, Hinge
	8534854	Left Hand
	8534853	Right Hand
3	W10321448	Barrier, Vapor

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Front Panel (Includes Item 12)
	W10562110	Black
	W10562111	White
	W10562114	Stainless
5		Toe Panel
	W10586590	Black
	W10586591	White
6		Access Panel
	W10195777	Black
	W10195778	White
7	W10315897	Insulation, Front Panel


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10526105	Insulation, Four Layer
9		Screw
	302868	Black
	3400836	White
10	304392	Screw
11	3400071	Screw
12	W10612925	Badge
13	W10463662	Spacer, Control Bracket Panel
14	W10641745	Bracket, Control
15	8269016	Clip, Ground



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly
	W10562076	Black
	W10562077	White
	W10562079	Stainless
2	W10195237	Clip, Control
3	W10735803	Control, Electronic
4	W10653840	Latch Assembly (Includes Switch)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10194937	Brace, Connector
6	W10348409	Screw
7	W10756253	Box, Connector
8		Handle Pocket
	W10562087	Black
	W10562088	White
	W10562090	Grey
9	W10566903	Jumper, 4-Wire

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10619840	User Interface
11	W10636690	Cover, User Interface
12		Button, Console
	W10613680	Black
	W10613681	White
	W10620464	Grey
13	W10348408	Screw
14	W10692204	Clip, Panel





# LAVAVAJILLAS MDB4949SDH1

**Illus.**


<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
1	W10348409	Screw
2	W10462232	Bracket, Dispenser
3	W10480715	Inner Door
4	W10497235	Seal, Door Bottom
5	W10177098	Screw

**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
6	W10629971	Dispenser Assembly
7	W10195007	Seal, Console/Door

**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
8	8281217	Screw
9	W10744902	Wiring Harness






<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch
2	8531412	Hose
3	W10195536	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10213825	Nut, Water Inlet (Also Order Item 4)
6	371505	Clamp, Hose

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10327249	Fill Valve Assembly
8	304392	Screw
9	370445	Clamp, Hose
10	W10545278	Drain Loop with Check Valve Assembly
11	W10195039	Switch, Overfill Control
12	W10647205	Housing, Overfill (Also Order Item 13)


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	8531743	Gasket, Flat
14	W10195038	Nut, Standpipe
15	W10195036	Float & Retainer Assembly
16	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681488	Tub Assembly (Includes Heater Assembly)
2	8269145	Bracket, Undercounter
3	W10300924	Gasket, Tub
4	W10082838	Plug, Tub
5	W10292870	Shield, Thermostat
6	W10179427	Seal, Cabinet
7	W10713315	Assembly, Terminal Box
8	W10084086	Door Balance Assembly
9	W10544004	Strike, Latch
10	3378128	Washer, Pronged Cup
11	3400074	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10348411	Screw
13	W10190778	Wheel Leg
14	W10619352	Leveler, Leg
15	3400014	Screw, Grounding
16	8270020	Spring, Door Balance
17	W10337661	Strain Relief
18	304392	Screw
19	W10653292	Cover, Terminal Box
20	W10158291	Cable, Door
21	W10309090	Screw
22		Spacer, Tub
	W10195630	Left Hand
	W10195631	Right Hand


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
23	8573239	Shield, Tub Sound
24	W10300703	Bracket, Thermostat
25	W10195091	Thermostat
26	W10195368	Sound Insulation, Bottom
27	3400924	Retainer, Push In
28	3367670	Screw
29	W10681564	Support Assembly, Rear
30	9743002	Gasket, Mounting Bracket
31	W10078083	Wheel And Mount Assembly



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10591545	Accumulator Assembly
2	W10195086	Motor, Isolator
3	W10571942	Cover, Accumulator
4	W10482462	Sump With Seal (Also Order Items 13 & 18)
5	W10463892	Cover, Outlet
6	W10591547	Protector, Inlet
7	W10591540	Adapter, Drain
8	W10591562	Chopper Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10591569	Motor Assembly (Also Order Item 13)
10	W10372113	Tab, Sump
11	W10348407	Screw
12	W10591570	Sump & Motor Assembly
13	W10538166	Grommet
14	8533949	Nut
15	W10348269	Pump, Drain
16	W10591561	Enclosure, Motor
17	8269144	Hose, Drain

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10445975	Hose Assembly (Includes 2 Clamps)
19	W10591558	Impeller Assembly
20	W10705575	Indicator, Optical Wash
21	W10591575	Capacitor
22	370445	Clamp, Hose
23	W10618403	Housing, Pump
24	W10467002	Screw
25	W10169167	Clamp, Hose
26	W10605800	Sprayarm, Lower






# LAVAVAJILLAS MDB4949SDH1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)
2	W10327455	Sprayarm, Third Level

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	3400918	Retainer
4	W10571949	Manifold

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10605345	Sprayarm, Upper
6	W10195690	Bracket, Feed Tube






<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10696509	Heater Element Assembly
2	W10446558	Washer, Heater

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10687139	Nut, Heater Element

NOTE: If heater element  
is removed, it must be  
replaced.






# LAVAVAJILLAS MDB4949SDH1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10599523	Dishrack, Upper
2	8565925	Stop, Track (Non-Removable)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10571738	Wheel Assembly, Stationary
4	3385089	Track, Dishrack
5	W10630200	Cupshelf

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10082860	Stop, Track (Non-Removable)
7	W10306230	Spacer, Track





# LAVAVAJILLAS MDB4949SDH1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525642	Dishrack, Lower
2	W10195416	Wheel & Transport Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10630199	Silverware Basket Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10630198	Lid, Side
5	W10630197	Lid, Center

# OPTIONAL PARTS (NOT INCLUDED)

## Illus. ACCESSORIES

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft. Handle Assembly
	W10702080	Black
	W10702081	White

## Illus. PAINT, TOUCH-UP (1/2OZ.)

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

## Illus. PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

## Illus. PAINT, BULK (1 QT.)

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	4392900	Biscuit/Bisque

## Illus. POWER CORD KIT

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

## Illus. ANTI-TIP KIT

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

## Illus. DISHRACK REPAIR

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis