


## CABINET PARTS




## MFF2055YEM00

1	W10405120	Use And Care Guide
1	W10458271	Energy Guide
1	2225623	Icemaker Service Sheet
1	W10536929	Service And Wiring Sheet
2	W10546298	Hinge, Top (LEFT HAND)
2	W10546299	Hinge, Top (RIGHT HAND)
3	W10359256	Roller, Front (LEFT HAND)
3	W10359255	Roller, Front (RIGHT HAND)
4	EDR1RXD1	Filter, Water (Replaces: W10217316)
5	2185788	Clamp, Tube (Replaces: M0108107)
6	488729	Screw (Replaces: 2262176)
7	489497	Screw
8	W10339257	Cover, Toe Grille (WHITE)
8	W10353930	Cover, Toe Grille (BLACK)
8	W10353932	Cover, Toe Grille (GREY)
9	489442	Screw
10	W10141622	Brake, Roller (Replaces: W10141622)
11	W10449880	Tube, Filter Inlet
12	3196256	Clamp, Power Cord (Replaces: 549193)
13	489497	Screw
14	W10521409	Hinge, Center (RIGHT HAND)
14	W10521411	Hinge, Center (LEFT HAND)
15	W10450363	Shim, Center Hinge
16	489442	Screw
17	N/P	Rail, Center
18	N/P	Fitting, Water Tube
19	W10844267	Housing, Water Filter (Replaces: W10346257)
20	W10283960	Cover, Corner (BLACK)
20	W10851579	Cover, Corner (GREY) (Replaces: W10283961)
20	W10283959	Cover, Corner (WHITE)
21	W10353933	Grille, Toe (BLACK)
21	W10353935	Grille, Toe (GREY)
21	W10300127	Grille, Toe (WHITE)
22	W10331226	Drum, Toe Grille
24	W10449611	Tube, Filter Outlet
25	W10465771	Cover, Hinge (LEFT HAND (BLACK))

25	W10465767	Cover, Hinge (RIGHT HAND (GREY))
25	W10465768	Cover, Hinge (LEFT HAND (GREY))
25	W10465764	Cover, Hinge (RIGHT HAND (WHITE))
25	W10465765	Cover, Hinge (LEFT HAND (WHITE))
25	W10465770	Cover, Hinge (RIGHT HAND (BLACK))
26	W10306392	Cover, Water Filter
27	W10636716	Cover, Unit (Replaces: W10444800)
28	N/P	Cabinet
29	1106508	Gasket, Seal
30	W10601149	Fitting, Water Tube
31	488163	Screw (Replaces: 488208)


MFF2055YEM00

## LINER PARTS



MFF2055YEM00

## FREEZER DOOR PARTS




## MFF2055YEM00

1	LW10353182	Door, Freezer
1	LW10413530	Door, Freezer
1	LW10413531	Door, Freezer
2	W10378263	Pan, Ice
3	W10460611	Gasket, Freezer (BEIGE) (Replaces: W10465758)
3	W10460583	Gasket, Freezer (BLACK) (Replaces: W10465761)
3	W10836785	Gasket, Freezer (GREY) (Replaces: W10465762)
4	W10360538	Assembly, Handle
4	W10409179	Assembly, Handle
4	W10409180	Assembly, Handle

MFF2055YEM00

## REFRIGERATOR DOOR PARTS




## MFF2055YEM00

1	LW10393587	Door, Refrigerator (LEFT HAND (WHITE))
1	LW10353181	Door, Refrigerator (RIGHT HAND (WHITE))
1	LW10413522	Door, Refrigerator (LEFT HAND (BLACK))
1	LW10413518	Door, Refrigerator (RIGHT HAND (BLACK))
1	LW10413524	Door, Refrigerator (LEFT HAND (STAINLESS))
1	LW10413519	Door, Refrigerator (RIGHT HAND (STAINLESS))
2	2183805	Bracket, Door Stop (Replaces: 2189202)
3	681249	Screw (Replaces: 489276)
4	W10366270	Thimble (RIGHT HAND)
4	W10334042	Thimble (LEFT HAND)
5	W10170766	Badge, Maytag
6	W10470155	Closure, Door
7	W10331764	Bin, Medium
8	W10460610	Gasket, Refrigerator (BLACK) (Replaces: W10413465)
8	W10460612	Gasket, Refrigerator (BEIGE) (Replaces: W10353189)
8	W10460580	Gasket, Refrigerator (GREY) (Replaces: W10413468)
9	W10252288A	Assembly, Handle (STAINLESS)
9	W10252285A	Assembly, Handle (BLACK)
9	W10252284A	Assembly, Handle (WHITE)
10	W10317224	Compartment, Utility
11	W10372916	Bin, Shallow
12	W10462298	Bin, Low Profile
13	W10624450	Mullion, Door (GREY)
13	W10624448	Mullion, Door (BLACK)
13	W10624451	Mullion, Door (WHITE)
14	W10854958	Screw (Replaces: 12990302)
15	W10397055	Bracket, Door Stop



MFF2055YEM00

## UNIT PARTS




## MFF2055YEM00

1	W10300116	Plate, Unit Mounting
2	W10852725	Grommet, Condenser (Replaces: 2319835)
3	W10342567	Condenser
4	W10436849	Heater, Defrost
5	W10321158	Assembly, Evaporator
6	8533961	Screw
7	W10314195	Shield, Heat
8	W10854533	Valve, Drain (Replaces: W10519112)
9	W10314199	Tube, Drain
10	W10683556	Clip, Condenser (Replaces: W10248621)
11	W10424230	Assembly, Low Voltage Wire
12	W11034366	Control, Electronic (Replaces: W10336511)
13	W10370696	Enclosure, Electronic Control
14	W10169124	Grommet (Replaces: 10835903)
15	W10194431	Device, Combination Start
16	W10313215	Cover, Electronic Control
17	W10475495	Roller
18	2179826	Axle, Rivet
19	8533859	Screw
20	W10236396	Strap, Compressor
21	W10204187	Strap, Bale
22	W10890667	Tray, Drain (Replaces: W10466213)
23	W10466682	Tube, Suction
24	W10390445	Assembly, Unit Wire
25	W10139483	Blade, Fan
26	2212848	Tube, Process (Replaces: VS20001)
27	489128	Screw (Replaces: 488500)
28	W10466675	Compressor (ALSO ORDER 876765 TUBE KIT)
29	W10843121	Drier (Replaces: W10190413)
30	W10662129	Capacitor (Replaces: 2169373)
31	2315541	Baffle, Air
32	2188874	Motor, Condenser
NI	978025	Valve, Access
NI	978026	Valve, Access
NI	978027	Valve, Access
NI	978028	Valve, Access

NI	978029	Valve, Access
NI	978030	Valve, Access
NI	876764	Valve, Access
NI	N/P	Refrigerant Charge 4.25 Oz.

MFF2055YEM00

## ICEMAKER PARTS




**MFF2055YEM00**

1	2185788	Clamp, Tube (Replaces: M0108107)
2	489478	Screw (Replaces: 489478)
3	628379	Clip, Thermal Fuse
4	4387491	Insert, Tube (Replaces: 2181939)
5	W10279909	Valve, Inlet
6	W10496649	Tube, Water
7	488163	Screw (Replaces: 488208)
8	W10289690	Cover, Icemaker
9	489136	Screw
10	W10190929	Assembly, Mold And Heater (Replaces: W10122527)
11	W10435665	Cup, Water Fill
12	627843	Ejector
13	W10122563	Stripper, Ice
14	2195914	Housing, Support (Replaces: 2194712)
15	2315522	Retainer, Thermostat
16	627985	Thermostat (Replaces: W10290336)
17	W10001280	Screw
18	681249	Screw (Replaces: 489276)
19	W10474785	Shut Off Arm
20	W10309400	Assembly, Ice Maker Wire
22	8201515	Assembly, Module And Motor (Replaces: W10223929)
23	N/P	Motor
100	4317943	Icemaker Assembly (Replaces: W10190952)


MFF2055YEM00

## SHELF PARTS

### REFRIGERATOR



### FREEZER



## MFF2055YEM00

1	W10486290	Assembly, Full Shelf
2	W10476425	Assembly, Flip Down Shelf (Replaces: W10352270)
3	W10468557	Track Rail, Center
4	W10305243	Shelf, Flip Down
5	W10468556	Track Rail, Right Hand
6	W10468555	Track Rail, Left Hand
7	W10370327	Pan, Crisper
8	W10317184	Pan, Crisper
9	P1FB6S1	Holder, Produce Filter (Replaces: W10408748)
10	W10356846	Control, Humidity
11	W10346771A	Filter, Produce Preserver (Replaces: W10346771)
12	W10397907	Assembly, Pantry Deli Pan
13	W10397908	Pantry Rail, Left Hand (Replaces: W10317191)
14	W10317189	Pantry Rail, Right Hand
15	W10278139	Roller
16	W10411411	Control, Temperature
17	W11241829	Assembly, Pantry Cover Support (Replaces: W10507470)
18	W10555437	Bin, Upper Freezer
19	W10257246	Axle, Roller
20	W10317289	Basket, Lower Freezer
21	W10371538	Shaft, Rack
22	W10277361	Collar, Gear
23	W10397636	Adaptor, Freezer
23	W10397635	Adaptor, Freezer
24	W10513681	Glass, Pantry Cover

**\*NOTA: SI EL CODIGO DEL ARTICULO QUE NECESITA NO APARECE EN NUESTRA PAGINA WEB, ES PROBABLE QUE SEA SOBRE PEDIDO O ESTE OBSOLETO.**

**FAVOR DE COMUNICARSE A NUESTRAS OFICINAS PARA MAYOR INFORMACION**

**TELEFONOS: 83377949, 83377999 Y 83373889.**