




Refrigerador Maytag MFI2670XEM10


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	25	12990702	Screw
	W10475393	Tech Sheet	26		Cabinet (Not A Servicable Part)
	W10314958	Use & Care Guide	27		Roller Assembly
	W10310961	Guide, Energy		W10515762	Right Hand
2	12961401	Tube, Water		W10515763	Left Hand
3	12698403	Plate, Pivot	28	12990302	Screw
4	B5759655	Gasket	29	12957801	Gasket, HV Control Box
5		Cover, Top Hinge (Right)	30	W10211854	Cover, Unit
	12962302AP	Grey	31	W10344402	Tube, Drain
6		Cover, Fill Tube	33	12820505	Insulation
	12981401AP	Grey	34	W10141622	Brake, Roller
7	12961602	Cover, Control Box	35	W10120821	Control, Electronic
8	M0108107	Clamp, Tube	36	W10438707	Board, Control
9	12992602	Screw	37	W10208592	Cover, Valve
10		Hinge, Top			
	12963205ED	Right Hand			
	12963204ED	Left Hand			
11	12992201	Screw, Center Hinge			
12	12990511	Screw			
13		Cover, Top Hinge (Left)			
	W10337648	Grey			
14	12992403	Screw			
15		Hinge, Center (RT)			
	13000002AP	Grey			
16	W10485986	Guide, Waterline			
17		Cover, Corner			
	12587703AP	Grey			
19		Shim, Top			
	12999501	Left Hand			
	12999502	Right Hand			
20	12991302	Screw			
22		Grille, Toe			
	W10244558	Grey			
23	W10296541	Lid, HV Control Box			
24		Hinge, Center (LT)			
	13000001AP	Grey			





Refrigerador Maytag MFI2670XEM10

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10343359	Housing, RC-LED
5	W10396902	Grille, Air
6	12466103	Switch, Rocker
8	W10289592	Module, Main LED
9	W10311756	Lens, RC Led
10	3400065	Screw
11	12960101	Cover, Upper Water Tank
12	12960301	Cover, Filter
13	12960001	Cover, Lower Water Tank
14	UKF8001	Filter, Water
15	12955901	Bracket, Filter Base
16	W10190541	Mount, Crisper Support
17	W10334463	Bracket, Water Tank & Valve
18	W10418477	Assembly, Water Tank & Head
19	12664501SP	Cartridge, Bypass
20	W10312696	Valve, Water Inlet
21	W10309869	Cover, Wiring
24	W10444033	Tube, Water
25	W10118193	Enclosure, Water Valve Connector
26	W10118194	Lid, Enclosure
		Following Parts Not Illustrated
	W10296251	Harness, RC Lights (Includes Thermistor)






Refrigerador Maytag MFI2670XEM10

Illus.
No.

Part No. **Description**


1	12883507 Shelf, Glide Out
2	12802602SP Front, Crisper Pan
3	12731302 Drawer, Pantry
4	12656815 Lid, Pantry
5	Endcap, Pantry
	12656019 Right Hand
	12656106 Left Hand
6	12990302 Screw
7	Ladder, Side
	W10251965 Right Hand
	W10251966 Left Hand
9	W10235370 Glide, Pantry
10	12804601SP Pan, Crisper
11	12642303WD Brace, Crisper Cover
12	W10329866 Frame, Crisper
13	12204824 Glass, Crisper
14	W10273464 Ladder, Center
15	12990513 Screw
16	12990515 Screw
17	12530805SP Slide, Humidity Control
18	13062602 Support, Crisper Frame
19	12655204 Knob, Temperature Control
20	12990504 Screw
21	12655304 Bar, Control
22	12655902SP Trim, Pantry Glass
23	12227305WHBrace, Pantry
24	12204830 Glass, Shelf
25	12656202 Control, Housing
26	12655402 Slide, Temperature Control
27	12656901 Gasket, Pantry
28	12731901 Divider, Pantry
29	W10231345 Trim, Crisper
30	W10326469 Rail, Center Crisper
31	12531901 Track, Deli Drawer
32	12990512 Screw
33	12885501 Shelf, Mini Stationary





Refrigerador Maytag MFI2670XEM10


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10536669	Assembly, Ice Bin
2	W10121282	Inlet, Blower
3	W10309863	Scroll, Blower
4	W10308033	Motor, Fan
5	W10123444	Wheel, Blower
6	12956603	Clip, Fan Motor
7	W10151687	Grommet, Fan Motor
8	W10309864	Divider, Ice Box
9	12920001	Gasket, Damper
10	W10309868	Motor, Auger
11	W10196393	Damper, Control
13	W10118612	Liner, Divider
14	12990511	Screw
16	W10465946	Washer
17	63052A001	Yoke, Ice Dispenser
18	W10346971	Bracket, Solenoid
19	W10309866	Assembly, Solenoid





Refrigerador Maytag MFI2670XEM10


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
3	12002497	Gear
5	12812903WD	Shaft, Rack
6	12570701	Socket, Light
7	A3189392	Gasket, Foam
8	12990521	Screw
9	W10311527	Bulb, Light
10	W10277466	Housing, Foil
11	W10308421	Cover, Evaporator
12	12990511	Screw
13		Bracket, Door Slide
	W10330991	Left Hand
	W10330993	Right Hand
14	W10315248	Module, Light
15	12956601	Clip, Fan Motor
16	12466111SP	Switch, Light
17	12990504	Screw
18	W10309238	Extension, Drain Tube
19	W10488000	Slide, Door
20	A3189397	Gasket, Foam
21		Adapter
	W10284682	Left Hand
	W10284683	Right Hand
22	12959901	Grille, Air
23	12951401	Shroud, Evaporator
24	12986101	Blade, Fan
25	12951101	Grommet, Fan Motor
26	W10276647	Motor, Evaporator (Includes Heater Harness)
27	D7753903	Funnel, Drain
28	M0500703	Seal
29	B8381501	Gasket, Drain
31	12815301	Cover, Thermistor
32	12990501	Screw





Refrigerador Maytag MFI2670XEM10


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	13107315S	Stainless
3	W10290553	Bucket, Upper
4	W10290555	Bucket, Wine Bottle
5	12840004	Bucket, Gallon
6	12990204	Screw
7	W10297151	Bucket, Lower
8		Gasket, Door
	W10443238	Grey
9		Handle, Door
	W10252288	Stainless
11	W10511930	Waterline, Door
13	W10287601	Seal, Ice Chute
14		Mullion, Door
	12722815AP	Grey
16		Closure, Door
	12028505AP	Grey
17		Stop, Door
	12968202AP	Grey
19	12996601	Clip, Bushing
21	12990521	Screw
22	W10170766	Stainless
23		Door, Right
	13107316S	Stainless
24	W10288153	Screw





Refrigerador Maytag MFI2670XEM10


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2	W10337912	UI Assembly
3		False, Wall, Dispenser
	W10299897	Grey
4	W10368732	Pad Assembly, Water & Ice
6	W10353552	Assembly, Seperator
7	2316647	Assembly, Spigot Body
8	W10174827	Bracket, Ice Door
9	W10205979	Motor, Ice Door
10	W10346124	Support, Ice Door
11	W10278987	Separator
12	W10339578	Guide, Ice
13	4449745	Screw
14		Tray, Dispenser
	W10299895	Grey
15		Slide Tray, Dispenser
	W10267863	Grey
17	W10238083	Assembly, LED





Refrigerador Maytag MFI2670XEM10

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Freezer Door
	12977863S	Stainless
2		Handle, Door
	W10252300	Stainless
3		Gasket, Door
	W10443322	Grey
5	W10146439	Divider, Upper Basket
6	W10348249	Basket, Upper
7	W10293682	Bin, Lower
10		Gear Spur
	W10474716	Left Hand
	W10474715	Right Hand
11		Gear Mount
	W10348260	Right Hand
	W10348259	Left Hand
12		Rack
	W10516602	Right Hand
	W10516603	Left Hand
13	W10288153	Screw
14	12812904WD	Shaft, Rack






Refrigerador Maytag MFI2670XEM10

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw
2	12825803	Blade, Fan
3	W10480111	Basepan
4	12990511	Screw
5	W10350564	Capacitor
6	W10233569	Tube, Discharge
8	W10296785	Pan, Drain
9	W10216919	Screw, Shoulder
10	12729123	Heater, Defrost
11	W10174384	Strap, Bale
12	W10448874	Device, Start
13	W10137529	Grommet, Condenser
14	2319835	Grommet, Condenser
15	12477102	Roller
16	12992101	Screw
18	W10346415	Condenser
19	W10281329	Clip, Drier
20	W10292803	Tray, Drip
21	12990518	Screw
22	W10313899	Evaporator
23		Dam
	12963102SP	Right Hand
	12963002SP	Left Hand
24	W10239053	Motor, Fan
25	10428101	Clip, Heater
26	W10402006	Harness, Unit (Includes Power Cord)
27	W10143759	Drier
28	W10445423	Compressor
29	10623002	Clip, Evaporator
30	12477202	Axle, Roller
31	W10189184	Shroud

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
34	W10334458	Connector, Water Tube
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		5.25 Ozs. (R-134A)





Refrigerador Maytag MFI2670XEM10

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300025	Assembly, Mold & Heater
2	W10378254	Arm, Shutoff
3	W10377998	Cup, Fill
4	W10318914	Ejector, Arm
5	W10122563	Stripper, Ice
8	W10290336	Thermostat
9	W10001240	Screw
10	W10351019	Extension, Shutoff Arm
11	8533917	Screw
12	W10460383	Cover, Front
13	W10342318	Valve, Solenoid
14	W10312691	Assembly, Impinger
15	W10404016	Harness, Icemaker
16	12990511	Screw
17	W10377147	Assembly, Module
18	W10001240	Screw
19	628379	Clip, Thermal Fuse
100	W10377151	Assembly, Icemaker

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key