



LAVADORA MVWC300VW0

Guía	Número de parte	Descripción
1	SCREW	W10846509
2	Spring Outer Bracket	WP64067
3	Suspension Spring	WP63907
4	SUPPORT	280184
5	Bracket, Spring Outer (L.F.)	WP64065
6	Leveling Mechanism Link	WP63466
7	Leveling Spring	8316845
8	OVERLAY, GRAPHIC	WP62837
9	Rear Leveling Foot	285244
10	Center Post Bearing	WP8546455
11	SEAL	W11095997
12	Counter Balance Spring Kit	285901
13	Suspension Pads - Package of 3	285219
14	Plate, Suspension (Includes It	WP3946509
15	Tub Wear Pads - Package of 3	285744
16	BASE	285771
17	Leveling Leg Locking Nut	WP3359452
18	Foot, Front - Single	WPW10001130
19	Washer Transmission Stem Seal	WP8577376
20	Centerpost Bearing and Seal Assembly	285203
21	Ring, Sound Deadening	WP63134
22	Suspension Spring Retainer	WPW10145155




LAVADORA MVWC300VW0

MAYTAG®

AUTOMATIC
WASHER


For Model: MVWC300VW0
(White)





LAVADORA MVWC300VW0


Guía	Número de parte	Descripción
1	INSTALL INSTRUCTIONS	W10200331
2	Washer Lid	WPW10193868
3	Lid Hinge Mounting Screw	WPW10119828
4	Lid Hinge Bearing	WP8319539
5	Screw, Ground	WP3351614
6	Washer Lid Switch	WP8318084
7	Hinge	WPW10225136
8	Washer Lid Hinge	WP91770
9	Cabinet Retaining Clip	WP62780
10	Bleach Dispenser	WPW10192089
11	TOP	W10194868
12	Spacer	WP62750
13	CABINET	63424
14	Screw, 8-18 x 1/2	WP3390631
15	Lid Bumper	WP9724509





LAVADORA MVWC300VW0


Guía	Número de parte	Descripción
1	Fabric Softener Dispenser	8575076A
2	Agitator Cap Barrier with Seal	WPW10074580
3	Seal, Inner Cap	WPW10072840
4	Agitator Bolt	WP358237
5	Washer	WP3949550
6	Agitator (Complete)	WPW10093672
7	AGIT REPAIR WPL	14210051
8	DOG-AGIT WPL	14210005
9	Agitator Cam Bearing	WP3363661
10	Upper Agitator	WP3349019
11	Thrust Spacer	285587
12	Agitator	WPW10110020
13	RING-TUB	W10880720
14	Gasket, Tub Ring	WP3976308
15	Clip, Agitator	WP3354845
16	Washer, Agitator	WP8543666
17	Ring, Balance	WP387240
18	NUT WPL	14210543
19	Inner Tub Basket	W10389328
20	CLIP	2219077
21	Water Pressure Hose - Cut-to-Fit	WP353244
22	BLOCK WPL	14210060
23	Washer Outer Tub	63849
24	Centerpost Gasket	W10814296





LAVADORA MVWC300VW0

Guía	Número de parte	Descripción
1	Basket Drive Assembly with Clutch	W10820043
2	Ring, Thrust	WP62658
3	Spin Pinion Seal	WP356427
4	Spin/Drive Tube	WP64208
5	RING-E	W10083190
6	Brake Shoe Assembly	285438
7	Spin Tube Bearing	WP8546462
8	SLEEVE	285658
9	SPRING, BRAKE	387806
10	SLEEVE	285658
11	Cam, Brake Release	WP8546461
12	Sleeve, Cam	WP63022
13	LINING WPL	14210478
14	RING-WIRE	W11033823





LAVADORA MVWC300VW0

Guía	Número de parte	Descripción
1	Extra Rinse Switch	WPW10168262
2	Capacitor, Motor Start	WP8572717
3	Console Clip	WP8312709
4	Water Level Switch	W10339334
5	SWTCH-TEMP	W10202616
6	CLIP	8317975
7	Timer	WPW10175557
8	CLIP	8318046
9	Control Panel and Touchpad - Stainless	W10089728
10	MEDALLION	W10101390
11	D-Shaped Knob Insert	WP8536939
12	Control Knob - Stainless	WPW10180218
13	Knob	WPW10180213
14	DIAL	W10180214
15	Strap, Console (2)	WP8568314
16	CORD-POWER	W10820044
17	Washer Power Cord Strain Relief	285777
18	Screw, 8-18 x 1/2	WP9740848
19	Screw, Ground	WP3351614
20	Zip Tie	WPW10339879
21	U-Bend, Drain Hose	WP8577378
22	HOSE-DRAIN	WPW10189267
23	Endcap	WPW10193824
24	Endcap	WPW10193821
25	CORD-LEAD-	Y62863
26	Support, Rear Panel	WP8519200
27	SCREW	3400073
28	Clamp, Hose	8541668
29	Hose Clamp	WP285655
30	Hose Clamp	WP616099
31	Tub-to-Pump Hose Kit	285871
32	PANEL-REAR	W10194451
33	Pad, Rear Panel	WP62747
34	HARNS-WIRE	W10189197
35	Pressure Switch Harness Clip	WP8055003
36	SHIELD	8539874
37	Water Inlet Valve and Thermistor Assemb	WP3979346




LAVADORA MVWC300VW0

Guía	Número de parte	Descripción
38	Hose Clamp	WP596669
39	Break Hose	WP8317926
40	Hose Clamp	WP596669
41	Water Inlet Syphon	WP3360977




LAVADORA MVWC300VW0





LAVADORA MVWC300VW0

Guía	Número de parte	Descripción
1	Basket Drive Assembly with Clutch	W10820043
2	Washer, Spin Tube Thrust	WP63292
3	Ring, Spin Tube Support	WPW10080230
4	Brake and Drive Tube Retainer Ring Kit	285353
5	Clutch Assembly	WP8299642
6	LINING	W10817888
7	Cap	WP62646
8	Spring	WP8559387
9	Gearcase	3360629
10	Screw	WP3400516
11	Plate, Motor Mount To Gearcase	WP62611
12	Single Motor Grommet	WP62691
13	Direct Drive Heavy Duty Coupling	285852A
14	Seal, Centerpost	WP8577374
15	Clip, Anti-Rattle	WP3355454
16	Screw	WP3400516
17	Motor Retainer Clip	WPW10086010
18	SHIELD-MTR	W10838408
19	2-Speed Drive Motor - 60Hz 120V	WP661600
20	Switch, Main Drive Motor	WP3952056
21	Pump Retainer	WP8546127
22	PUMP WPL	14210009
23	Screw	WP273556
24	Shield, Motor	WP3946532
25	WASHER	8578981





LAVADORA MVWC300VW0

Guía	Número de parte	Descripción
1	Gearcase	3360629
2	COVER	285202
3	Washer Gear Case Cover Seal	WP3349985
4	Sealer, Gasket (.20 Fl. Oz.) (WP285195
5	Screw, Ground	WP3351614
6	Gearcase	3360629
7	NOT AVAILABLE	N/A
8	Ring, Retaining	90369
9	RETAINER	62677
10	SPRING	62676
11	Shaft, Agitator (Complete)	WP389387
12	WASHER	62619
13	Shaft, Agitator (Complete)	WP389387
14	Shaft, Agitator (Complete)	WP389387
15	Shaft, Agitator	WP389231
16	WASHER, CAM THRUST	62618
17	Washer, Intermediate	WP388815
18	Shaft, Agitator (Complete)	WP389387
19	BEARING	285205
20	BEARING	285205
21	Oil Seal Kit for Gearcase Input Shaft	285352
22	DISCONTINUED	N/A
23	WASHER	285766
24	NEUTRAL DRAIN KIT	388253A
25	Gearcase	3360629
26	Gearcase	3360629