


Lavadora Maytag MVWX500XW2

MAYTAG

AUTOMATIC WASHER

For Models: MVWX500XW2, MVWX500XL2
 (White) (Silver)



Literature Parts



Lavadora Maytag MVWX500XW2


Guía	N.P.	Descripción
1	W10240509	Installation instructions
1A	W10338687	Owner's manual
1B	W10468342	Technical sheet
1C	W10280498	Lndry gde
1D	W10062961	Energy guide
2	W10238290	Washer top panel
2A	W10268719	Top
3	W10270565	Washer lid and bumper (white)
3A	W10270567	Lid
4	9724509	Washer lid bumper
5	W10295775	Hinge washer
6	W10294031	Washer lid hinge, right
7	W10119828	Washer screw
8	W10240513	Washer door strike
8A	W10240514	Washer lid lock strike
9	W10273971	Washer screw
10	W10240977	Washer bleach dispenser
10A	W10304138	Dispenser
11	W10392041	Washer lid lock bezel
11A	W10392092	Bezel
12	W10293272	Washer lid hinge bearing, left
12A	W10293230	Washer lid hinge bearing, right
13	90016	Washer wire harness retainer
14	W10404050	Washer lid lock assembly
15	8281163	Refrigerator screw
16	W10333228	Hinge pad
17	W10251994	Washer cabinet



Lavadora Maytag MVWX500XW2

Guía	N.P.	Descripción
17A	W10240528	Washer cabinet
18	W10215098	Brace
19	W10215099	Brace
20	1157158	Appliance screw
21	W10248088	Washer cabinet clip
22	W10397767	Washer leveling leg
23	W10250884	Panel
24	W10215102	Hinge washer
25	W10142728	Refrigerator screw
26	W10215139	Wire shield
27	3400076	Washer power cord gro
28	W10339879	Washer cable tie
29	W11244231	Washer drain hose
30	W10280024	Washer drain hose u-bend bracket
31	356138	Hose clamp
32	9740848	Dishwasher screw
33	W10323735	Medallion

Lavadora Maytag MVWX500XW2






Lavadora Maytag MVWX500XW2

Guía	N.P.	Descripción
1	W10276397	Washer drain pump assembly
2	W10004910	Washer screw
3	W10215091	Washer tub-to-pump hose
4	8317496	Washer hose clamp
5	W10469846	Washer gear case
6	W10249633	Screw
7	W10416660	Washer drive motor
8	W10094780	Washer counterwe
9	W10326374	Washer drive pulley
10	W10006352	Washer drive pulley
11	W10006353	Washer drive pulley
12	W10006354	Washer drive pulley
13	W10006356	Washer motor drive pulley
14	W10163336	Nut washer
15	W10006384	Washer drive belt
16	W10006355	Washer actuator
17	9741052	Screw, 6-32 x 1.00
18	W10390446	Washer start/run capacitor
19	22001995	Washer screw
20	W10427633	Washer pulley shield

Lavadora Maytag MVWX500XW2





Lavadora Maytag MVWX500XW2


Guía	N.P.	Descripción
1	W10272444	Washer console (white)
1A	W10293204	Console
2	W10251381	Dryer control knob
2A	W10251384	Dryer control knob
3	W10272630	Washer user interface
4	W10219342	Screw
5	8312709	Laundry appliance end cap clip
6	W10480127	Washer electronic control board
7	W10420984	Washer control panel cover, rear
8	3390647	Appliance screw
9	489069	Appliance screw
10	W10280079	Seal
11	W10266797	Washer power cord
12	400076	Washer power cord grou
13	W10432327	Washer dispenser housing and water
14	W10240949	Washer water inlet valve
15	W10240948	Washer water inlet valve
16	W10343675	Washer wire harness
18	97787	Dryer screw
19	W10240946	Washer dispenser bezel (white)
20	W10240960	Washer dispenser drawer assembly
21	W10285493	Washer wire harne
22	9740848	Dishwasher screw
23	W10326923	Laundry appliance control knob spacer
24	8536939	Laundry appliance control knob clip
25	W10274524	Laundry appliance electronic control
26	W10305134	Laundry appliance control knob bezel
28	W10287478	Washer handle

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Maytag MVWX500XW2





Lavadora Maytag MVWX500XW2

Guía	N.P.	Descripción
1	W10305251	Cap
2	W10003790	Washer screw
3	3949550	Washing machine washer
4	W10215146	Washer tub ring
5	W10205824	Washer tub ring p
6	W10215119	Washer washplate
7	8533953	Washer screw
8	W10396887	Driveblock
9	W10402178	Washer drive hub
10	W10348658	Washer suspension spring, 2-pack
11	W10469848	Washer spin basket
12	W10238301	Washer outer tub
13	W10006371	Washer tub seal assembly
14	W10215093	Washer drain pump filter
15	8533928	Appliance screw
16	W10780051	Washer suspension rod kit
17	W10405423	Ball
18	W10256551	Bushing
19	W10383573	Washer wire harness
20	8572540	Washer water-level pressure switch
21	W10005430	Clamp
22	8533943	Dryer screw
23	W10339879	Washer cable tie