


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW

Guía	Refacción	Descripción
1	WW01F01499	PANEL DE CONTROL
7	WG04L00423	PERILLA
8	WE1M361	BUTTON SWITCH
10	WW01F01483	TIMER Y SWITCH ARNES ENSAMBLE
10	WW02A00202	TIMER Y SWITCH ARNES ENSAMBLE
20	WG04A00079	CLIP
22	WE2X196	CLIP
23	WG04F04221	SWITCH , PTS
25	WE1M398	SHIELD CONTROL
27	WE26M00392	HARNESS CONTROL PANEL
34	WG04L00302	KNOB
34	WW01L00646	KNOB
34	WW01L00644	PERILLA ROTAT. G.E. ENS.
100	WE20M532	PANEL FRONT(WHITE) (WHITE)
101	WE18M20	FILTER
102	WG02L00217	INTERRUPTOR PUERTA
105	WE1M406	GRID
107	WE1M407	SLIDE
109	WG03L00198	SELLO PUERTA
111	WE14M00234	TRAP DUCT PAINTED
114	WW02L00145	SELLO PUERTA
120	WG04F03491	TOPE PUERTA
121	212D1080G41	CABLES
126	WW01A00537	SELLO ESPUMA
128	WW01A00538	SELLO ESPUMA
129	212D1080G41	GASKET (SEAL) 1 (SEAL)
202	212D1080G41	DOOR LINER
207	212D1080G41	OUTER DOOR W
213	WG04F00606	LATCH
220	WW02L00029	HINGE
401	WE20M205	TOP COVER T
404	WE20M533	SIDE PANEL
406	WE26M00394	HARNESS ELECT WITH TSTATS
408	WE20M534	CHASSIS BASE
420	WE1M194	KNOCKOUT

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW

Guía	Refacción	Descripción
422	WW02F00022	CORD CLIP
436	WE1M225	COVER KNOCKOUT
445	WE26M338	CORD SET
500	WE1M914	BLOWER CLAMP
501	WG04F03475	BLOWER WHEEL
502	WG04F00059	BLOWER HOUSING
504	WG04A00990	SOPORTE
506	WE14M41	PLATE ELBOW
510	WG04F03477	MOTOR & PULLEY
514	WE3M28	RESSORT TENDEUR
519	WG04A00026	BELT DRIVE
520	WG04F01582	MOTOR STRAP
524	WE1M915	BLOWER CLAMP
528	WE1X689	BAFFLE
529	WE12M00054	PULLEY
530	WE1M493	BRACKET, BELT SWITCH
532	WE13X182	STRAP MOTOR
544	WG04F01064	SWITCH INTER.
545	WE4M286	THERMOSTAT, BIASED
546	WW01F01490	THERMOSTAT
547	WG04F02270	THERMOSTATO
600	WW01F01467	DRUM ASM
620	WE14X20094	BAFFLE
623	WW01F01486	HARNES FCT THERMO
625	WG04F01880	HEATER ASSY (240V MTY)
626	WE19X20526	DEFLECTOR
630	WW02F00244	SOPORTE
630	WG02F02340	SOPORTE
630	WG02F02340	SHAFT & BRACKET ASM
636	WE02M00310	SPEED CLIP DRUM
637	WG04A00067	BUJE PARA SECADORA
640	WG04F00475	GROUND STRAP ASM
640	WW01A00443	GROUND STRAP ASM
640	WW02F00833	GROUND STRAP ASSEMBLY
707	WW02A00097	DRYER SCREW

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA PCKS443EB3WW

Guía	Refacción	Descripción
714	WE2M142	SCREW, FAN CLAMP
734	WE2M278	SCREW SHIELD
1101	WG04A00178	SCREW
1102	WG04A00380	SCREW
1102	WG04A00387	SCREW
1120	WE2M209	SCREW
1121	WW01A00001	SCREW
1127	WE1M280	SCREW
1132	WE2X194	SCREW (12)
1157	WW01A00456	SCREW #10