




Explosionado de partes
SIDE BY SIDE REFRIGERATOR
MODELO: WD1006S01






<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	2150304	Roller
3	W10297485	Screw
4	12477102	Roller
5	12477202	Axle, Roller
6	981125	Rivet, Roller
7	W10379525	Tube, Drain
8	W10900758	Bracket, Foot
9	W10141622	Brake, Roller
10	W10308751	Screw (Black)
11	W10498992	Valve, Inlet
12		Hinge, Top (Freezer)
	W10901054	Grey
13		Hinge, Top (Refrigerator) W10901049 Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10308489	Screw (Grey)
15		Hinge, Bottom (Freezer)
	W10249952	Grey
16		Hinge, Bottom (Refrigerator)
	W11084346	Grey
17		Closer, Door (Refrigerator)
	W10738911	Grey
18	W10141645	Screw
19	549193	Clamp, PowerCord
20	W10257323	Cover, Unit
21		Filler, Wrapper
	12587703AP	Grey
22		Grille
	W10713153	Grey
23	W10142234	Screw
24		Closer, Door (Freezer)
	W11084346	Grey
25	W10001250	Screw


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
26	W10279882	Tube, FilterInlet
27	W10279884	Tube, FilterOutlet
28	W10370680	Fitting, Drain
29	12957702	Lid, HVBox
30	W10887255	Control, Electronic
31		Cabinet (Not A Serviceable Part)
32	W10247993	Box, Control
33	2223388	Clip, AxleRetainer



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (NotAServiceable Part)
2	W10739358	Filter, Water
3	W10300482	Cover, Water Filter
4	W11175955	Assembly, AirDiffuser
5	W10457601	Cover, Air Diffuser
6	W10847849	Switch,Light
7	N/A	Assembly, TopLightWire
8	N/A	Trim,Light

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	N/A	Shield, Heat 10
	W10141632	Screw
11	W10271543	Connector, WaterTube
12	W10134764	Socket, Light
13	W10269099	Lens, TopLight
14	2155597	Socket,Light
15	W10366790	Reservoir
16	W11125625	Lamp, LED
17	W10269099	Lens, Light
18	W10280385	Thermistor

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10425252	Cover, Thermistor
20	W10844058	Housing, Water Filter
21	W10457603	Cover, AirFilter
22	W10352518	Socket, Light



Illus.

No. Part No. Description

- 1 W10508311 Shelf, SnackPan
- 2 W11084209 Trim,Handle
- 3 W10282883 Slide, Humidity
- 4 W10282880 Housing, Humidity

Illus.


No. Part No. Description

- 5 W10508334 Assembly, Cover
- 6 W10256846 Pan,Snack
- 7 2150304 Roller
- 8 W10628712 Axle,Roller

Illus.

No. Part No. Description


- 9 W10292504 Pan,Crisper
- 10 W10256854 Pan,Meat
- 11 W10773886 Shelf Assembly



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10527863	Assembly, Cover
3	W10773886	Shelf, Glass Upper
4	W10260437	Bimetal
5	W10773887	Shelf, Glass Lower
6	W10260983	Pan, Freezer (Also Order Item 7)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	2150304	Roller
8	W10628712	Axle, Roller
9	W11034724	Trim, Handle
10	W10847849	Switch, Light
11	2155597	Socket, Light
12	W11125625	Lamp, LED
13	W11032814	Switch, Rocker Arm

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10425252	Cover, Thermistor
15	W10269101	Lens
16	2155597	Socket, Light



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10774957	Ice Container (Complete)
2	W10693542	Assembly, Latch
3	2220458	Coupling, Bottom
4	W10258544	Shaft, Drive
5	W10754509	Spring, Coupling
6	W10293211	Assembly, Mounting Plate

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	2198628	Seal
8	W10291905	Gasket
9	2212370	Washer
10	W11117906	Motor, Dispenser
11	W10669473	Cover, Container
12	W10691248	Plate, Switch

Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10666871	Rocker, Switch
14	W10847849	Switch, Rocker Arm
15	W10749467	Filler, EPS, IM Cover
16	W10646076	Assembly, Wire Jumper Switch



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)
	LW10651576	Stainless
2	W10527271	Bin, GallonDoor
3	W10296816	Screw
4	W10296855	Bin, Shallow Door
5		Gasket, Door
	W10249916	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Handle
	W10678291	Brushed Aluminum
7	2200086	Thimble, Top
8	W10460893	Screw
9		Closer, Upper CamDoor
	W10257203	Grey
10	W10296804	Screw
11	W10888898	Bracket, Door Stop


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Nameplate
	W10511972	Grey
13	W10010140	Set Screw(Silver)
14		Cover, Door StopW10789147
		Grey
15	W10324760	Assembly, Utility Compartment



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door,Freezer(Includes Item 8 And Dispenser Front Parts)
	LW10835738	Stainless
2		Handle
	W10678291	Brushed Aluminum
3	2200086	Thimble,Top
4	W10296804	Screw
5	W10460893	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10296857	Bin, Door
7	W10296816	Screw
8		Gasket, Door
	W10249917	Grey
9		Closer,Upper CamDoor
	W10257206	Grey
10	W10247907	Bracket, DoorStop
11	W10010140	Set Screw(Silver)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Cover, Door StopW10632062 Grey
13	W10323148	Cover,Wire



Illus.**No. Part No. Description**


1	False Wall, Dispenser W10276228 Grey
2	Grate, Drip TrayW10276223 Grey
3	W10174827 Bracket, IceDoor
4	W10435760 Guide, Ice
5	W10205978 Motor,Dispenser
6	W10781993 Assembly,Separator
7	W10346124 Support, IceDoor

Illus.**No. Part No. Description**

8	4449745 Screw
9	Ring, Trim W10276227 Grey
10	N/A LED
11	W10758681 User InterfaceAssembly
12	Pad, Ice and WaterW10370594 Grey
13	Tray,Drip W10276224 Grey

Illus.**No. Part No. Description**

14	Cover, Front W10276229 White
15	W10386778 Assembly, Water Fitting
16	W10691730 Tube,Water



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	FanScroll
2	W10260421	Retainer, Fan Motor
3	W10260380	Duct, UpperAir
4		Bi-Metal Defrost (Not Serviced)
5	W10260378	Duct, FreezerAir
6	W10001260	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	2315549	Motor,Fan
8	2169142	Blade,Fan
9	W10240370	Gasket, Evaporator Cover
10	2176759	Grommet, Motor
11	W10369602	Clip,EvaporatorCover
12	W11050120	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10142292	Screw
14	W10388268	Cover, Evaporator
15	W10260382	Cover,Light
16	W11125625	Lamp,LED
17	W10352518	Socket, Light



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271541	Connector, Union
2	2225834	Blade, Fan
3	W10240365	Assembly, Condenser
4	W10142255	Screw
5	2212996	Strap, Bale 6
	W10171469	Screw
7	W10277958	Connector, Water
8	W10303521	Sleeve
9	W10142287	Bolt
10	W10197428	Device,Combination Start (Start Relayand Overload)
11	W10219381	Tube,Suction

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10248621	Clip,Condenser
13	W10350564	Capacitor
14	2325479	Tube,Process
15	2205813	Tie,Wire
16	2188822	Evaporator
17	2161324	Clip, DefrostHeater
18	W10909387	Motor, CondenserFan
19	W10713147	Tray,Evaporator
20	W10274575	Shield, Heat
21	W10771114	Drier
22	W10670174	Assembly, UnitWire
23	W10277704	Basepan

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10634815	Cord, Power
25	W10251467	Baffle,Air
26	W10495967	Heater, Defrost
27	W10284726	Cover, Unit Bottom
28	W10391109	Compressor (Also Order 876765 Tube Kit)
29	10835903	Grommet
30	W10815861	Clip, BottomCover
31	W10236396	Strap, Compressor
		REFRIGERANT CHARGE 5.0 oz. (R-134A)



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10237915	Bracket, WaterValve
2	W11130444	Assembly, IceMaker

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10691732	Tube, Water
4	W10341320	Assembly, WaterValve

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10141625	Screw
6		Fill Tube Assembly (Not Serviced)

Filtro de Agua

W10790813

