


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Literature Parts	*****
2a	Front Roller Right	W10327665
2b	Front Roller Left	W10327666
4	Roller (Rear)	W10327667
5	Screw	*****
6	Clip Grille	2155013
8	Housing water filter	W10121138
9	Shim	*****
10	Screw	*****
11	Water Filter	4396710
12	Hinge Top FC	W10287685
13	Hinge Top RC	W10287684
14	Screw	*****
15	Hinge cover	2203407B
16	Hinge bottom	W10251408
17	Cap water	2260502B
18	Screw	*****
19	Block housing support	2260519
20	Screw	*****
21	Filler wrapper	W10283960
22	Grille	W10283953
23	Screw	*****
24	Button water filter	2260503B
25	Screw	*****
26	Screw	*****
27	Screw	*****
28	Tube filter inlet	*****
29	Tube filter outlet	*****



Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
30	Drain fitting	2304888
31	Extension tube	*****
32	Clip drain tube	*****
33	Cover unit	2304898
34	Cabinet (not servicable)	*****
35	Hinge cover RC	2203408B
36	Screw	*****
37	Clamp service cord	*****
38	Screw	*****
39	Door closer lower cam	2155311
40	Screw	*****

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Liner (not a servicable part)	*****
2	Escutcheon, Meat Pan Control	*****
3	Slide Meat Pan Control	*****
4	Louver	2257741
5	Bracket Dual Crisper Light	*****
6	Screw	*****
7	Wire Harness, Dual Crisper	W10279385
8	Bracket Retainer	*****
9	Air Diffuser Assembly	W10151374
10	Air Diffuser Cover	2152019
11	Cover, Wiring	W10252495
12	Screw	*****
13	Socket	2162085
14	Reservoir	W10276792
15	Light Bulb	527949
16	Light Lens	2171706
17	Screw	*****

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00






Refrigerador Whirlpool WD2003D00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Shelf. Snack Pan	*****
2	Glass, cover	2179259
3	Cover, crisper	2209698
4	Trim, Pan	*****
5	Glass, cover	2179259
6	Deflector	*****
7	Trim, crisper pan	*****
8	Cover, Meat Pan	*****
9	Slide, Humidity Control	*****
10	Crisper Pan	2188653
11	Meat pan	2188654
12	Stud assembly	W10173126
13	Screw	*****
14	Housing, humidity control	*****
15	Stud assembly	W10173127
16	Screw	*****
17	Snack Pan	*****
18	Trim Handle	*****
19	Shelf assembly Spillguard	W10276348

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Liner (Not A Seviceable Part)	*****
3	Door, Ice Compartment	2171712
4	Shelf, Wire	W10318951
5	Clip, Air Duct	2315163
6	Support, Stud	*****
7	Freezer Bin	2309758
8	Switch, Rocker Arm	1115373
9	Screw	*****
10	Stud Assembly	2196206
11	Shelf, Wire	W10318952
12	Shelf, Top Comparment	*****
13	Light Lens	*****
14	Light Bulb	527949
15	Light Socket	*****
16	Stud, Rear	*****
17a	Slide Container, Left Side	1119237
17b	Slide Container, Right Side	1119293
18	Screw	*****
19	Screw	*****
20	Shelf, Wire	W10318953

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00

No.Illus.	DESCRIPCIÓN	No. de Parte
1	Bracket, Motor	W10284487
2	Motor, Dispenser	W10317991
3	Soleniod Assembly	2152713
4	Guide, Solenoid	2149100
5	Screw	*****
6	Wiring Assembly,Ice Dispenser	W10281336
7	Screw	*****
8	Coupling, Motor	W10169511
9	Screw	*****
10	Socket, Light	2162085
11	Ice Container	2196089
12	Spacer, Step	1119005
13	Spacer, Flat	1119007
14	Blade, Rotary A	W10278731
15	Blade, Rotary B	W10278732
16	Blade, Rotary C	W10278733
17	Washer, Plain	489235
18	Blade, Fixed	W10278727
19	Block, Blade	2157405
20	Roll Pin	489229
21	Auger	W10295082
22	Drum	2305377
23	Floating Baffle	2171682
24	Nut, Bearing	1119018
25	Control Arm	2155231
26	Spring, Return	1119020
27	Retainer Clip, Rod	1119021
28	Screw	*****



Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
29	Housing, Crusher	W10413658
30	Deflector, Ice	1119017
31	Washer, Plain	489235
32	Retainer Ring	489236
33	Front Cover, Ice Container	2171709
34	Light Bulb	527949
35	Light Lens, Dispenser	2171706
100	Ice Container (Complete)	W10312301

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Refrigerator Door	2309622US
2	Door, Compartment	2256101
3	Screw	*****
4	Shelf Bin	2187172
5	Endcap	2194272B
6	Door Gasket, Magnetic	2309653
7	Handle	W10285540
8	Thimble-Top	2308091
9	Clip	*****
10	Door Closer, Upper Cam	2182178
11	Screw	*****
12	Bracket, Door Stop	W10185567
13	Badge-Whirlpool	W10393264
14	Screw	*****
15	Trivet, Shelf	2309941
16	Screw	*****

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Freezer Door	W10415827
2	Handle	W10285540
3	Thimble-Top	2182181
4	Screw	*****
5	Endcap	2194272B
6	Trivet	2309717
7	Screw	*****
8	Door Gasket, Magnetic	2309654
9	Trim, Door Shelf	W10307489
10	Screw	*****
11	Screw	*****
12	Door Closer, Upper Cam	2182179
13	Bracket, Door Stop	W10185567

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Housing, Dispenser (Not Serviced)	*****
2	Screw	*****
3	Retainer, Levers	2194719
4	Spring, Torsion	2304772
5	Pin	2196195
6	Door, Ice	2180353
7	Door, Mechanism Assembly	2304355
8	Mechanism Delay	W10467899
9	Grille, Overflow	2206671B
10	Water Fitting Assembly	2304317
11	Lever, Ice Dispenser	W10152854
12	Guide, Ice	2180224
13	Lamp Holder	2180200
14	Switch	2162361
15	Bracket, Control	W10282667
16	Bulb, Light	3406124
17	Lever, Water Dispenser	W10152859
18	Switch Assembly	W10243995
19	Overlay, Front Cover	*****
20	Wire Assembly	W10281336
21	Front Cover Housing	*****
22	Screw	*****
23	Front Cover Assembly	W10153724
24	Spacer, Switch	625834
25	Strain Relief	2195051
26	Bracket, Dispenser	2304673

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00

No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Fan Blade	12825802
3	Condenser Assembly	W10222349
4	Screw	*****
5	Clip wire	2208280
6	Screw	*****
7	Clip Retaining	*****
14	Tube Suction	*****
15	Clip Condenser	2311725
17	Capacitor	2255130
18	Tube Condenser to Heat Loop	*****
19	TSD Start/Protect	2188831
21	Screw	*****
22	Evaporator	2188822
23	Clamp	2161324
24	Fan Motor	2188874
25	Tray Evaporator	1105523
26	Heat Shield	W10194474
27	Drier	W10177049
28	Compressor	W10151487
30	Unit mounting frame	2304903
31	Unit Harness (includes power cord)	2187605
32	Fan motor bracket	2181929
33	Heater defrost	2188174
34	Clip	489396
37	Screw	*****
39	Grommet	1100826
40	Screw	*****
41	Air Baffle	W10332806



Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
42	Clip, Heat Shield	2155547
43	Unit Cover, Bottom	2304898
44	Clip	489396
45	Unit, Mounting, Rail	W10207512
46	Screw	*****
47	Guard Fan	2260516
48	Strap	2263990
49	Screw	*****
50	Union	*****

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Fan Scroll	2182119
2	Retainer Fan motor	2155590
3	Air Scoop	*****
4	Bi-metal Defrost	W10225581
5	Air duct Freezer	W10166220
7	Fan motor	2315549
8	Fan blade	2169142
9	Gasket, Evaporator Cover	2304241
10	Fan Grommet	2176759
11	Duct, Ice Maker	*****
12	Harness Fan Evaporator (includes #4)	W10297480
13	Gasket Fan Scroll	2155788
14	Wire Tie	*****
16	Gasket	W10252476
17	Cover Evaporator	W10207508
18	Screw	*****
21	Screw	*****
22	Support R.S	2203595
23	Support L.S	2203596

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Control Box	W10159858
2	Mounting Bracket	2311611
3	Light Swicht	*****
4	Adaptive Defrost Board ADC	W10135900
5	Screw	*****
6	Thermostat Mech	2198202
7	Screw	*****
8	Cam Assembly	2182195
9	Bearing Body	1110560
10	Damper Control	2196062
11	Pivot Arm	1110559
12	Screw	*****
13	Light Socket	2162085
14	Tube Barrier, Thermostat	2196001
15	Light Bulb	527949
16	Control Box Harness	W10354806
17	Clip, Wiring	1115374
18	Screw	*****
19	Connecting Rod	2311631
20	Fastener, Push-On	489285
21	Thermostat, Knob	2311614
22	Control Knob	2311615
23	Spring washer	489203

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD2003D00





Refrigerador Whirlpool WD2003D00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Screw	***
2	Chute Water	2209774
3	Clip Fuse	628379
4	Tube Water	W10357069
5	Screw	***
6	Filter Valve Asm	2188708
7	Tube Clip	2208280
8	Cover	W10289690
9	Screw	***
10	Mold & Heater Assembly	628228
1	Cup water fill	W10122561
12	Ejector	627843
13	Stripper Ice, SXS	W10122563
14	Support Housing, Ice - Maker	2195914
15	Retainer Thermostat	2315522
16	Thermostat Wako	628397
17	Screw	***
18	Screw	***
19	Shut off arm	2304354
20	Bracket	628320
21	Module Assembly	626681
22	Screw	***
23	Mid-Torque Motor Assy	626683
100	Complete Icemaker Assembly	W10190969