


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Front Roller	2150304
4	Axle, Roller	12477102
5	Roller (Rear)	12477202
6	Rivet, Roller	W10285005
7	Extension, Tube	W10284538
8	Bracket, Foot	W10257186
9	Foot, Braket	W10141622
10	Screw	
11	Valve, Inlet	W10498992
12	Hinge, Top (FC) Apollo Grey	W10249922
13	Hinge, Top (RC) Apollo Grey	W10249925
14	Screw	
15	Bottom Hinge (FC)	W10249943
16	Bottom Hinge (RC)	W10492501
17	Door Closer (RC)	W10412764
18	Screw	
19	Clamp, Service Cord	
20	Cover, Unit	W10257325
21	Filler, Wrapper	12587703AP
22	Grille	W10511269
23	Screw	
24	Door Closer (FC)	W10257200
25	Screw	
26	Tube, Filter Inlet	W10279882
27	Tube, Filter Outlet	W10279884
28	Drain Fitting	W10370680
29	Cover	12957702
30	Elec. Control	W10268622

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00






Refrigerador Whirlpool WD6075A00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Liner (No Servicable)	
2	Escutcheon, Meat Pan Control	W10260988
3	Slide, Meat Pan Control	W10260989
4	Air Diffuser Assembly	W10251495
5	Air Diffuser Cover	W10260409
6	Switch Rocker Arm	C3680314
7	Wire Assy, Top Light	W10253300
8	Trim, Light	W10280178
9	Shield, Heat	2223680
10	Screw	
11	Light Bulb	2326255
12	Socket, Light	2162085
13	Lens, Top Light	W10280420
14	Socket, Light	2162085
15	Reservoir	W10366790
16	Light Bulb	W10311505
17	Lens, Light	W10269099
18	Thermistor	W10316760
19	Air Filter Housing	W10342986
20	Air Filter	W10315189
21	Air Filter Cover	W10340015
22	Housing, Water Filter	W10238123
23	Cover, Thermistor	W10425252
24	Connector, 1/4 X 5/16	W10271543
25	Cover, Water Filter	W10260405
26	Water Filter	W10217316

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Shelf, Snack Pan	W10290493
2	Trim, Snack Pan	W10256775
3	Slide, Humidity	W10282883
4	Housing, Humidity	W10282880
5	Cover, Assy	W10282541
6	Snack Pan	W10256770
7	Roller	W10278139
8	Axle, Roller	W10257246
9	Crisper Pan	W10278653
10	Meat Pan	W10256774
11	Trim, Crisper Pan	W10309637
12	Trim, Meat Pan	W10309638
13	Shelf Assy	W10495620

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Liner (No Servicable)	
2	Cover Assy	W10269181
3	Shelf, Glass Upper	W10238483
4	Thermistor	W10316760
5	Shelf, Glass Lower	W10269145
6	Pan Freezer	W10260985
7	Cover, Thermistor	W10425252
8	Switch, Rocker Arm	1115373
9	Trim, Handle	W10260986
10	Slide Container Left Side	1119237
	Slide Container Right Side	1119293
11	Screw	
12	Roller	W10278139
13	Axle, Roller	W10257246

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Bracket, Motor	W10276181
2	Motor, Dispenser	W10317991
3	Solenoid Assembly	2152713
4	Guide, Solenoid	2149100
5	Wiring Assembly, Ice Dispenser	W10298085
6	Screw	
7	Coupling, Motor	W10169511
8	Screw	
9	Socket, Light	2162085
10	Ice, Container	W10276184
11	Spacer, Step	W10189661
12	Spacer, Flat	W10189658
13	Blade, Rotary	W10278731
14	Blade, Rotary	W10278732
15	Blade, Rotary	W10278733
16	Washer, Plain	W10189660
17	Blade, Fixed	W10181990
18	Block, Blade	W10189708
19	Roll, Pin	489229
20	Auger	W10295082
21	Drum	2305377
22	Floating, Baffle	2171682
23	Nut, Bearing	1119018
24	Control Arm	2155231
25	Spring Return	1119020
26	Retainer Clip, Rod	1119021
27	Screw	
28	Housing, Crusher	W10185018



Refrigerador Whirlpool WD6075A00

No. Ilus.	DESCRIPCIÓN	No. de Parte
29	Deflector, Ice	1119017
30	Washer, Plain	489234
31	Retainer Ring	489236
32	Front Cover, Ice Container	W10276185
33	Ice Door	W10189202
34	Light Bulb	W10311505
35	Light Lens, Dispenser	2171706
36	Spacer - Crusher Housing	W10138206
37	Coupling, Auger Ice Container	983668

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Refrigerator Door	W10287390
2	Door Bin	W10321304
3	Screw	
4	Door Bin Shallow	W10296855
5	Door Gasket, Magnetic	W10249916
6	Handle	W10274730
7	Thimble-Top	2200086
8	Stud, Handle	W10460893
9	Door Closer, Upper Cam	W10257203
10	Screw	
11	Bracket, Door Stop Chrome	W10367462
12	Nameplate	W10393264
13	Set Screw	W10010140
14	Cover, Door Stop	W10257218
15	Mantequillero (Utility Bin)	W10324760

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00






Refrigerador Whirlpool WD6075A00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Freezer Door	W10290911
2	Handle	W10274730
3	Thimble-Top	2200086
4	Screw	
5	Stud, Handle	W10460893
6	Door Bin	W10296857
7	Screw	
8	Door Gasket, Magnetic	W10249917
9	Door Closer, Upper Cam	W10257206
10	Bracket, Door Stop	W10247907
11	Set Screw	W10010140
12	Chute Adapter	W10284556
13	Filler, Chute	W10283476
14	Half Bin Housing	W10314925
15	Bin, Upper	W10316652
16	Cover, Door Stop	W10257223

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Housing Dispenser (No Serviciable)	
2	Grate, Drip Tray	W10276223
3	Bracket, Ice Door	W10174827
4	Chute, Door	W10277032
5	Motor, Ice Door	W10205978
6	Ice Door Assy	W10493172
7	Support, Ice Door	W10346124
8	Screw	
9	Trim Ring	W10276227
10	Spigot	
11	Electronic Control Assy	W10326983
12	Pad, Ice & Water	W10370594
13	Tray, Housing	W10276224
14	Front Cover	W10254285

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Connector, 5/16	W10271541
2	Fan, Blade	12825802
3	Condenser Assy	W10276899
5	Clip	2223314
7	Strap, Compressor	W10271543
8	Sleeve	W10303521
10	Start Device Combination Relay & Overload	W10260370
11	Tube Suction	W10219381
12	Clip, Condenser	W10248621
13	Capacitor	W10350564
14	Process Tube	2325479
15	Strap	2205813
16	Evaporator	2188822
17	Clamp	2161324
18	Fan, Motor	W10312647
19	Tray, Evaporator	W10238584
20	Heat Shield	W10274575
21	Drier Service	W10177049
22	Harness, Wiring Water Valve/Diode	W10209479
23	Support Plate, Compressor	W10277704
24	Power Cord	2310234
25	Air Baffle	W10251467
26	Heater, Defrost	W10495967
27	Unit Cover, Bottom	W10278140
28	Compressor	W10260368
29	Grommet Service	10835903
30	Clip	W10296661

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Bracket, Valve	W10237915
2	Clip, Fuse	628379
3	Water, Tube	W10175644
4	Screw	
5	Filter Valve Asm	W10238102
6	Screw	
7	Cover	W10289690
8	Screw	
9	Mold & Heater Assembly	W10300025
10	Cup, Water Fill	W10435665
11	Ejector	W10318914
12	Ice Stripper	W10122563
13	Support	2195914
14	Retainer, Thermostat	2315522
15	Thermostat	2321258
16	Screw	
17	Shut Off Arm	2304354
18	Harness, Wiring	W10242433
19	Module Assembly	626691
20	Screw	
21	Motor (No Serviciable)	
	Complete Icemaker	W10300022

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6075A00





Refrigerador Whirlpool WD6075A00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Fan Scroll	W10251462
2	Retainer, Fan Motor	W10260421
3	Clip, Mounting	W10369602
4	Bi-Metal, Defrost	W10260437
5	Air Duct, Freezer	W10251474
6	Screw, Evap Cover	
7	Fan Motor	W10312647
8	Fan Blade	2169142
9	Gasket, Evaporator Cover	W10240370
10	Fan, Grommet	2176759
11	Harness, Fan Evaporator	W10253282
12	Cover, Evaporator	W10388268