

# Whirlpool

SERVICE

CENTRO DE SOLUCIONES



LO ORIGINAL MARCA DIFERENCIA


**EXPLOSIONADO DE PARTES**  
**-REFRIGERADOR-**  
**MODELO| WD6575S00**

**acros**


**Whirlpool**  
CORPORATION

**MAYTAG**


**KitchenAid**



<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Literature Parts Use & Care Guide	- 1	---- No serviceable
2	Roller	2	2150304
3	Screw	-	----
4	Roller	2	12477102
5	Axle, Roller	2	12477202
6	Rivet, Roller	2	981125
7	Tube, Drain	1	W10379525
8	Bracket, Foot	2	W10900758
9	Brake, Roller	2	W10141622
10	Screw	-	----
11	Valve, Inlet	1	W10498992
12	Hinge, Top (Freezer)	1	W10901054
13	Hinge, Top (Refrigerator)	1	W10901049
14	Screw	-	----
15	Hinge, Bottom (Freezer)	1	W10249952
16	Hinge, Bottom (Refrigerator)	1	W10492501
17	Closer, Door (Refrigerator)	1	W10738911
18	Screw	-	----
19	Clamp, Power Cord	1	6-919724
20	Cover, Unit	1	W10257325
21	Filler, Wrapper	2	12587703AP
22	Grille	1	W10713153
23	Screw	-	----
24	Closer, Door (Freezer)	1	W10770893
25	Screw	-	----
26	Tube, Filter Inlet	1	W10279882
27	Tube, Filter Outlet	1	W10279884
28	Fitting, Drain	1	W10370680
29	Lid, HV Box	1	12957702
30	Control, Electronic	1	W10516800
31	Cabinet	-	No serviceable
32	Box, Control	1	W10247993



<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Liner	-	No serviceable
2	Filter, Water	1	W10790813
3	Cover, Water Filter	1	W10300482
4	Assembly, Air Diffuser	1	W11175955
5	Cover, Air Diffuser	1	W10457601
6	Switch, Light	1	W10656773
7	Assembly, Top Light Wire	1	W10253300
8	Trim, Light	1	W10280178
9	Shield, Heat	1	2223680
10	Screw	-	----
11	Connector, Water Tube	1	W10271543
12	Socket, Light		W10191429
13	Lens, Top Light	1	W10280420
14	Socket, Light	1	2162085
15	Reservoir	1	W10366790
16	Lamp, LED	1	2326255
17	Lens, Light	1	W10269099
18	Thermistor	1	W10280385
19	Cover, Thermistor	1	W10425252
20	Housing, Water Filter	1	W10844058
21	Cover, Air Filter	1	W10457603






## Refrigerador Whirlpool WD6575S00

<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Shelf, Snack Pan	1	W10463648
2	Trim, Handle	1	W10256775
3	Slide, Humidity	1	W10282883
4	Housing, Humidity	1	W10282880
5	Assembly, Cover	1	W10463650
6	Pan, Snack	1	W10256770
7	Roller	2	W10628713
8	Axle, Roller	1	W10628712
9	Pan, Crisper	1	W10278653
10	Pan, Meat	1	W10256774
11	Trim, Handle	1	W10309637
12	Assembly, Shelf	3	W10773888










## Refrigerador Whirlpool WD6575S00

<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Liner	-	No serviceable
2	Assembly, Cover	1	W10463653
3	Shelf, Glass Upper	2	W10773890
4	Thermistor	1	W10280386
5	Shelf, Glass Lower	1	W10773892
6	Pan, Freezer	1	W10260985
7	Roller	2	W10628713
8	Axle, Roller	2	W10628712
9	Trim, Handle	1	W10260986
10	Switch, Rocker Arm	1	W10656771
11	Socket, Light	1	2162085
12	Lamp, LED	4	2311792
13	Switch, Rocker Arm	1	W10656772
14	Cover, Thermistor	1	W10425252
15	Lens	1	W10269101
16	Socket, Light	1	2155597






## Refrigerador Whirlpool WD6575S00

<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Ice Container (Complete)	1	W10774957
2	Assembly, Latch	1	W10693542
3	Coupling, Bottom	1	2220458
4	Shaft, Drive	1	W10258544
5	Spring, Coupling	1	W10754509
6	Assembly, Mounting Plate	1	W10293211
7	Seal	1	2198628
8	Gasket	1	W10291905
9	Washer	1	2212370
10	Motor, Dispenser	1	W10225313
11	Cover, Container	1	W10287594


Refrigerador Whirlpool WD6575S00






## Refrigerador Whirlpool WD6575S00

<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Door, Refrigerator	1	W10651576
2	Bin, Gallon Door	2	W10527271
3	Screw	-	----
4	Bin, Shallow Door	2	W10296855
5	Gasket, Door	1	W10249916
6	Handle	1	W10678291
7	Thimble, Top	1	2200086
8	Screw	-	----
9	Closer, Upper Cam Door	1	W10257203
10	Screw	-	----
11	Bracket, Door Stop	1	W10888898
12	Nameplate	1	W10511972
13	Screw	-	----
14	Cover, Door Stop	1	W10789147
15	Assembly, Utility Compartment	1	W10324760



<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Door, Freezer	1	W10762965
2	Handle	1	W10678291
3	Thimble, Top	1	2200086
4	Screw	-	----
5	Screw	-	----
6	Bin, Door	3	W10296857
7	Screw	-	----
8	Gasket, Door	1	W10249917
9	Closer, Upper Cam Door	1	W10257206
10	Bracket, Door Stop	1	W10247907
11	Set Screw	-	----
12	Cover, Door Stop	1	W10632062
13	Pin, Door	1	2198634
14	Spring, Door	1	2198635
15	Cover, Emitter	1	W10258502
16	Board, Emitter Circuit	1	W10518659
17	Cover, Receiver	1	W10363396
18	Board, Receiver Circuit	1	W10518658
19	Door, Emitter	1	W10258520
20	Slide, Icemaker Shut Off	1	W10258540
21	Harness, Emitter and Receiver	1	W10411699









## Refrigerador Whirlpool WD6575S00

<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Housing, Dispenser	-	No serviceable
2	Grate, Drip Tray	1	W10276223
3	Bracket, Ice Door	1	W10174827
4	Guide, Ice	1	W10435760
5	Motor, Dispenser	1	W10205978
6	Assembly, Separator	1	W10781993
7	Support, Ice Door	1	W10346124
8	Screw	-	----
9	Ring, Trim	1	W10276227
10	Assembly, LED	1	W10238083
11	Assembly, User Interface	1	W10714048
12	Pad, Ice and Water	2	W10370594
13	Tray, Drip	1	W10276224
14	Cover, Front	1	W10276229
15	Assembly, Water Fitting	1	W10386778




<b>No. lustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Fan Scroll	1	W10251462
2	Retainer, Fan Motor	1	W10260421
3	Duct, Upper Air	1	W10550199
4	Bi-Metal, Defrost	-	W10260437
5	Duct, Freezer Air	1	W10260378
6	Screw	-	----
7	Motor, Fan	1	2315549
8	Blade, Fan	1	2169142
9	Gasket, Evaporator Cover	2	W10240370
10	Grommet, Motor	2	2176759
11	Clip, Evaporator Cover	4	W10369602
12	Assy Evaporator Fan Wire	1	W11050120
13	Screw	-	----
14	Cover, Evaporator	1	W10388268
15	Cover, Light	1	W10260382
16	Lamp, LED	-	2311792
17	Socket, Light	1	2162085



<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Connector, Union	1	W10271541
2	Blade, Fan	1	2225834
3	Condenser	1	W10276899
4	Screw	-	----
5	Strap, Bale	1	2212996
6	Screw	-	----
7	Connector, Water	1	W10277958
8	Sleeve	1	W10303521
9	Bolt	1	W10142287
10	Device, Combination Start	1	W10197428
11	Tube, Suction	1	W10219381
12	Clip, Condenser	4	W10248621
13	Capacitor	1	W10350564
14	Tube, Process	1	2325479
15	Tie, Wire	1	2205813
16	Evaporator	1	2188822
17	Clip, Defrost Heater	2	2161324
18	Motor, Condenser Fan	1	W10909387
19	Tray, Evaporator	1	W10703218
20	Shield, Heat	1	W10274575
21	Drier	1	W10771114
22	Assembly, Unit Wire	1	W10670174
23	Basepan	1	W10277704
24	Cord, Power	1	W10634815
25	Baffle, Air	1	W10251467
26	Heater, Defrost	1	W10495967
27	Cover, Condenser (Bottom)	1	W10278140
28	Compressor	1	W10200250
29	Grommet	4	10835903
30	Clip, Bottom Cover	2	W10815861
31	Strap, Compressor	2	W10236396

Refrigerador Whirlpool WD6575S00







## Refrigerador Whirlpool WD6575S00

<b>No. Ilustración</b>	<b>Descripción</b>	<b>Piezas</b>	<b>No. Parte</b>
1	Bracket, Water Valve	1	W10237915
2	Clip, Thermal Fuse	1	628379
3	Tube, Water	1	W10238092
4	Screw	-	----
5	Assembly, Water Valve	1	W10341320
6	Screw	-	W10001240
7	Cover, Icemaker	1	W10251088
8	Screw	-	----
9	Assembly, Mold and Heater	1	W10251081
10	Assembly, Fill Tube	1	W10347034
11	Ejector	1	W10318644
12	Stripper, Ice	1	W10747731
13	Support, Housing	1	2194712
14	Retainer, Thermostat	2	2315522
15	Thermostat	1	2321258
16	Screw	-	----
17	Bracket, Mounting	1	W10747726
18	Harness, Wiring	1	W10242365
19	Assembly, Module and Motor	1	626691
20	Screw	-	----
21	Motor	-	No serviceable
-	Complete Icemaker Assembly	1	W10122576