


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Front Roller	2150304
4	Roller (Rear)	12477102
5	Axle, Roller	12477202
6	Rivet, Roller	W10285005
8	Bracket, Foot	W10257186
9	Foot, Brake	W10141622
11	Valve, Inlet	W10238100
12	Hinge, Top (FC) Apollo Grey	W10249922
13	Hinge, Top (RC) Apollo Grey	W10249925
14	Screw	***
15	Bottom Hinge (FC) Apollo Grey	W10249943
16	Bottom Hinge (RC) Apollo Grey	W10257209
17	Door Closer (RC) Apollo Grey	W10257197
18	Screw	***
19	Clamp, Service Cord	W10279839
20	Cover, Unit	W10257325
21	Filler, Wrapper Apollo Grey	12587703AP
22	Grille Midnight Grey	W10257234
23	Screw	***
24	Door Closer (FC) Midnight Grey	W10257200
25	Screw	***
26	Tube, Filter Inlet	W10277956
27	Tube, Filter Outlet	W10277957
28	Drain Fitting	***
29	Extension Tube	***
30	Cabinet (Not A Serviceable Part)	***
31	Control Elek Minotaur	W10268630
32	Cover	12957702

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01






Refrigerador Whirlpool WD6971Y01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Liner (Not A Serviceable Part)	***
2	Escutcheon, Meat Pan Control	W10260988
3	Slide, Meat Pan Control	W10260989
4	Air Diffuser Assembly	W10251495
5	Air Diffuser Cover	W10260409
6	Switch Rocker Arm	C3680314
7	Reservoir	W10366790
8	LED Light Assy	W10279030
9	Thermistor	W10316760
10	Air Filter Housing	W10342986
11	Air Filter	W10315189
12	Air Filter Cover	W10340015
13	Housing, Water Filter	W10238123
14	Cover, Thermistor	W10356630
15	Connector, 1/4 x 5/16	W10271543
16	Cover, Water Filter	W10260405
17	Water Filter	W10295370

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Shelf, Snack Pan	W10290493
2	Cover, Assy	W10282541
3	Snack Pan Also Order 4 & 5	W10256800
4	Roller	W10278139
5	Axle, Roller	W10257246
6	Crisper Pan Also Order 4 & 5	W10256801
7	Meat Pan Also Order 4 & 5	W10256802
8	Shelf Assy	W10276663

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Liner (Not A Seviceable Part)	***
2	Cover Assy	W10269181
3	Shelf, Glass Upper	W10269184
4	Thermistor	W10280386
5	Shelf, Glass Lower	W10278132
6	Pan, Freezer Upper	W10256823
7	Roller	W10278139
8	Axle, Roller	W10257246
9	Pan, Freezer Lower	W10256827
10	Switch, Rocker Arm	1115373
11	Pin	2198634
12	Spring	2198635
13	Cover, Emitter	W10258502
14	P.C. Board Emitter	W10180607
15	Cover, Receiver	W10258510
16	P.C. Board Receiver	W10296530
17	Cover, Thermistor	W10356630
18	Door Emmiter	W10258520
19	Slide, Ice Maker Shut Off	W10258540
20	Leds	W10279030

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Ice Bin Assy	W10353207
2	Ice Bin	W10286610
3	Auger	W10178230
4	Washer	2258220
5	Spacer, Step	W10341948
6	Cover, Crusher	W10178232
7	Blade, Rotary	W10341944
8	Spacer, Step	W10341948
9	Blade, Fixed	2257020
10	Blade, Rotary	W10341943
11	Block, Blade	W10178238
12	Roll Pin	W10166878
13	Blade, Rotary	W10341942
14	Washer, Plain	489235
15	Washer, Coupling	2198661
16	Coupling, Upper	2220457
19	Latch, Assy	W10258552
20	Coupling, Lower	2220458
21	Drive Shaft	W10258544
22	Spring, Coupling	2198607
23	Mounting Plate Assembly	W10293211
24	Seal	2198628
25	Gasket	W10291905
26	Washer	2212370
27	Dispenser, Motor	2323603
28	Gasket	W10166854
29	Motor Box Assy	W10238131
30	Cover, Container	W10287594

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Refrigerator Door	W10287399
2	Door Compartment Assembly	W10336573
3	Screw	***
4	Door Bin, Shallow	W10335221
5	Door Gasket, Magnetic Apollo Grey	W10249916
6	Handle Stainless/Satina	W10274730
7	Thimble-Top	2200087
8	Stud, Handle	W10170540
9	Door Closer, Upper Cam Apollo Grey	W10257203
10	Screw	***
11	Bracket, Door Stop Chrome	W10247909
12	Badge Whirlpool	W10393264
13	Set Screw Chrome	W10010140
14	Door Bin, Gallon	W10335219
15	Door, Compartment	W10336570
16	Cover, Door Stop Midnight Grey	W10257218

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01






Refrigerador Whirlpool WD6971Y01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Freezer Door Mono Stainless	W10290925
2	Handle Stainless/Satina	W10274730
3	Thimble-Top	2200087
4	Screw	***
5	Stud, Handle	W10170540
6	Door Bin	W10335217
7	Screw	***
8	Door Gasket, Magnetic Apollo Grey	W10249917
9	Door Closer, Upper Cam Apollo Grey	W10257206
10	Bracket, Door Stop Chrome	W10247907
11	Set Screw Chrome	***
12	Cover, Door Stop Midnight Grey	W10257223

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Housing, Dispenser (Not Serviced)	***
2	Grate, Drip Tray	W10276209
3	Bracket, Ice Door	W10174827
4	Guide, Ice	W10339578
5	Motor, Ice Door	W10205978
6	Door, Ice	W10317279
7	Support, Ice Door	W10346124
8	Screw	***
9	Trim Ring Chromium Frost	W10254252
10	Spigot	2305235
11	Electronic Control Assy	W10254278
12	Pad, Ice & Water Midnight Grey	W10290362
13	Tray, Housing Satina	W10276225
14	Front Cover Silver	W10254266

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Connector, 5/16	W10271541
2	Fan, Blade	12825802
3	Condenser Assy	W10276899
4	Screw	*****
5	Clip	W10204187
6	Screw	*****
7	Connector, 1/4	W10277958
8	Sleeve	W10303521
9	Screw	*****
10	Start Device Combination Relay	W10197428
11	Tube Suction	W10219381
12	Clip Condenser	W10248621
13	Capacitor	2264017
14	Process Tube	2325479
15	Strap	2205813
16	Evaporator	2188822
17	Clamp	2161324
18	Fan, Motor	2188874
19	Tray, Evaporator	W10238584
20	Heat Shield	W10274575
21	Drier	W10177049
22	Harness, Wiring Water Valve/Diode	W10209479
23	Support Plate, Compressor	W10277704
24	Power Cord	2310234
25	Air Baffle	W10251467
26	Heater, Defrost	W10251470
27	Clip	2304287
28	Compressor (Includes 10, 13, 21, & 29)	W10200250



Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
29	Grommet	10835903
30	Clip, Heat Shield	2155547
31	Unit Cover, Bottom	W10278140
32	Clip	W10296661
33	LED Power Supply	W10356137

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Bracket, Valve	W10237915
2	Clip, Fuse	***
3	Water Tube	W10238092
4	Screw	***
5	Filter Valve Asm	W10258562
6	Screw	***
7	Cover	W10251088
8	Screw	***
9	Mold & Heater Assembly	W10251081
10	Fill Tube Assy	W10347034
11	Ejector	W10318644
12	Ice Striper	W10251078
13	Support	2194712
14	Retainer, Thermostat	2315522
15	Thermostat	2321258
16	Screw	***
17	Bracket, Mounting	W10251080
18	Harness, Wiring	W10242365
19	Module Assembly	626691
20	Screw	***
21	Motor	626683
100	Complete Icemaker Assembly	W10122576

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y01





Refrigerador Whirlpool WD6971Y01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Fan Scroll	W10251462
2	Retainer, Fan Motor	W10260421
3	Air Duct, Upper	W10223286
4	Bi-Metal, Defrost	W10260437
5	Air Duct Freezer	W10260378
6	Screw	***
7	Fan Motor	2315549
8	Fan Blade	2169142
9	Gasket, Evaporator Cover	W10240370
10	Fan Grommet (2)	2176759
11	Clip, Mounting	W10274578
12	Harness, Fan Evaporator	W10242409
13	Screw, Evap Cover	***
14	Cover, Evaporator	W10239739
15	Clip, Air Duct	***