


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|----------------------------------|---------------------|
| 1 | Literature Parts | *** |
| 2 | Front Roller | 2150304 |
| 3 | Screw | *** |
| 4 | Roller (Rear) | 12477102 |
| 5 | Axle, Roller | 12477202 |
| 6 | Rivet, Roller | W10285005 |
| 8 | Bracket, Foot | W10257186 |
| 9 | Foot, Brake | W10141622 |
| 11 | Valve, Inlet | W10238100 |
| 12 | Hinge, Top (FC) Apollo Grey | W10249922 |
| 13 | Hinge, Top (RC) Apollo Grey | W10249925 |
| 15 | Bottom Hinge (FC) Apollo Grey | W10249943 |
| 16 | Bottom Hinge (RC) Apollo Grey | W10257209 |
| 17 | Door Closer (RC) Apollo Grey | W10257197 |
| 19 | Clamp, Service Cord | W10279839 |
| 20 | Cover, Unit | W10257325 |
| 21 | Filler, Wrapper Apollo Grey | 12587703AP |
| 22 | Grille Midnight Grey | W10257234 |
| 24 | Door Closer (FC) Midnight Grey | W10257200 |
| 26 | Tube, Filter Inlet | W10277956 |
| 27 | Tube, Filter Outlet | W10277957 |
| 28 | Drain Fitting | *** |
| 29 | Extension Tube | *** |
| 30 | Cabinet (Not A Serviceable Part) | *** |
| 31 | Control Elek Minotaur | W10268630 |
| 32 | Cover | 12957702 |

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02






Refrigerador Whirlpool WD6971Y02

| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|--------------------------------|---------------------|
| 1 | Liner (Not A Serviceable Part) | *** |
| 2 | Escutcheon, Meat Pan Control | W10260988 |
| 3 | Slide, Meat Pan Control | W10260989 |
| 4 | Air Diffuser Assembly | W10251495 |
| 5 | Air Diffuser Cover | W10260409 |
| 6 | Switch Rocker Arm | C3680314 |
| 7 | Reservoir | W10366790 |
| 8 | LED Light Assy | W10279030 |
| 9 | Thermistor | W10316760 |
| 10 | Air Filter Housing | W10342986 |
| 11 | Air Filter | W10315189 |
| 12 | Air Filter Cover | W10340015 |
| 13 | Housing, Water Filter | W10238123 |
| 14 | Cover, Thermistor | W10356630 |
| 15 | Connector, 1/4 x 5/16 | W10271543 |
| 16 | Cover, Water Filter | W10260405 |
| 17 | Water Filter | W10295370 |

Refrigerador Whirlpool WD6971Y02






Refrigerador Whirlpool WD6971Y02

| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|------------------------------|---------------------|
| 1 | Shelf, Snack Pan | W10290493 |
| 2 | Cover, Assy | W10282541 |
| 3 | Snack Pan Also Order 4 & 5 | W10256800 |
| 4 | Roller | W10278139 |
| 5 | Axle, Roller | W10257246 |
| 6 | Crisper Pan Also Order 4 & 5 | W10256801 |
| 7 | Meat Pan Also Order 4 & 5 | W10256802 |
| 8 | Shelf Assy | W10276663 |

Refrigerador Whirlpool WD6971Y02









Refrigerador Whirlpool WD6971Y02

| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|-------------------------------|---------------------|
| 1 | Liner (Not A Seviceable Part) | *** |
| 2 | Cover Assy | W10269181 |
| 3 | Shelf, Glass Upper | W10269184 |
| 4 | Thermistor | W10280386 |
| 5 | Shelf, Glass Lower | W10278132 |
| 6 | Pan, Freezer Upper | W10256823 |
| 7 | Roller | W10278139 |
| 8 | Axle, Roller | W10257246 |
| 9 | Pan, Freezer Lower | W10256827 |
| 10 | Switch, Rocker Arm | 1115373 |
| 11 | Pin | 2198634 |
| 12 | Spring | 2198635 |
| 13 | Cover, Emitter | W10258502 |
| 14 | P.C. Board Emitter | W10180607 |
| 15 | Cover, Receiver | W10258510 |
| 16 | P.C. Board Receiver | W10296530 |
| 17 | Cover, Thermistor | W10356630 |
| 18 | Door Emmiter | W10258520 |
| 19 | Slide, Ice Maker Shut Off | W10258540 |
| 20 | Leds | W10279030 |

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|-------------------------|---------------------|
| 1 | Ice Bin Assy | W10353207 |
| 2 | Ice Bin | W10286610 |
| 3 | Auger | W10178230 |
| 4 | Washer | 2258220 |
| 5 | Spacer, Step | W10341948 |
| 6 | Cover, Crusher | W10178232 |
| 7 | Blade, Rotary | W10341944 |
| 8 | Spacer, Step | W10341948 |
| 9 | Blade, Fixed | 2257020 |
| 10 | Blade, Rotary | W10341943 |
| 11 | Block, Blade | W10178238 |
| 12 | Roll Pin | W10166878 |
| 13 | Blade, Rotary | W10341942 |
| 14 | Washer, Plain | 489235 |
| 15 | Washer, Coupling | 2198661 |
| 16 | Coupling, Upper | 2220457 |
| 19 | Latch, Assy | W10258552 |
| 20 | Coupling, Lower | 2220458 |
| 21 | Drive Shaft | W10258544 |
| 22 | Spring, Coupling | 2198607 |
| 23 | Mounting Plate Assembly | W10293211 |
| 24 | Seal | 2198628 |
| 25 | Gasket | W10291905 |
| 26 | Washer | 2212370 |
| 27 | Dispenser, Motor | 2323603 |
| 28 | Gasket | W10166854 |
| 29 | Motor Box Assy | W10238131 |
| 30 | Cover, Container | W10287594 |

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|-------------------------------------|---------------------|
| 1 | Refrigerator Door (Includes Item 5) | W10365609 |
| 2 | Door Compartment Assembly | W10336573 |
| 3 | Screw | *** |
| 4 | Door Bin, Shallow | W10335221 |
| 5 | Door Gasket, Magnetic Apollo Grey | W10249916 |
| 6 | Handle Stainless/Satina | W10274730 |
| 7 | Thimble-Top | 2200087 |
| 8 | Stud, Handle | W10170540 |
| 9 | Door Closer, Upper Cam Apollo Grey | W10257203 |
| 10 | Screw | *** |
| 11 | Bracket, Door Stop Chrome | W10247909 |
| 12 | Badge Whirlpool | W10393264 |
| 13 | Set Screw Chrome | W10010140 |
| 14 | Door Bin, Gallon | W10335219 |
| 15 | Door, Compartment | W10336570 |
| 16 | Cover, Door Stop Midnight Grey | W10257218 |

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|------------------------------------|---------------------|
| 1 | Freezer Door | W10365684 |
| 2 | Handle Stainless/Satina | W10274730 |
| 3 | Thimble-Top | 2200087 |
| 4 | Screw | *** |
| 5 | Stud, Handle | W10170540 |
| 6 | Door Bin | W10335217 |
| 7 | Screw | *** |
| 8 | Door Gasket, Magnetic Apollo Grey | W10249917 |
| 9 | Door Closer, Upper Cam Apollo Grey | W10257206 |
| 10 | Bracket, Door Stop Chrome | W10247907 |
| 11 | Set Screw Chrome | *** |
| 12 | Cover, Door Stop Midnight Grey | W10257223 |

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|-----------|-----------------------------------|--------------|
| 1 | Housing, Dispenser (Not Serviced) | *** |
| 2 | Grate, Drip Tray | W10276209 |
| 3 | Bracket, Ice Door | W10174827 |
| 4 | Guide, Ice | W10339578 |
| 5 | Motor, Ice Door | W10205978 |
| 6 | Door, Ice | W10317279 |
| 7 | Support, Ice Door | W10346124 |
| 8 | Screw | *** |
| 9 | Trim Ring Chromium Frost | W10254252 |
| 10 | Spigot | 2305235 |
| 11 | Electronic Control Assy | W10254278 |
| 12 | Pad, Ice & Water Midnight Grey | W10290362 |
| 13 | Tray, Housing Satina | W10276225 |
| 14 | Front Cover Silver | W10254266 |

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|-----------|--|--------------|
| 1 | Connector, 5/16 | W10271541 |
| 2 | Fan, Blade | 12825802 |
| 3 | Condenser Assy | W10276899 |
| 4 | Screw | ***** |
| 5 | Clip | W10204187 |
| 6 | Screw | ***** |
| 7 | Connector, 1/4 | W10277958 |
| 8 | Sleeve | W10303521 |
| 9 | Screw | ***** |
| 10 | Start Device Combination Relay | W10197428 |
| 11 | Tube Suction | W10219381 |
| 12 | Clip Condenser | W10248621 |
| 13 | Capacitor | 2264017 |
| 14 | Process Tube | 2325479 |
| 15 | Strap | 2205813 |
| 16 | Evaporator | 2188822 |
| 17 | Clamp | 2161324 |
| 18 | Fan, Motor | 2188874 |
| 19 | Tray, Evaporator | W10238584 |
| 20 | Heat Shield | W10274575 |
| 21 | Drier | W10177049 |
| 22 | Harness, Wiring Water Valve/Diode | W10209479 |
| 23 | Support Plate, Compressor | W10277704 |
| 24 | Power Cord | 2310234 |
| 25 | Air Baffle | W10251467 |
| 26 | Heater, Defrost | W10251470 |
| 27 | Clip | 2304287 |
| 28 | Compressor (Includes 10, 13, 21, & 29) | W10200250 |



Refrigerador Whirlpool WD6971Y02

| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|--------------------|---------------------|
| 29 | Grommet | 10835903 |
| 30 | Clip, Heat Shield | 2155547 |
| 31 | Unit Cover, Bottom | W10278140 |
| 32 | Clip | W10296661 |
| 33 | LED Power Supply | W10356137 |

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02


| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------|----------------------------|--------------|
| 1 | Bracket, Valve | W10237915 |
| 2 | Clip, Fuse | *** |
| 3 | Water Tube | W10238092 |
| 4 | Screw | *** |
| 5 | Filter Valve Asm | W10258562 |
| 6 | Screw | *** |
| 7 | Cover | W10251088 |
| 8 | Screw | *** |
| 9 | Mold & Heater Assembly | W10251081 |
| 10 | Fill Tube Assy | W10347034 |
| 11 | Ejector | W10318644 |
| 12 | Ice Striper | W10251078 |
| 13 | Support | 2194712 |
| 14 | Retainer, Thermostat | 2315522 |
| 15 | Thermostat | 2321258 |
| 16 | Screw | *** |
| 17 | Bracket, Mounting | W10251080 |
| 18 | Harness, Wiring | W10242365 |
| 19 | Module Assembly | 626691 |
| 20 | Screw | *** |
| 21 | Motor | 626683 |
| 100 | Complete Icemaker Assembly | W10122576 |

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool WD6971Y02





Refrigerador Whirlpool WD6971Y02

| No. Ilus. | DESCRIPCIÓN | No. de Parte |
|------------------|--------------------------|---------------------|
| 1 | Fan Scroll | W10251462 |
| 2 | Retainer, Fan Motor | W10260421 |
| 3 | Air Duct, Upper | W10223286 |
| 4 | Bi-Metal, Defrost | W10260437 |
| 5 | Air Duct Freezer | W10260378 |
| 6 | Screw | *** |
| 7 | Fan Motor | 2315549 |
| 8 | Fan Blade | 2169142 |
| 9 | Gasket, Evaporator Cover | W10240370 |
| 10 | Fan Grommet (2) | 2176759 |
| 11 | Clip, Mounting | W10274578 |
| 12 | Harness, Fan Evaporator | W10242409 |
| 13 | Screw, Evap Cover | *** |
| 14 | Cover, Evaporator | W10239739 |
| 15 | Clip, Air Duct | *** |