


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





## Refrigerador Whirlpool WD6971Y03


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Literature Parts	***
<b>2</b>	Front Roller	2150304
<b>3</b>	Screw	***
<b>4</b>	Roller (Rear)	12477102
<b>5</b>	Axle, Roller	12477202
<b>6</b>	Rivet, Roller	W10285005
<b>8</b>	Bracket, Foot	W10257186
<b>9</b>	Foot, Brake	W10141622
<b>11</b>	Valve, Inlet	W10238100
<b>12</b>	Hinge, Top (FC) Apollo Grey	W10249922
<b>13</b>	Hinge, Top (RC) Apollo Grey	W10249925
<b>15</b>	Bottom Hinge (FC) Apollo Grey	W10249943
<b>16</b>	Bottom Hinge (RC) Apollo Grey	W10257209
<b>17</b>	Door Closer (RC) Apollo Grey	W10257197
<b>19</b>	Clamp, Service Cord	W10279839
<b>20</b>	Cover, Unit	W10257325
<b>21</b>	Filler, Wrapper Apollo Grey	12587703AP
<b>22</b>	Grille Midnight Grey	W10257234
<b>24</b>	Door Closer (FC) Midnight Grey	W10257200
<b>26</b>	Tube, Filter Inlet	W10277956
<b>27</b>	Tube, Filter Outlet	W10277957
<b>28</b>	Drain Fitting	***
<b>29</b>	Extension Tube	***
<b>30</b>	Cabinet (Not A Serviceable Part)	***
<b>31</b>	Control Elek Minotaur	W10268630
<b>32</b>	Cover	12957702

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03






## Refrigerador Whirlpool WD6971Y03

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Liner (Not A Serviceable Part)	***
<b>2</b>	Escutcheon, Meat Pan Control	W10260988
<b>3</b>	Slide, Meat Pan Control	W10260989
<b>4</b>	Air Diffuser Assembly	W10251495
<b>5</b>	Air Diffuser Cover	W10260409
<b>6</b>	Switch Rocker Arm	C3680314
<b>7</b>	Reservoir	W10366790
<b>8</b>	LED Light Assy	W10279030
<b>9</b>	Thermistor	W10316760
<b>10</b>	Air Filter Housing	W10342986
<b>11</b>	Air Filter	W10315189
<b>12</b>	Air Filter Cover	W10340015
<b>13</b>	Housing, Water Filter	W10238123
<b>14</b>	Cover, Thermistor	W10356630
<b>15</b>	Connector, 1/4 x 5/16	W10271543
<b>16</b>	Cover, Water Filter	W10260405
<b>17</b>	Water Filter	W10295370

Refrigerador Whirlpool WD6971Y03






## Refrigerador Whirlpool WD6971Y03

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Shelf, Snack Pan	W10290493
<b>2</b>	Cover, Assy	W10282541
<b>3</b>	Snack Pan Also Order 4 & 5	W10256800
<b>4</b>	Roller	W10278139
<b>5</b>	Axle, Roller	W10257246
<b>6</b>	Crisper Pan Also Order 4 & 5	W10256801
<b>7</b>	Meat Pan Also Order 4 & 5	W10256802
<b>8</b>	Shelf Assy	W10276663

Refrigerador Whirlpool WD6971Y03








## Refrigerador Whirlpool WD6971Y03

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Liner (Not A Seviceable Part)	***
<b>2</b>	Cover Assy	W10269181
<b>3</b>	Shelf, Glass Upper	W10269184
<b>4</b>	Thermistor	W10280386
<b>5</b>	Shelf, Glass Lower	W10278132
<b>6</b>	Pan, Freezer Upper	W10256823
<b>7</b>	Roller	W10278139
<b>8</b>	Axle, Roller	W10257246
<b>9</b>	Pan, Freezer Lower	W10256827
<b>10</b>	Switch, Rocker Arm	1115373
<b>11</b>	Pin	2198634
<b>12</b>	Spring	2198635
<b>13</b>	Cover, Emitter	W10258502
<b>14</b>	P.C. Board Emitter	W10180607
<b>15</b>	Cover, Receiver	W10258510
<b>16</b>	P.C. Board Receiver	W10296530
<b>17</b>	Cover, Thermistor	W10356630
<b>18</b>	Door Emmiter	W10258520
<b>19</b>	Slide, Ice Maker Shut Off	W10258540
<b>20</b>	Leds	W10279030



Refrigerador Whirlpool WD6971Y03





## Refrigerador Whirlpool WD6971Y03


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Ice Bin Assy	W10353207
<b>2</b>	Ice Bin	W10286610
<b>3</b>	Auger	W10178230
<b>4</b>	Washer	2258220
<b>5</b>	Spacer, Step	W10341948
<b>6</b>	Cover, Crusher	W10178232
<b>7</b>	Blade, Rotary	W10341944
<b>8</b>	Spacer, Step	W10341948
<b>9</b>	Blade, Fixed	2257020
<b>10</b>	Blade, Rotary	W10341943
<b>11</b>	Block, Blade	W10178238
<b>12</b>	Roll Pin	W10166878
<b>13</b>	Blade, Rotary	W10341942
<b>14</b>	Washer, Plain	489235
<b>15</b>	Washer, Coupling	2198661
<b>16</b>	Coupling, Upper	2220457
<b>19</b>	Latch, Assy	W10258552
<b>20</b>	Coupling, Lower	2220458
<b>21</b>	Drive Shaft	W10258544
<b>22</b>	Spring, Coupling	2198607
<b>23</b>	Mounting Plate Assembly	W10293211
<b>24</b>	Seal	2198628
<b>25</b>	Gasket	W10291905
<b>26</b>	Washer	2212370
<b>27</b>	Dispenser, Motor	2323603
<b>28</b>	Gasket	W10166854
<b>29</b>	Motor Box Assy	W10238131
<b>30</b>	Cover, Container	W10287594

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





## Refrigerador Whirlpool WD6971Y03


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Refrigerator Door (Includes Item 5)	W10365609
<b>2</b>	Door Compartment Assembly	W10336573
<b>3</b>	Screw	***
<b>4</b>	Door Bin, Shallow	W10335221
<b>5</b>	Door Gasket, Magnetic Apollo Grey	W10249916
<b>6</b>	Handle Stainless/Satina	W10274730
<b>7</b>	Thimble-Top	2200087
<b>8</b>	Stud, Handle	W10170540
<b>9</b>	Door Closer, Upper Cam Apollo Grey	W10257203
<b>10</b>	Screw	***
<b>11</b>	Bracket, Door Stop Chrome	W10247909
<b>12</b>	Badge Whirlpool	W10393264
<b>13</b>	Set Screw Chrome	W10010140
<b>14</b>	Door Bin, Gallon	W10335219
<b>15</b>	Door, Compartment	W10336570
<b>16</b>	Cover, Door Stop Midnight Grey	W10257218

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





Refrigerador Whirlpool WD6971Y03


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Freezer Door	W10365684
<b>2</b>	Handle Stainless/Satina	W10274730
<b>3</b>	Thimble-Top	2200087
<b>4</b>	Screw	***
<b>5</b>	Stud, Handle	W10170540
<b>6</b>	Door Bin	W10335217
<b>7</b>	Screw	***
<b>8</b>	Door Gasket, Magnetic Apollo Grey	W10249917
<b>9</b>	Door Closer, Upper Cam Apollo Grey	W10257206
<b>10</b>	Bracket, Door Stop Chrome	W10247907
<b>11</b>	Set Screw Chrome	***
<b>12</b>	Cover, Door Stop Midnight Grey	W10257223

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





Refrigerador Whirlpool WD6971Y03

No. Ilus.	DESCRIPCIÓN	No. de Parte
<b>1</b>	Housing, Dispenser (Not Serviced)	***
<b>2</b>	Grate, Drip Tray	W10276209
<b>3</b>	Bracket, Ice Door	W10174827
<b>4</b>	Guide, Ice	W10339578
<b>5</b>	Motor, Ice Door	W10205978
<b>6</b>	Door, Ice	W10317279
<b>7</b>	Support, Ice Door	W10346124
<b>8</b>	Screw	***
<b>9</b>	Trim Ring Chromium Frost	W10254252
<b>10</b>	Spigot	2305235
<b>11</b>	Electronic Control Assy	W10254278
<b>12</b>	Pad, Ice & Water Midnight Grey	W10290362
<b>13</b>	Tray, Housing Satina	W10276225
<b>14</b>	Front Cover Silver	W10254266




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





## Refrigerador Whirlpool WD6971Y03

No. Ilus.	DESCRIPCIÓN	No. de Parte
<b>1</b>	Connector, 5/16	W10271541
<b>2</b>	Fan, Blade	12825802
<b>3</b>	Condenser Assy	W10276899
<b>4</b>	Screw	*****
<b>5</b>	Clip	W10204187
<b>6</b>	Screw	*****
<b>7</b>	Connector, 1/4	W10277958
<b>8</b>	Sleeve	W10303521
<b>9</b>	Screw	*****
<b>10</b>	Start Device Combination Relay	W10197428
<b>11</b>	Tube Suction	W10219381
<b>12</b>	Clip Condenser	W10248621
<b>13</b>	Capacitor	2264017
<b>14</b>	Process Tube	2325479
<b>15</b>	Strap	2205813
<b>16</b>	Evaporator	2188822
<b>17</b>	Clamp	2161324
<b>18</b>	Fan, Motor	2188874
<b>19</b>	Tray, Evaporator	W10238584
<b>20</b>	Heat Shield	W10274575
<b>21</b>	Drier	W10177049
<b>22</b>	Harness, Wiring Water Valve/Diode	W10209479
<b>23</b>	Support Plate, Compressor	W10277704
<b>24</b>	Power Cord	2310234
<b>25</b>	Air Baffle	W10251467
<b>26</b>	Heater, Defrost	W10251470
<b>27</b>	Clip	2304287
<b>28</b>	Compressor (Includes 10, 13, 21, & 29)	W10200250



## Refrigerador Whirlpool WD6971Y03


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>29</b>	Grommet	10835903
<b>30</b>	Clip, Heat Shield	2155547
<b>31</b>	Unit Cover, Bottom	W10278140
<b>32</b>	Clip	W10296661
<b>33</b>	LED Power Supply	W10356137

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





## Refrigerador Whirlpool WD6971Y03


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Bracket, Valve	W10237915
<b>2</b>	Clip, Fuse	***
<b>3</b>	Water Tube	W10238092
<b>4</b>	Screw	***
<b>5</b>	Filter Valve Asm	W10258562
<b>6</b>	Screw	***
<b>7</b>	Cover	W10251088
<b>8</b>	Screw	***
<b>9</b>	Mold & Heater Assembly	W10251081
<b>10</b>	Fill Tube Assy	W10347034
<b>11</b>	Ejector	W10318644
<b>12</b>	Ice Striper	W10251078
<b>13</b>	Support	2194712
<b>14</b>	Retainer, Thermostat	2315522
<b>15</b>	Thermostat	2321258
<b>16</b>	Screw	***
<b>17</b>	Bracket, Mounting	W10251080
<b>18</b>	Harness, Wiring	W10242365
<b>19</b>	Module Assembly	626691
<b>20</b>	Screw	***
<b>21</b>	Motor	626683
<b>100</b>	Complete Icemaker Assembly	W10122576

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool WD6971Y03





Refrigerador Whirlpool WD6971Y03

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Fan Scroll	W10251462
<b>2</b>	Retainer, Fan Motor	W10260421
<b>3</b>	Air Duct, Upper	W10223286
<b>4</b>	Bi-Metal, Defrost	W10260437
<b>5</b>	Air Duct Freezer	W10260378
<b>6</b>	Screw	***
<b>7</b>	Fan Motor	2315549
<b>8</b>	Fan Blade	2169142
<b>9</b>	Gasket, Evaporator Cover	W10240370
<b>10</b>	Fan Grommet (2)	2176759
<b>11</b>	Clip, Mounting	W10274578
<b>12</b>	Harness, Fan Evaporator	W10242409
<b>13</b>	Screw, Evap Cover	***
<b>14</b>	Cover, Evaporator	W10239739
<b>15</b>	Clip, Air Duct	***