




## UNDERCOUNTER DISHWASHER

### MODELS:

WDF520PADB5 (Black)  
WDF520PADW5 (White)  
WDF520PADM5 (Stainless)



**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
1		Literature Parts
	W10435040	Installation Instructions
	W10656410	Energy Guide
	W10717213	Use & Care Guide
	W10590887	Tech Sheet, English
	W10590888	Tech Sheet, French
2		Arm, Hinge
	W10274922	Left Hand
	W10274921	Right Hand
3	W10195120	Stiffener, Door

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
4		Panel, Front (Includes Nameplate)
	W10629470	Black
	W10629471	White
	W10629473	Stainless
5		Access Panel
	W10369023	Black
	W10369025	White
6		Nameplate
	W10393264	Grey
	W10387117	White
7	W10519755	Insulation, Toe Panel

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
8		Fastener
	W10503548	Black
	W10503549	White
9	304392	Screw
10	489470	Screw
11	W10620222	Insulation, Front Panel
12	8268961	Sleeve, Friction



**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
1		Console Assembly (Includes Insert)
	W10629482	Black
	W10629483	White
	W10629485	Stainless
2	W10756253	Box, Connector
3		Handle Pocket
	W10629511	Black

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
4	W10629497	Light Pipe
5	W10648588	Screw
6	W10629499	Button Tree
7	W10574864	Latch Assembly (Includes Switch)
8	W10804131	Control, Electronic
9	W10372484	Brace, Connector
10	W10485367	Clip, Panel

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
11	W10629551	Tab, Control
12	3400061	Screw



**Illus.****No.   Part No.   Description**


- 1 W10348413 Screw
- 2 W10524920 Cap, Rinse Aid
- 3 W10713291 Inner Door Assembly  
(Also Order Item 6)
- 4 W10482094 Cover, Dispenser
- 5 W10329609 Vent Assembly  
(Also Order Item 6)

**Illus.****No.   Part No.   Description**

- 6 8269259 Gasket, Vent
- 7 W10671924 Bezel, Vent  
(Also Order Item 6)
- 8 W10671905 Dispenser Assembly
- 9 W10803035 Wiring Harness
- 10 W10177098 Screw

**Illus.****No.   Part No.   Description**

- 11 W10274923 Seal, Console/Door
- 12 W10462232 Bracket, Dispenser





**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
1	370445	Clamp, Hose
2	W10769066	Hose
3	W10195536	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10508676	Nut, Inlet (Also Order Item 4)

**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
6	371505	Clamp, Hose
7	W10327250	Fill Valve Assembly
8	304392	Screw
9	W10545278	Drain Loop with Check Valve Assembly
10	304231	Screw
11	W10195039	Switch, Overfill Control

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
12	W10316267	Standpipe, Overfill
13	W10346525	Float & Retainer Assembly
14	W10195037	Lever, Overfill Switch
15	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)



<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1	W10349289	Tub Assembly (Includes Heater Assembly)	10	8575897	Wheel Assembly		19	8268990	Bushing, Door Spring	
2		W10321574	Shield, Thermostat	11	3400892	Screw		20	3378128	Washer, Pronged Cup	
3		W10524469	Seal, Tub	12	8268991	Cover, Terminal Box					
4		W10341745	Screw	13	W10380479	Shield, Tub Sound					
5		3367670	Screw	14	W10539489	Clip, Thermostat					
6		8269145	Bracket, Undercounter	15	3371618	Thermostat					
7		W10304231	Support, Bottom	16	W10544004	Strike, Latch					
8		W10619352	Leveler, Leg	17	W10746770	Sound Insulation, Bottom					
9		W10337934	Spring, Door Balance	18	3400014	Screw, Grounding					



**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
1	W10455271	Cover, Outlet
2	W10482462	Sump With Seal (Also Order Items 13 & 16)
3	W10463906	Screen
4	W10195086	Motor, Isolator
5	W10733530	Sump & Motor Assembly
6	W10372113	Tab, Sump

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
7	W10693534	Filter Cup Assembly
8	W10724439	Pump, Drain
9	8269144	Hose, Drain
10	W10348407	Screw
11	370445	Clamp, Hose
12	W10723295	Indicator, Optical Wash
13	W10538166	Grommet

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
14	W10169167	Clamp, Hose
15	W10610147	Motor (Also Order Items 13 & 16)
16	W10445975	Hose Assembly (Includes 2 Clamps)
17	W10319027	Lower Sprayarm




**Illus.****No. Part No. Description**

- 1 W10671930 Feed Tube Assembly
- 2 W10165274 Screw

**Illus.****No. Part No. Description**

- 3 W10317197 Sprayarm
- 4 W10340683 Manifold





**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
1	W10441445	Heater Element Assembly (Includes Heater Washer & Nut)


**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
2	W10446558	Washer, Heater
3	W10477552	Nut, Heater Element

**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
4	8269262	Bracket, Heater Support

NOTE: If heater element is removed, it must be replaced.



Illus.No. Part No. Description


1	W10164198	Dishrack, Upper
2	8575281	Mount, Wheel Assembly
3	3385089	Track, Dishrack

Illus.No. Part No. Description

4	8565925	Stop, Track (Non-Removable)	7
5	8268826	Clip, Cupshelf	8
6	8268828	Cupshelf, Small	

Illus.No. Part No. Description

W10082861	Stop, Track (Removable)	
W10306228	Track, Spacer	



Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8539225	Dishrack, Lower
2	8268645	Wheel & Transport Assembly

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10629541	Silverware Basket Assembly
4	W10629533	Lid, Silverware Basket (Side)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10629537	Lid, Silverware Basket (Center)
6	W10671904	Clip, Silverware Basket

# OPTIONAL PARTS (NOT INCLUDED)

<b>ACCESSORIES</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft. Handle Assembly
	W10702080	Black
	W10702081	White

<b>PAINT, TOUCH-UP (1/2OZ.)</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		72017 White
		72032 Black
		4392899 Biscuit/Bisque

<b>PAINT, PRESSURIZED SPRAY (12 OZ.)</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		350930 White
		285006 Black
		4392901 Biscuit/Bisque

<b>PAINT, BULK (1 QT.)</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		799344 White (Uncut)
		4392900 Biscuit/Bisque

<b>POWER CORD KIT</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		4317824 Power Cord Kit (Included Cord & Misc. Hardware)

<b>ANTI-TIP KIT</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		8171477 Floor Mount Kit
		8212560 Side Mount Kit

<b>DISHRACK REPAIR</b>		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
		4396838 White
		4396840 Grey
		4396854 Silver Atlantis
		VINYL TOUCH-UP (4oz)
		676453 White
		676455 Grey
		4396853 Silver Atlantis