




UNDERCOUNTER DISHWASHER

MODELS:

WDF520PADB5 (Black)
WDF520PADW5 (White)
WDF520PADM5 (Stainless)



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10435040	Installation Instructions
	W10656410	Energy Guide
	W10717213	Use & Care Guide
	W10590887	Tech Sheet, English
	W10590888	Tech Sheet, French
2		Arm, Hinge
	W10274922	Left Hand
	W10274921	Right Hand
3	W10195120	Stiffener, Door

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Panel, Front (Includes Nameplate)
	W10629470	Black
	W10629471	White
	W10629473	Stainless
5		Access Panel
	W10369023	Black
	W10369025	White
6		Nameplate
	W10393264	Grey
	W10387117	White
7	W10519755	Insulation, Toe Panel

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Fastener
	W10503548	Black
	W10503549	White
9	304392	Screw
10	489470	Screw
11	W10620222	Insulation, Front Panel
12	8268961	Sleeve, Friction



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)
	W10629482	Black
	W10629483	White
	W10629485	Stainless
2	W10756253	Box, Connector
3		Handle Pocket
	W10629511	Black

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10629497	Light Pipe
5	W10648588	Screw
6	W10629499	Button Tree
7	W10574864	Latch Assembly (Includes Switch)
	W10804131	Control, Electronic
8		
9	W10372484	Brace, Connector
10	W10485367	Clip, Panel

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10629551	Tab, Control
12	3400061	Screw



Illus.**No. Part No. Description**


- 1 W10348413 Screw
- 2 W10524920 Cap, Rinse Aid
- 3 W10713291 Inner Door Assembly
(Also Order Item 6)
- 4 W10482094 Cover, Dispenser
- 5 W10329609 Vent Assembly
(Also Order Item 6)

Illus.**No. Part No. Description**

- 6 8269259 Gasket, Vent
- 7 W10671924 Bezel, Vent
(Also Order Item 6)
- 8 W10671905 Dispenser Assembly
- 9 W10803035 Wiring Harness
- 10 W10177098 Screw

Illus.**No. Part No. Description**

- 11 W10274923 Seal, Console/Door
- 12 W10462232 Bracket, Dispenser



Illus.


No.	Part No.	Description
1	370445	Clamp, Hose
2	W10769066	Hose
3	W10195536	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10508676	Nut, Inlet (Also Order Item 4)

Illus.


No.	Part No.	Description
6	371505	Clamp, Hose
7	W10327250	Fill Valve Assembly
8	304392	Screw
9	W10545278	Drain Loop with Check Valve Assembly
10	304231	Screw
11	W10195039	Switch, Overfill Control

Illus.

No.	Part No.	Description
12	W10316267	Standpipe, Overfill
13	W10346525	Float & Retainer Assembly
14	W10195037	Lever, Overfill Switch
15	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)



<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1	W10349289	Tub Assembly (Includes Heater Assembly)	10	8575897	Wheel Assembly		19	8268990	Bushing, Door Spring	
2		W10321574	Shield, Thermostat	11	3400892	Screw		20	3378128	Washer, Pronged Cup	
3		W10524469	Seal, Tub	12	8268991	Cover, Terminal Box					
4		W10341745	Screw	13	W10380479	Shield, Tub Sound					
5		3367670	Screw	14	W10539489	Clip, Thermostat					
6		8269145	Bracket, Undercounter	15	3371618	Thermostat					
7		W10304231	Support, Bottom	16	W10544004	Strike, Latch					
8		W10619352	Leveler, Leg	17	W10746770	Sound Insulation, Bottom					
9		W10337934	Spring, Door Balance	18	3400014	Screw, Grounding					



Illus.


No.	Part No.	Description
1	W10455271	Cover, Outlet
2	W10482462	Sump With Seal (Also Order Items 13 & 16)
3	W10463906	Screen
4	W10195086	Motor, Isolator
5	W10733530	Sump & Motor Assembly
6	W10372113	Tab, Sump

Illus.

No.	Part No.	Description
7	W10693534	Filter Cup Assembly
8	W10724439	Pump, Drain
9	8269144	Hose, Drain
10	W10348407	Screw
11	370445	Clamp, Hose
12	W10723295	Indicator, Optical Wash
13	W10538166	Grommet

Illus.

No.	Part No.	Description
14	W10169167	Clamp, Hose
15	W10610147	Motor (Also Order Items 13 & 16)
16	W10445975	Hose Assembly (Includes 2 Clamps)
17	W10319027	Lower Sprayarm




Illus.**No. Part No. Description**

- 1 W10671930 Feed Tube Assembly
- 2 W10165274 Screw

Illus.**No. Part No. Description**

- 3 W10317197 Sprayarm
- 4 W10340683 Manifold



Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10441445	Heater Element Assembly (Includes Heater Washer & Nut)


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10446558	Washer, Heater
3	W10477552	Nut, Heater Element

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	8269262	Bracket, Heater Support

NOTE: If heater element is removed, it must be replaced.



Illus.**No. Part No. Description**


1	W10164198	Dishrack, Upper
2	8575281	Mount, Wheel Assembly
3	3385089	Track, Dishrack

Illus.**No. Part No. Description**

4	8565925	Stop, Track (Non-Removable)	7
5	8268826	Clip, Cupshelf	8
6	8268828	Cupshelf, Small	

Illus.**No. Part No. Description**

W10082861	Stop, Track (Removable)	7
W10306228	Track, Spacer	





LAVAVAJILLAS WDF520PADW5

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8539225	Dishrack, Lower
2	8268645	Wheel & Transport Assembly

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10629541	Silverware Basket Assembly
4	W10629533	Lid, Silverware Basket (Side)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10629537	Lid, Silverware Basket (Center)
6	W10671904	Clip, Silverware Basket

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft. Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		72017 White
		72032 Black
		4392899 Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		350930 White
		285006 Black
		4392901 Biscuit/Bisque

PAINT, BULK (1 QT.)		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		799344 White (Uncut)
		4392900 Biscuit/Bisque

POWER CORD KIT		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		4317824 Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		8171477 Floor Mount Kit
		8212560 Side Mount Kit

DISHRACK REPAIR		
<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
		4396838 White
		4396840 Grey
		4396854 Silver Atlantis
		VINYL TOUCH-UP (4oz)
		676453 White
		676455 Grey
		4396853 Silver Atlantis