




UNDERCOUNTER DISHWASHER

MODELS:


WDF760SADB3 (Black)
WDF760SADW3 (White)
WDF760SADT3 (Biscuit)
WDF760SADM3 (Stainless)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10806906	Installation Instructions
	W10864208	Energy Guide
	W10889568	Use & Care Guide
	W10880570	Tech Sheet, English
	W10880571	Tech Sheet, French
2		Arm, Hinge
	8534854	Left Hand
	8534853	Right Hand
3	W10844384	Barrier, Vapor

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Panel, Front (Includes Nameplate)
	W10698612	Black
	W10698613	White
	W10698614	Biscuit/Bisque
	W10698615	Stainless
5		Access Panel
	W10441006	Black
	W10441007	White
	W10441008	Biscuit/Bisque
6	304392	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7		Fastener
	W10503548	Black
	W10503549	White
	W10503550	Biscuit/Bisque
8		Nameplate
	W10393264	Grey
	W10387117	White
9	3400071	Screw
10	W10641745	Bracket, Control
11	W10463662	Spacer, Control Bracket Panel






LAVAVAJILLAS WDF760SAD

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)
	W10644293	Black
	W10644294	White
	W10644295	Biscuit/Bisque
	W10644296	Stainless
2	W10195237	Clip, Control

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W11024455	Control, Electronic
4	W10653840	Latch Assembly (Includes Switch)
5	W10194937	Brace, Connector
6		Handle Pocket
	W10629511	Black
7	W10756253	Box, Connector

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10671940	Housing Assembly, User Interface
9	W10566903	Jumper, 4-Wire
10	W10348408	Screw
11	W10485367	Clip, Panel






LAVAVAJILLAS WDF760SAD

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	W10177098	Screw
3	W10713614	Inner Door Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10667473	Seal, Door Bottom
5	W10195007	Seal, Console/Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10620296	Dispenser Assembly
7	W10877734	Wiring Harness






LAVAVAJILLAS WDF760SAD


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch
2	W10769066	Hose
3	W10195536	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10213825	Nut, Water Inlet (Also Order Item 4)
6	371505	Clamp, Hose

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10327249	Fill Valve Assembly
8	304392	Screw
9	371505	Clamp, Hose
10	W10545278	Drain Loop with Check Valve Assembly
11	W10734532	Switch, Overfill Control
12	W10647205	Housing, Overfill (Also Order Item 13)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	8531743	Gasket, Flat
14	W10195038	Nut, Standpipe
15	W10195036	Float & Retainer Assembly
16	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681492	Tub Assembly (Includes Heater Assembly)	12	W10348411	Screw	22	W10681564	Support Assembly, Rear
2	W10292870	Shield, Thermostat	13	W10190778	Wheel Leg	23	W10866978	Shield, Tub Sound
3	W10300924	Gasket, Tub	14	W10619352	Leveler, Leg	24	W10300703	Bracket, Thermostat
4	W10813122	Plug, Tub	15		Spacer, Tub Brace	25	W10195091	Thermostat
5	3378128	Washer, Pronged Cup		W10195630	Left Hand	26	W10544004	Strike, Latch
6	W10835073	Seal, Cabinet		W10195631	Right Hand	27	W10696509	Heater Element Assembly (Includes Heater Washer & Nut)
7	3400014	Screw, Grounding	16	8270020	Spring, Door Balance			NOTE: If heater element is removed, it must be replaced.
8	W10084086	Door Balance Assembly	17	W10337661	Strain Relief			
9	3367670	Screw	18	3400892	Screw			
10	8269145	Bracket, Undercounter	19	W10653292	Cover, Terminal Box			
11	3400074	Screw	20	W10158291	Cable, Door			
			21	W10713315	Assembly, Terminal Box			



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10629542	Cover, Outlet
2	W10195086	Motor, Isolator
3	W10463906	Screen
4	W10455268	Sump With Seal (Also Order Items 5 & 20)
5	W10538166	Grommet
6	W10723295	Indicator, Optical Wash
7	W10348407	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10789806	Filter Cup Assembly
9	W10885542	Motor (Also Order Items 5 & 20)
10	9741232	Screw
11	8269146	Clamp, Hose
12	W10671942	Sump & Motor Assembly
13	W10372113	Tab, Sump
14	W10849439	Motor, Diverter

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10348269	Pump, Drain
16	W10476221	Disc, Diverter
17	8269144	Hose, Drain
18	W10169167	Clamp, Hose
19	W10300776	Damper, Sump Assembly
20	W10445975	Hose Assembly (Includes 2 Clamps)
21	W10629546	Sprayarm, Lower






LAVAVAJILLAS WDF760SAD

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10753067	Feed Tube Assembly (Includes Items 2 & 3)
2	W10327455	Sprayarm, Third Level
3	3400918	Retainer

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10788845	Manifold
5	W10498900	Sprayarm
6	W10671899	Manifold, Proscrub


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10355006	Tube, Connecting
8	W10644280	Manifold, Tall Item Zone



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10350380	Dishrack, Upper
2		Housing, Adjuster
	W10656415	Left Hand
	W10656414	Right Hand
3	W10250160	Clip, Adjuster
4		Adjuster Assembly
	W10629521	Left Hand
	W10629520	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10195839	Strap, Tether Adjuster
6	W10195840	Positioner, Adjuster
7	W10082649	Cupshelf Assembly
8	W10752617	Clip, Dispenser Guard
9	W10250162	Cover, Adjuster
10	W10460371	Track, Dishrack
11	W10309090	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	8562030	Tine Row, Fold Down
13	W10082848	Clip, Cupshelf
14	W10082853	Clip, Pivot
15	W10671900	Positioner, Dual





LAVAVAJILLAS WDF760SAD

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10720474	Dishrack, Lower
2	W10644277	Lid, Silverware Basket (Side)
3	W10195416	Wheel & Transport Assembly
4	W10671902	Retainer, Tine Row (Combo)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10629540	Silverware Basket Assembly
6	W10644279	Lid, Silverware Basket (Center)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10380209	Tine, Fold Down
8	W10671904	Clip, Silverware Basket

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft. Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis