



**WF203ANSXAX PUERTA**

D0001



F0064








## WF203ANSXAX PUERTA

C58	DC64-00519B	DOOR LOCK
D01	DC97-12918B	DOOR ASSEMBLY
D08	DC61-01858A	BRACKET
D10	DC97-12919B	DOOR COVER
D105	DC61-01827A	SUPPORT
D106	DC63-00693A	DOOR COVER
D107	DC66-00326A	DOOR LEVER
D108	DC61-01841A	DOOR HINGE
D16A	DC63-00808B	DOOR COVER
D61	DC64-00504C	DOOR GLASS
D72	DC61-00891A	GUIDE-HINGE
D75	DC64-01429B	DOOR HANDL
D81	DC61-01842A	GLASS HOLDER
F103	DC61-01840B	FRAME
F64	DC97-12917B	FRAME ASSEMBLY
R30	DC97-04973B	WIRE ASSEMBLY
Z36	6001-001668	MACHINE SCREW

**WF203ANSXAX TABLERO**






## WF203ANSXAX TABLERO

C02	DC97-12953D	CONTROL PANEL
C09	DC64-01471A	WINDOW
C10	DC64-01424A	WINDOW
C29	DC97-12954B	KNOB ASSEMBLY
C43	DC64-01419B	BUTTON
C44	DC64-01433B	BUTTON
C45	DC64-01420B	BUTTON
C46	DC64-01432B	BUTTON
C56	DC64-01422A	DECOBUTTON
C57	DC64-01421A	DECOBUTTON
N09	DC65-00008A	CLAMPER HOOD
P164	DC61-01847A	PANEL GUIDE
R14	DC97-12955B	DRAWER ASSEMBLY
R157	DC67-00121B	RINSE CAP
R158	DC67-00051B	DRAWER HOSE
R159	DC97-08800A	SHOULDER ASSEMBLY
R19	DC97-07125L	HOUSING
R85	DC61-01171A	GUIDE-LIQU
R96	DC61-01167A	DRAWER
W2	DC62-30312J	WATER VALVE
W2A	DC62-30314K	WATER VALVE
Y165	DC64-01431A	DECORATIVE LED
Y168	DC61-01846A	LED GUIDE
Y170	MFS-WF203L-T1	POWER CONTROL BOAR
Y171	MFS-WF203L-00	POWER CONTROL BOAR
Y172	MFS-WF203L-S1	POWER CONTROL BOAR

**WF203ANSXAX GABINETE**









## WF203ANSXAX GABINETE

A25	DC97-07448D	FIXER ASY
A282	DC63-00522A	COVER
A372	DC97-08740D	ASSY-CAP O
A83	DC61-00274A	GUIDE HOSE
B45	DC61-01652A	LEG RING
B70	DC97-00920N	LEG ASSY
B73	DC61-01747A	LEG RUBBER
F223	DC62-00202A	CHECK VALVE
F28	DC97-06995T	FRAME ASSEMBLY
I23	DC97-07128D	HOSE
I30	DC62-10278A	HANGER HOSE
I40	DC97-15648A	HOSE ASSEMBLY
I40A	DC97-15648A	HOSE ASSEMBLY
J13	DC96-01414A	PUMP
J17	DC61-01853A	BRACKET
J25	DC31-00054A	DRAIN PUMP
N1	DC61-00133A	CLAMPER HOOD
N6	DC61-40081A	WIRING HOLDER
P01	DC97-12878D	COVER
P53	DC63-00523H	COVER
Q06	DC97-03716C	SENSOR
R161	DC62-40178A	WATER SEAL
U161	DC61-01200B	GUIDE WIRE
W02	DC96-00757A	POWER
W04	DC96-00758G	HARNESS
W36	DC29-00013C	EMI FILTER
X51	DC99-00815A	ASSY-LEG
Y162	MFS-MEMS-00	ASSY PCB P
Z47	6009-001317	SCREW
Z48	6009-001476	HEX SCREW

**WF203ANSXAX TAMBOR**





## WF203ANSXAX TAMBOR

I43	DC67-00126A	DRAIN HOSE
I46	DC67-00280A	TUBE HOSE
I79	DC97-13072A	HOSE ASSEMBLY
N08	DC61-70029C	SPRING-CLI
N10	DC61-01679A	CLIP HOSE
R01	DC97-13109A	DRUM ASSEMBLY
R06	DC66-00477A	DRUM LIFTR
R07	DC97-06987A	FLANGE ASSEMBLY
R21	DC97-12747A	GUIDE ASSEMBLY
S58	DC97-12545A	BALANCER
U10	DC66-00368A	PULLEY
U133	DC66-00343E	SHOCK DAMPER
U185	DC67-00155A	HOSE
U29	DC64-01479A	DOOR
U353	6031-001482	WASHER
U354	6031-001519	WASHER
U359	DC61-01482A	BRACKET-HE
U362	DC60-60049A	WASHER-SPR
U363	6502-000127	CABLE CLAMP
U364	DC69-00804A	PACKING-TU
U365	DC97-02412A	BOLT ASSEMBLY
U367	DC63-10003C	SPONGE
U38	DC97-04981D	CLAMP
U384	DC61-01438A	TUBE BRACKET
U391	DC67-00140A	WEIGHT BAL
U53	6031-001531	WASHER PLATE
U53A	DC60-60044A	WASHER PLATE
U53B	DC60-60044B	WASHER PLATE
U63	6502-000168	CABLE CLAMP
U63A	DC63-00820A	HEATER COVER
U63B	DC65-20008C	CLAMP-CABL



U67A	DC63-10003E	SPONGE HOSE
U79	DC97-08760B	SEMI TUBE
U86	DC67-00139A	WEIGHT-BAL
U95	6602-001216	BELT
W05	DC96-01417B	HEATER ASSEMBLY
W31	DC72-00001D	BAND RING
Z04	DC60-50148B	HEX NUT