


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Estufa Whirlpool WF7009S00





Estufa Whirlpool WF7009S00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	COOKTOP	W10710669
2	FRONT PANEL EXTENTION SS	W10604155
3	FRONT CLIP COOKTOP	W10620563
4	SINGLE KNOB GRAY	W10699982
5	ASSY. STD. BURNER	W10743941
	STD. CAP	W10672381
	CAP STD. BURNER	W10744981
6	ASSY. SUPER BURNER	W10860540
	SUPER MAX BURNER CAP.	W10744982
	CAP. SUPER BURNER	W10672379
7	GRATE CENTRAL CAST IRON	W10718553
8	GRATE LATERAL CAST IRON	W10718552
9	GRIDDLE STAMPED-ENAMEL	W10387432
10	BRACKET MANIFOLD TUBE	W10381587
11	GLASS LID ASSY	W10625931
12	BRACKET-LS, GLASS LID-BLACK	W10546253
13	BRACKET-RS, GLASS LID-BLACK	W10546251
14	TRIM - GLASS LID, SHORT	W10477615
15	R.H. HINGE GLASS LID	W10206666
16	L.H. HINGE GLASS LID	W10206667
**	BUMPER GLASS LID	W10603704

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones
Electrodomesticas

Estufa Whirlpool WF7009S00



Estufa Whirlpool WF7009S00





Estufa Whirlpool WF7009S00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	FRONT FRAME	W10448074
2	SIDE PANEL - MIDNIGHT GREY	W10354874
3	BROIL BACK COVER	W10515063
4	C - BRACKET	W10358263
5	CORNER BRACKET RH	W10364813
6	CORNER BRACKET LF	W10446940
7	FRONT BRACKET OVEN BURNER	W10616130
8	COUNTER SUPPORT	W10327222
9	OVEN DOOR SEAL	W10759584
10	BASE CORNER FRONT	W10596641
11	BASE RAIL	W10446524
12	CROSS SUPPORT - 30"	W10327223
13	FRONT VERTICAL PILLAR F/S	W10354862
14	OVEN INSULATION WRAPPER 30"	W10364807
15	ALUMINUM FOIL ULTRA	*****
16	OVEN RACK	W10550642
17	OVEN BOTTOM 30"	W10448075
18	FLUE BOX ASM	W10742507
19	BRACKET OVEN BURNER	W10381594

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Estufa Whirlpool WF7009S00






Estufa Whirlpool WF7009S00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	MANIFOLD TUBE	W10381640
2	VALVE SURF ZAMAK TUB.SUP	W10452673
3	VALVE SURF ZAMAK TUB.STD	W10452660
4	THERMOSTAT	W10718787
5	FRONT TUBING ASM - SUP	W10704837
6	FRONT TUBING ASM - STD	W10704879
7	REAR TUBING ASM - STD	W10704886
8	REAR TUBING ASM - SUP	W10704894
9	BRACKET - SURFACE BURNER	W10612731
10	NUT BRACKET TUBING	W10610297
11	OVEN BURNER	W10646981
12	OVEN TUBING - UPPER THERMOSTAT	*****
13	TUBING ASSY BOTTOM - OVEN	W10647685
14	SADDLE CONNECTION	98017516
15	SADDLE CONNECTION	W10075697
16	OVEN TUBING CONNECTOR	*****
**	MANIFOLD TUBE ASSY	W10444635

Estufa Whirlpool WF7009S00






Estufa Whirlpool WF7009S00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	MAIN HARNESS F & F	W10446865
2	OVENLIGHT SWITCH- SHGRY	W10568374
3	IGNITION SWITCH SH GRAY	W10568375
4	SPARK MODULE 6 POS.	W10736963
5	OVEN BULB	W10452019
6	SOCKET - OVEN LIGHT	W10554269
	TOP ELECTRODE 740	W10736982
7	TOP ELECTRODE 650	W10736981
	TOP ELECTRODE 500	W10736980
	TOP ELECTRODE 350	W10736979
8	CLIP IGNITOR -TOP BURNER	W10654842

Estufa Whirlpool WF7009S00






Estufa Whirlpool WF7009S00

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	FS MASK & OUTER GLASS ASM S.S.	W10528450
2	OVEN DOOR HANDLE	W10397442
3	OVEN DOOR CROSS SUPPORT	W10387343
4	OVEN DOOR PILLAR LEFT	W10445015
5	UPPER TRIM - OVEN DOOR	W10544145
6	INNER GLASS - OVEN DOOR	W10372163
7	INNER GLASS SEAL	W10292266
8	OVEN DOOR PILLAR RIGHT	W10445013
9	OVEN DOOR HINGE	W10420753
10	BADGE-WHIRLPOOL CENTENNIAL	W10481433
**	OVEN DOOR, METAL - SS	W10493700

Estufa Whirlpool WF7009S00



No. Ilus.	DESCRIPCIÓN	No. de Parte
1	OUTER BROILER DOOR - STAINLESSSTEEL	W10482110
2	INSULATION - BROILER DOOR 30"	W10557381
3	30" INNER BROILER DOOR	W10446851
4	BROILER DOOR HINGE	W10625517
5	HANDLE - BROILER DOOR, SHADOW GRAY	W10495568
**	BROILER DOOR ASM - S	W10493745

KIT DE CONVERSION GAS NATURAL:	W10720072	
Componentes a solicitar:	W10620394 (4)	ORIFICE HE STD BURNER
	W10716160 (2)	ORIFICE HE SUP BURNER
	W10539375 (1)	ORIFICE OVEN BURNER
	W10121465 (1)	BY-PASS THERMOSTAT
	W10452673 (2)	VALVE FOR HE STD BURNER
	W10452674 (2)	VALVE FOR HE SUP BURNER