


Estufa Whirlpool WF8650S01





Estufa Whirlpool WF8650S01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	COOKTOP	W10491397
2	FRONT PANEL EXTENTION SS	W10604155
3	FRONT CLIP COOKTOP	W10620563
4	KNOB ASSY	W10387511
5	KNOB ASSY THERMOSTAT	W10717828
6	STD BURNER	W10354371
7	STD BURNER CAP MATT	W10190267
8	SUPER BURNER	W10356319
9	SUPER BURNER CAP MATT	W10190271
10	FCB BURNER	W10110911
11	FCB INTERIOR CAP	W10110910
12	FCB EXTERIOR CAP	W10110909
13	GRATE CENTRAL CAST IRON	W10381515
14	GRATE LATERAL CAST IRON	W10381517
15	GRIDDLE - ALUMINUM TEFLONIZED	W10466256
16	GLASS LID ASSY	W10625933
17	BRACKET - LS, GLASS LID - SILVER	W10546253
18	BRACKET - RS, GLASS LID - SILVER	W10546251
19	TRIM - GLASS LID, LARGE	W10477618
20	HINGE - LS, GLASS LID	W10387290
21	HINGE - RS, GLASS LID	W10387289
**	BUMPER GLASS LID	W10373346
**	FCB - CARTON BOX ASSY	W10118060
	TORNILLO CUBIERTA QUEMADOR	W10146346

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones
Electrodomesticas

Estufa Whirlpool WF8650S01



Estufa Whirlpool WF8650S01





Estufa Whirlpool WF8650S01


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	FRONT FRAME	W10448074
2	SIDE PANEL - MIDNIGHT GREY	W10354874
3	BROIL BACK COVER	W10515063
4	C - BRACKET	W10358263
5	CORNER BRACKET RH	W10364813
6	CORNER BRACKET LH	W10446940
7	FRONT BRACKET OVEN BURNER	W10387513
8	COUNTER SUPPORT	W10327222
9	OVEN DOOR SEAL	W10759584
10	BASE CORNER FRONT	W10498418
11	BASE RAIL	W10446524
12	CROSS SUPPORT - 30"	W10327223
13	FRONT VERTICAL PILLAR F/S	W10354862
14	OVEN WRAPPER 30"	W10364807
**	ALUMINUM FOIL ULTRA	W10446939
16	OVEN RACK	W10743506
17	OVEN BOTTOM 30"	W10448075
18	FLUE BOX ASM	W10742507
19	BRACKET OVEN BURNER	W10381594
20	GUIDE - RACK SUPPORT (RIGHT)	W10744031
21	GUIDE - RACK SUPPORT (LEFT)	W10743523
22	RACK SUPPORT ASSY. (RIGHT)	W10743545
23	RACK SUPPORT ASSY. (LEFT)	W10743544
24	PUSH ROD	W10743557
25	BRACKET RETAINER	W10479996

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Estufa Whirlpool WF8650S01





Estufa Whirlpool WF8650S01


No.Illus.	DESCRIPCIÓN	No. de Parte
1	MANIFOLD TUBE	W10422196
2	VALVE SURF ZAMAK TUB.STD	W10200740
3	VALVE SURF ZAMAK TUB.SUP	W10200741
4	SURFACE VALVE FCB	W10444644
5	THERMOSTAT WITH SAFETY	W10387499
6	FRONT TUBING ASM - SUP	W10494190
7	REAR TUBING ASM - SUP	W10556806
8	FRONT TUBING ASM - STD	W10494191
9	REAR TUBING ASM - STD	W10494192
10	TUBING - FCB	W10459197
11	FCB BODY	W10115665
12	OVEN TUBING ASSY	W10647687
**	TUBING ASSY BOTTOM - OVEN	W10381596
14	BRACKET - SURFACE BURNER	W10354300
15	NUT BRACKET TUBING	98017323
16	OVEN BURNER	W10519079
17	THERMOCOUPLE	W10491992
18	VALVE - SHUT OFF	W10777489
19	BRACKET - SHUT OFF VALVE	W10553975
20	TUBING - CUT OFF	W10387503
21	FITTING - 3/8 NPT MALE TO 5/8" FLARED	W10527477
22	SADDLE CONNECTION	W10075697
23	SADDLE CONNECTION EXTENDED-ZAMA	W10381172
24	SADDLE CONNECTION	98017516
**	MANIFOLD TUBE ASSY	W10444636

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Estufa Whirlpool WF8650S01






Estufa Whirlpool WF8650S01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	MAIN HARNESS HW	W10568049
2	TOD MEMBRANE HW FS	W10381615
3	TOD HARNESS HW	W10446872
4	TOD PLUS HW	W10516849
5	COVER CLOCK	W10381619
6	THERMO SWITCH	W10244824
7	COVER CLOCK EXTENSION - PLASTIC	W10487396
8	ULTRA FAN DUCT	W10492455
9	TOD SUPPLY SOURCE HW	W10391623
10	SUPPLY SOURCE BRACKET	W10745757
11	FAN BLOWER	W10391629
12	SWITCH HARNESS HW	W10381662
13	SPARK MODULE 6 POS.	W10455035
14	OVEN BULB	W10452019
15	SOCKET - OVEN LIGHT	W10554269
	TOP ELECTRODE 740	W10391624
16	TOP ELECTRODE 650	W10391625
	TOP ELECTRODE 500	W10381604
	TOP ELECTRODE 350	W10381605
17	CLIP IGNITOR -TOP BURNER	W10654842
18	SWITCH DOOR	98005765
19	OVEN ELECTRODE	W10145060

Estufa Whirlpool WF8650S01






Estufa Whirlpool WF8650S01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	FS MASK & OUTER GLASS ASM S.S.	W10528451
2	OVEN DOOR HANDLE	W10397442
3	OVEN DOOR CROSS SUPPORT	W10387343
4	OVEN DOOR PILLAR RIGHT	W10460272
5	UPPER TRIM - OVEN DOOR	W10544145
6	INNER GLASS - OVEN DOOR	W10372163
7	INNER GLASS SEAL	W10292266
8	OVEN DOOR PILLAR LEFT	W10460273
9	OVEN DOOR HINGE	W10420753
10	BADGE-WHIRLPOOL CENTENNIAL	W10481433
**	OVEN DOOR, METAL - SS	W10493702

Estufa Whirlpool WF8650S01





Estufa Whirlpool WF8650S01

No. Ilus.	DESCRIPCIÓN	No. de Parte
1	OUTER BROILER DOOR - STAINLESS	W10482110
*	INSULATION - BROILER DOOR 30"	W10075717
3	30" INNER BROILER DOOR	W10446851
4	BROILER DOOR HINGE LEFT	W10625517
	BROILER DOOR HINGE RIGHT	W10661466
5	HANDLE - BROILER DOOR, SHADOW	W10495568
**	BROILER DOOR ASM - SS	W10493745

KIT DE CONVERSION GAS NATURAL:	W10513483	
Componentes a solicitar:	W10132112 (2)	ORIFICE STD BURNER
	W10118331 (2)	ORIFICE SUPER BURNER
	W10549799 (1)	ORIFICE FCB
	W10539375 (1)	ORIFICE OVEN BURNER
	98007152 (1)	BY-PASS THERMOSTAT
	W10200741 (2)	VALVE FOR STD. BURNER
	W10258173 (2)	VALVE FOR SUPER BURNER
	W10539406 (1)	VALVE FOR FCB