


# Estufa Whirlpool WF8650S02







## Estufa Whirlpool WF8650S02

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	COOKTOP	W10491397
<b>2</b>	FRONT PANEL EXTENTION SS	W10604155
<b>3</b>	FRONT CLIP COOKTOP	W10620563
<b>4</b>	KNOB ASSY	W10387511
<b>5</b>	KNOB ASSY THERMOSTAT	W10717828
<b>6</b>	STD BURNER	W10354371
<b>7</b>	STD BURNER CAP MATT	W10190267
<b>8</b>	SUPER BURNER	W10356319
<b>9</b>	SUPER BURNER CAP MATT	W10190271
<b>10</b>	FCB BURNER	W10110911
<b>11</b>	FCB INTERIOR CAP	W10110910
<b>12</b>	FCB EXTERIOR CAP	W10110909
<b>13</b>	GRATE CENTRAL CAST IRON	W10381515
<b>14</b>	GRATE LATERAL CAST IRON	W10381517
<b>15</b>	GRIDDLE - ALUMINUM TEFLONIZED	W10466256
<b>16</b>	GLASS LID ASSY	W10383604
<b>17</b>	BRACKET - LS, GLASS LID - SILVER	W10546253
<b>18</b>	BRACKET - RS, GLASS LID - SILVER	W10546251
<b>19</b>	TRIM - GLASS LID, LARGE	W10477618
<b>20</b>	HINGE - LS, GLASS LID	W10387290
<b>21</b>	HINGE - RS, GLASS LID	W10387289
<b>**</b>	BUMPER GLASS LID	W10373346
<b>**</b>	FCB - CARTON BOX ASSY	W10118060
	TORNILLO CUBIERTA QUEMADOR	W10146346

Estufa Whirlpool WF8650S02



Estufa Whirlpool WF8650S02






## Estufa Whirlpool WF8650S02

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	FRONT FRAME	W10801532
<b>2</b>	SIDE PANEL - MIDNIGHT GREY	W10354874
<b>3</b>	BROIL BACK COVER	W10515063
<b>4</b>	C - BRACKET	W10358263
<b>5</b>	CORNER BRACKET RH	W10364813
<b>6</b>	CORNER BRACKET LH	W10446940
<b>7</b>	FRONT BRACKET OVEN BURNER	W10475852
<b>8</b>	COUNTER SUPPORT	W10327222
<b>9</b>	OVEN DOOR SEAL	W10759584
<b>10</b>	BASE CORNER FRONT	W10718549
<b>11</b>	BASE RAIL	W10446524
<b>12</b>	CROSS SUPPORT - 30"	W10327223
<b>13</b>	FRONT VERTICAL PILLAR F/S	W10354862
<b>14</b>	OVEN WRAPPER 30"	W10364807
<b>15</b>	ALUMINUM FOIL ULTRA	*****
<b>16</b>	OVEN RACK	W10743506
<b>17</b>	OVEN BOTTOM 30"	W10448075
<b>18</b>	FLUE BOX ASM	W10742507
<b>19</b>	BRACKET OVEN BURNER	W10381594
<b>20</b>	GUIDE - RACK SUPPORT (RIGHT)	W10744031
<b>21</b>	GUIDE - RACK SUPPORT (LEFT)	W10743523
<b>22</b>	RACK SUPPORT ASSY. (RIGHT)	W10743545
<b>23</b>	RACK SUPPORT ASSY. (LEFT)	W10743544
<b>24</b>	PUSH ROD	W10743557
<b>25</b>	BRACKET RETAINER	W10479996

Estufa Whirlpool WF8650S02






Estufa Whirlpool WF8650S02

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	MANIFOLD TUBE	W10422196
<b>2</b>	VALVE SURF ZAMAK TUB.STD	W10200740
<b>3</b>	VALVE SURF ZAMAK TUB.SUP	W10200741
<b>4</b>	SURFACE VALVE FCB	W10444644
<b>5</b>	THERMOSTAT WITH SAFETY	W10387499
<b>6</b>	FRONT TUBING ASM - SUP	W10556803
<b>7</b>	REAR TUBING ASM - SUP	W10556806
<b>8</b>	FRONT TUBING ASM - STD	W10556804
<b>9</b>	REAR TUBING ASM - STD	W10556805
<b>10</b>	TUBING - FCB	W10459197
<b>11</b>	FCB BODY	W10115665
<b>12</b>	OVEN TUBING - UPPER THERMOSTAT	*****
<b>13</b>	TUBING ASSY BOTTOM - OVEN	W10647687
<b>14</b>	BRACKET - SURFACE BURNER	W10354300
<b>15</b>	NUT BRACKET TUBING	98017323
<b>16</b>	OVEN BURNER	W10519079
<b>17</b>	THERMOCOUPLE	W10491992
<b>18</b>	VALVE - SHUT OFF	W10488109
<b>19</b>	BRACKET - SHUT OFF VALVE	W10553975
<b>20</b>	TUBING - CUT OFF	W10387503
<b>21</b>	FITTING - 3/8 NPT MALE TO 5/8" FLARED	W10527477
<b>22</b>	SADDLE CONNECTION	W10075697
<b>23</b>	SADDLE CONNECTION EXTENDED-ZAM	W10381172
<b>24</b>	SADDLE CONNECTION	98017516
<b>**</b>	MANIFOLD TUBE ASSY	W10444636

Estufa Whirlpool WF8650S02









## Estufa Whirlpool WF8650S02

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	MAIN HARNESS HW	W10452021
<b>2</b>	TOD MEMBRANE HW FS	W10381615
<b>3</b>	TOD HARNESS HW	W10446872
<b>4</b>	TOD PLUS HW	W10516849
<b>5</b>	COVER CLOCK	W10381619
<b>6</b>	THERMO SWITCH	W10244824
<b>7</b>	COVER CLOCK EXTENSION - PLASTIC	W10487396
<b>8</b>	ULTRA FAN DUCT	W10492455
<b>9</b>	TOD SUPPLY SOURCE HW	W10391623
<b>10</b>	SUPPLY SOURCE BRACKET	W10676136
<b>11</b>	FAN BLOWER	W10391629
<b>12</b>	SWITCH HARNESS HW	W10381662
<b>13</b>	SPARK MODULE 6 POS.	W10455035
<b>14</b>	OVEN BULB	W10452019
<b>15</b>	SOCKET - OVEN LIGHT	W10554269
	TOP ELECTRODE 740	W10391624
	TOP ELECTRODE 650	W10391625
<b>16</b>	TOP ELECTRODE 500	W10381604
	TOP ELECTRODE 350	W10381605
<b>17</b>	CLIP IGNITOR- TOP BURNER	W10654842
<b>18</b>	SWITCH DOOR	98005765
<b>19</b>	OVEN ELECTRODE	W10145060



No. Ilus.	DESCRIPCIÓN	No. de Parte
1	FS MASK & OUTER GLASS ASM S.S.	W10528451
2	OVEN DOOR HANDLE	W10397442
3	OVEN DOOR CROSS SUPPORT	W10387343
4	OVEN DOOR PILLAR RIGHT	W10460272
5	UPPER TRIM - OVEN DOOR	W10544145
6	INNER GLASS - OVEN DOOR	W10372163
7	INNER GLASS SEAL	W10292266
8	OVEN DOOR PILLAR LEFT	W10460273
9	OVEN DOOR HINGE	W10420753
10	BADGE-WHIRLPOOL CENTENNIAL	W10481433
**	OVEN DOOR, METAL - SS	W10493702

Estufa Whirlpool WF8650S02



No.Ilus.	DESCRIPCIÓN	No. de Parte
1	OUTER BROILER DOOR - STAINLESS ST	W10482110
2	INSULATION - BROILER DOOR 30"	W10557381
3	30" INNER BROILER DOOR	W10446851
4	BROILER DOOR HINGE	W10661466
5	HANDLE - BROILER DOOR, SHADOW GR	W10495568
**	BROILER DOOR ASM - SS	W10493745

KIT DE CONVERSION GAS NATURAL:		W10513483
Componentes a solicitar:	W10132112 (2)	ORIFICE STD BURNER
	W10118331 (2)	ORIFICE SUPER BURNER
	W10549799 (1)	ORIFICE FCB
	W10539375 (1)	ORIFICE OVEN BURNER
	98007152 (1)	BY-PASS THERMOSTAT
	W10200741 (2)	VALVE FOR STD. BURNER
	W10258173 (2)	VALVE FOR SUPER BURNER
	W10539406 (1)	VALVE FOR FCB