




**30" GAS RANGE BABEL 2° WAVE**  
**Service Parts Catalog (EXPLOSIONADO DE PARTES)**

**MODELS:**


WFR9000S00



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10497101	L.H. HINGE - GLASS LID  Bisagra del capelo	4	W10909692	EBL FLAT GLASS LID FS  Vidrio del capelo	7	W11083217	GLASS-LID,ASSY,FS,HANDLE,SC  Capelo completo
2	W11162985	GLASS-LID,TRIM,MEDIUM  Molduras del capelo	5	W10896319	BUMPER - GLASS LID BLE  Cojinete			
3	W10206666	R.H. HINGE GLASS LID  Bisagra del capelo	6	W10896332	EBL GLASS LID HANDLE FS  Jaladera del capelo			




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10422229	ACCESORY WOK CAST IRON-DRAGON  Accesorio Dragon Hierro Fundido	4	W11181360	CAST IRON GRATE FLAT 5TH BURNER  Parrilla Central	7	W11098906	COOKTOP LOWER COVER  Cubierta inferior
2	W10387433	GRIDDLE -STAMPED TEFLONIZED  Comal con teflón	5	W11035411	BRACKET - LS GLASS LID  Soporte lateral	8	W11100746	KNOB ASSY ILLUM BABEL DUAL  Perilla
3	W11170839	CAST IRON GRATE LATERAL EBL  PARRILLA LATERAL	6	W11049345	30" COOKTOP DECORATED 2STD+2SUP+1SUPPOW  CUBIERTA SUPERIOR	9	W11046170	BABEL ILLUMINATI KNOB ASSY  Perilla




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10190271	SUPER BURNER CAP MATT BLACK Tapa del super quemador	9	W11037658	CENTRAL TUBING ASSY INT SIMMER - TORCH Tubo central	16	W10678288	BRACKET & REGULATOR ELEC 7U.ASM LP 11/10 Ensamble de bracket y regulador electric
2	W10356319	SUPER BURNER SAND BLASTED CLEAR Super quemador	10	W11049693	REAR TUBING ASSY CTR RGT - STD 5 Tubo trasero	17	W10354300	BRACKET - SURFACE BURNER Bracket
3	W10190267	STD BURNER CAP MATT BLACK Tapa del quemador STD	11	W11334135	TUBING,FRONT,RGT,SUPER DEF,ASSY Tubo Frontal	18	W10512963	Tubing (Regulator to Oven Valve) Tubo regulador
4	W10354371	STD BURNER (SANDBLASTED - CLEAR) Quemador STD	12	W10619922	TUBE 3/8" MANIFOLD TO REG Tubo del Manifold	19	W11297306	BRACKET, LIGHTED-KNOB Bracket
5	W11088239	SUPER POWER BURNER DOUBLE Quemador super power	13	W11038344	MANIFOLD TUBE ASSY 2STD+2SUP+1TORCH-THMS Manifold	20	W10670152	SINGLE VALVE ASM,ELECTRIC-INVELAR Valvula
6	W11037326	REAR TUBING ASSY LFT - SUP Tubo trasero	14	W11208965	IGNITER - HOT SURFACE ELEMENT Aditamento de encendido incandescente	21	W10141714	VALVE SURFACE - PROPANE Valvula
7	W11039129	FRONT TUBING ASSY STD RGT Tubo Frontal	15	W10650358	OVEN BURNER ASM-US ELECTRONIC Quemador del horno	22	W10141712	VALVE SURFACE - PROPANE Valvula
8	W11037659	CENTRAL TUBING ASSY EXT RING - TORCH Tubo central				23	W10381658	DUAL VALVE Valvula

KIT DE CONVERSIÓN A GAS NATURAL - WFR9000S		
Numero de Parte	Nombre de la pieza	Cantidad
W10118331	ORIFICE SUP BURNER	2
W10132112	ORIFICE STD BURNER	2
W10267026	ORIFICE OVEN BURNER	1
W10141712	VALVE FOR STD BURNER	2
W10141714	VALVE FOR SUP BURNER	2







<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10381605	TOP ELECTRODE 350 Bujia	10	W11046714	SWITCH HARNESS 5 POS DUAL VALVE Switch del arnes	19	9755542	Probe, Temperature Probeta
2	W10381604	TOP ELECTRODE 500 Bujia	11	W11046711	MAIN HARNESS FLAGSHIP Arnes principal	20	W11295673	BROIL ELEMENT 1500W Resistencia
3	W10391625	TOP ELECTRODE 650 Bujia	12	98005765	SWITCH DOOR Interruptor de Puerta	21	W10391629	FAN BLOWER Ventilador
4	W10391624	TOP ELECTRODE 740 Bujia	13	W11325853	LIGHTED KNOB HARNESS ASSY Arnes de la luz de perillas	22	W10174487	COOLING DUCT Conducto de enfriamiento
5	W10816149	SPARK MODULE 5 POSITIONS ASSY Modulo de encendido	14	98005896	Clip, Wire	23	W11341520	HOSE COUPLER, G3EVO Tapa
6	98005894	Clamp, Cord abrazadera	15	W10519553	Clip del cable COVER SWITCH PAPER Cubierta del switch	24	W11046716	G3EVO / BABAGE COMM HARNESS Arnes
7	W10554269	Socket - Oven Light Adaptador para foco	16	W11121700	G3EVO BABEL FLAGSHIP Display	25	W10385340	OVEN ELEMENT SUPPORT Soporte de resistencia
8	W10788320	Bulb, Light Foco del horno	17	W10511641	SWITCH HARNESS - DUAL VALVE Switch del arnes	26	W10586204	Sensor - RTD, WAKO Sensor
9	W10822899	CLIP ELECTRODE SS Clip del electrodo	18	W10696226	Jack, Meat Probe Probeta	27	W11398848	CNTL-ASM,FSR, CHARLIE BABEL MX NEW RTD Tarjeta



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11328311	TOP COVER ASSY - FULL DOOR,FIN CUBIERTA SUPERIOR	8	W11233137	DOOR END CAP LEFT Bracket del vidrio del horno	14	W11363102	LOWER DOOR STOPPER RH,FINISH Tope inferior de la puerta
2	W11049186	GASKET-SIDE, GLASS, FS Marco lateral	9	W11236228	ENDCAP-ASPIRE Bracket	15	W11112383	BRACKET SLIDE OUT SWING DOOR Soporte puerta deslizable
3	W11333372	INNER GLASS - FULL DOOR Vidrio Interno de la puerta del horno	10	W11281215	HANDLE ASM, ASPIRE 30, TAPPED Agarradera			
4	W11233135	DOOR END CAP RIGHT Bracket del vidrio del horno	11	W11283990	FS OUTER DOOR GLASS & PILLAR ASSY Vidrio Exterior de la puerta del horno			
5	W11312651	LATCH-RECEIVER Gancho de seguridad	12	W11233152	LOWER TRIM FULL OVEN DOOR-FIN Moldura inferior de la puerta del horno			
6	W11403601	GLASS BRACKET Bracket del vidrio del horno	13	W11233184	MECHANICAL STOP DOOR - BOTTOM, RH Tope inferior de la puerta			
7	W11403920	WASHER Bracket						



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11284471	BOTTOM HINGE BRACKET LH ASSY Bisagra Inferior	11	W10515063	BROILER BACK OVER ASM Ensamble cubierta del asador	20	W11318275	KICK PANEL 30", FRS, BLACK Panel inferior
2	W11312616	SPRING Resorte	12	W11167392	FRONT VERTICAL PILLAR - SWING Pilar frontal vertical	21	W11161990	COVER BROILER RGT FULL DOOR Tapa asador derecho
3	W11312650	LATCH-HOOK Gancho de seguridad	13	W11359301	TOP SWING HINGE ASSY RH Soporte de bisagra superior	22	W11161987	COVER BROILER LFT FULL DOOR Tapa asador izquierdo
4	W10500814	REAR FRAME F/S ASM Ensamble estructural posterior	14	W11172775	CROSS SUPPORT - 30" RAW Soporte transversal	23	W11344677	FOILS ASSY TOSIDE PANEL US RIGHT GRAY Panel lateral
5	W10577312	Support, Side Panel REFUERZO DE PANEL LATERAL	15	W10446524	BASE RAIL Base riel	24	W11326466	30" MAIN-BACK Respaldo Principal
6	W11344678	FOILS ASSY TOSIDE PANEL US LEFT GRAY Panel lateral	16	W10549293	SAFETY VALVE REAR COVER Guarda para valvula	25	98015363	Support, Rear Soporte trasero
7	W11082674	COUNTERSUPPORT - SWING HINGE Contrabisagra	17	W11086742	FRONT FRAME 30" FULL SWING FINISH Marco frontal	26	W11323022	COVER - REAR,NAT,FSR,30" Guarda posterior
8	W11082675	COUNTERWEIGHT GUARD Guarda contra peso	18	W11171308	SEAL OVEN DOOR SWING Sello de la puerta del horno	27	W11283324	BUSHING SWING DOOR Tope inferior de la puerta
9	98006710	Counterweight Contrapeso	19	W10605426	Panel, Side Panel lateral			
10	W11363165	TOP HINGE BRACKET RH,FINISH Soporte de bisagra superior						



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		CAVITY ASM W/LIGHT F/S - NO ES REFACCIONABLE  Ensamble de la cavidad	4	W11181059	UPPER INSULATION COVER  Cubierta aislante superior	8	W10620410	Assembly, Oven Bottom  piso del horno
2	W10902086	FLUE BOX ASM  Ensamble de chimenea	5	98004722	Clip, Cooktop Clip	9	W10132554	WIRE - INSULATION TIE  Cable
3	W11130754	Wrapper oven cavity insulation  Aislante cavidad del horno	6	W10550642	Rack, Oven Parrilla del horno	10	W11291031	30" OVEN INSULATION BACK ULTRA USA UL
			7	W11315584	KIT SLIDE OUT - SS HIGH MODELS  kit parrilla deslizable	0		Aislante cavidad del horno
						11	W10670197	Deflector, Oven Deflector del piso