


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA WGD4850HW1






# SECADORA WGD4850HW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11361424	Owners Manual
	W11355746	Quick Start Guide
	W10876312	Wiring Diagram
2	693995	Screw
3		Assembly, Timer Knob
	W11158829	White
4	8536939	Clip, Spring
5		Lint Screen
	W10717210	White
6	W10416486	Panel, Rear Console

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	90767	Screw
8	688983	Screw
9		Top
	8559800	White
10		Knob, Push To Start
	W11160348	White
11	W10436302	Timer Assembly (60 Hz.)
12		Assembly, Console W11178662
		White
13	8312709	Clip, Console

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10298336	Nut, "U"
15	3389682	Spacer, Top Panel
16	W10865758	Harness, Wiring
17	3348629	Screw
18	694419	Buzzer, Mini
19	W10420747	Switch, Rotary
20	W10446920	Switch, Push to Start

# SECADORA WGD4850HW1






# SECADORA WGD4850HW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8066217	Hinge, Top
2	343641	Screw
3	693995	Screw
4	W10841728	Seal, Spill Guard
5	3396795	Cover, Terminal Block
6	3404162	Clamp, Motor (With Shield)
7	W10571724	Panel, Rear
8	W10575896	Clip, Spring
9		Plug, Sight Hole
	8564457	White
10	W10569603	Switch, Door
11	697773	Screw
12	W10041960	Spring, Door
13	W10121316	Clamp, Motor Mount
14	341029	Clamp, Pipe
15	W10775448	Clip, Front Panel
16	W10561321	Foot, Dryer
	W10570316	Foot - Package of 4 (Not Included)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10773242	Screw
18		Cabinet
	8530603	White
19	98234	Clip, Ground
20	8066092	Lock, Front Top
21		Panel, Front
	W10664692	White
22	685203	Clip, Felt Pad
23	337189	Clip, Hinge
24	3389441	Assembly, Door Catch
25	W10823580	Seal, Door
26	W10869141	Cord, Power
27	342055	Screw
28	W10396029	Assembly, Motor
29	8066184	Pulley, Motor
30	3400500	Bolt
31	348780	Base, Motor
32	W10131364	Belt, Drive
33	696144	Strike, Door
34	691366	Idler Assembly

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
35	695737	Door, Rear
36		Door, Front
	W10714515	White
37		Handle, Door
	W10714516	White
38	W10803476	Assembly, Seal and Bearing
39	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
40	342043	Screw
41	3357011	Screw
42	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)

# SECADORA WGD4850HW1





# SECADORA WGD4850HW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute
2	W10298789	Nut, Hex
3	3388703	Washer
4	347139	Seal, Lint Chute
5	90767	Screw
6	W10389567	Shield, Exhaust
7	3392519	Fuse, Thermal (91C)
8	3387134	Thermostat
9	348197	Washer
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip, Heater Box
13	343641	Screw
14	3406022	Bracket, Bulkhead Chute
15	8530285	Box, Heater (96C)


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	8066049	Funnel, Burner
17	338906	Sensor, Radiant
18	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)
19	W10754607	Thermostat, High Limit SPST (180F)
20	489463	Screw
21	3390647	Screw
22	339956	Seal
23	W11032820	Bracket, Support
24	90296	Nut, Push On
25	W10757750	Assembly, Drum (Complete)
26	692490	Baffle, Drum (Long)
29	W10219342	Screw
27	3403636	Baffle, Drum (Short)
30	692526	Bearing, Ring
31	W10754671	Seal, Bulkhead
32	W10756057	Roller, Support
33	W10359269	Shaft, Drum Roller - Right Hand Thread
34	W10359270	Shaft, Drum Roller - Left Hand Thread
35	W10512946	Washer, Tri Ring

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
36	8578825	Bracket, Drum Light
37	3406124	Bulb, Light
38	W10214261	Socket, Light
39	3402841	Lens, Drum Light
40	3390631	Screw



# SECADORA WGD4850HW1

USE WITH TYPE 1 - NATURAL,  
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES





# SECADORA WGD4850HW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	W10366705	Screw
6	343641	Screw
7	693986	Base, Burner
8	3387057	Screw
9		Orifice, Burner
	234826	Type 1 (Natural)
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	8318277	Valve, Gas (60 Hz)
11	694421	Screw, Coil
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz (2 Terminal) (Main)
14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18	239822	Plug, Pipe Following Parts Not Illustrated
	49572A	Conversion Kit (Type 1 and 2) to Type (4)  L.P.G.



# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

Illus.

No.   Part No.   Description

72017   White

## PAINT, BULK (1 QT.)

Illus.

No.   Part No.   Description

799344   White (Uncut)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

No.   Part No.   Description

350930   White  
350938   Gray Primer

## ACCESSORY PARTS

Illus.

No.   Part No.   Description

279948   Kit, Dryer Repair  
3406839   Dry Rack  
8522199   Kit, Dryer Vent Testing