


SECADORA WGD4950HW1






SECADORA WGD4950HW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11361424	Owners Manual
	W11355746	Quick Start Guide
	W11366444	Cycle Guide
	W10876312	Wiring Diagram
2		Assembly, Control Panel
	W11178665	White
3	694419	Buzzer, Mini
4		End Cap (Left)
	W10520782	White
5	8312709	Clip, Console

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10556829	Panel, Rear (Console)
7	W10661453	Switch, Temperature
8		End Cap (Right)
	W10520780	White
9	693995	Screw
10		Lint Screen
	W10717210	White
11	8536939	Clip, Spring
12	3400818	Screw
13	688983	Screw
14	W10773242	Screw
15	3348629	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16		Top
	8559800	White
17	W10117655	Switch, Push To Start
18		Assembly, Control Knob
	W10770858	White/Metallic
19		Assembly, Timer Knob
	W10770866	White/Metallic
20	W10185981	Assembly, Timer (60 Hz.)
21	W10872688	Harness, Wiring

SECADORA WGD4950HW1






SECADORA WGD4950HW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10773242	Screw
2	3357011	Screw
3	693995	Screw
4	W10841728	Seal, Spill Guard
5	3396795	Cover, Terminal Block
6	3404162	Clamp, Motor (With Shield)
7	W10571724	Panel, Rear
8	W10575896	Clip, Spring
9	W10569603	Switch, Door
10	697773	Screw
11	342055	Screw
12	342043	Screw
13	W10561321	Foot, Dryer
14	W10041960	Spring, Door
15		Cabinet
	8530603	White
16	98234	Clip, Ground
17	8066092	Lock, Front Top

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18		Panel, Front
	W10664692	White
19	685203	Clip, Felt Pad
20	3389441	Assembly, Door Catch
21	W10823580	Seal, Door
22	343641	Screw
23	341029	Clamp, Pipe
24	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
25	696144	Strike, Door
26	695737	Door, Rear
27		Door, Outer
	W10714515	White
28		Handle, Door
	W10714516	White
29	W10803476	Assembly, Seal and Bearing
30		Plug, Hinge Hole
	8564457	White

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
31	W10869141	Cord, Power
32	W10775448	Clip, Front Panel
33	8066217	Hinge, Top
34	691366	Idler Assembly
35	W10131364	Belt, Drive
36	348780	Base, Motor
37	3400500	Bolt
38	8066184	Pulley, Motor
39	W10396029	Assembly, Motor
40	W10121316	Clamp, Motor Mount
41	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
42	337189	Clip, Hinge
43	3357011	Screw

SECADORA WGD4950HW1






SECADORA WGD4950HW1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	15	W10754607	Thermostat, High Limit SPST (180F)	26	W10359269	Shaft, Drum Roller - Right Hand Thread
2	489463	Screw	16	W11050897	Kit, Thermal Cut-Off	27	W10756057	Roller, Support
3	3388703	Washer			(includes thermostat)	28	348197	Washer
4	347139	Seal, Lint Chute	17	3390647	Screw	29	W10298789	Nut, Hex
5	90767	Screw	18	8066049	Funnel, Burner	30	W10714468	Rear Bulkhead
6	W10389567	Shield, Exhaust	19	3403636	Baffle, Drum (Short)	31	338906	Sensor, Radiant
7	3392519	Fuse, Thermal (91C)	20	90296	Nut, Push On	32	692490	Baffle, Drum (Long)
8	8578825	Bracket, Drum Light	21	W11032820	Bracket, Support	33	692526	Bearing, Ring
9	3387134	Thermostat	22	3406022	Bracket, Bulkhead Chute	34	W10219342	Screw
10	694089	Wheel, Blower	23	339956	Seal	35	W10856781	Seal, Rear Drum
11	8577230	Housing, Blower	24	W10512946	Washer, Tri Ring	36	W10757750	Assembly, Drum (Complete)
12	3398161	Clip, Heater Box	25	W10359270	Shaft, Drum Roller - Left Hand Thread	37	3406124	Bulb, Light
13	3390631	Screw				38	3402841	Lens, Drum Light
14	8530285	Box, Heater (96C)				39	W10214261	Socket, Light

SECADORA WGD4950HW1

USE WITH TYPE 1 - NATURAL,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES

1





SECADORA WGD4950HW1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)	10	8318277	Valve, Gas (60 Hz)	18	239822	Plug, Pipe Following Parts Not Illustrated
2	688617	Tube, Burner	11	694421	Screw, Coil			
3	694298	Bracket, Ignitor	12	694538	Bracket, Coil		49572A	Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
4	686590	Ignitor	13	694540	Coil, 60 Hz (2 Terminal) (Main)			
5	W10366705	Screw	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			
6	343641	Screw	15	694424	Leak, Limiter			
7	693986	Base, Burner	16	694423	Screw, Regulator Adjustment			
8	3387057	Screw	17	694422	Spring, Regulator			
9		Orifice, Burner						
	234826	Type 1 (Natural)						
	229742	Type 4 (Butane)						
	234868	Type 4 (Propane)						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

Illus.

No. Part No. Description

72017 White

PAINT, BULK (1 QT.)

Illus.

No. Part No. Description

799344 White (Uncut)

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

No. Part No. Description

350930 White
350938 Gray Primer

ACCESSORY PARTS

Illus.

No. Part No. Description

279948 Kit, Dryer Repair
3406839 Dry Rack
8522199 Kit, Dryer Vent Testing