


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9	3936144	Plug, Terminal	23	W10012810	Rast, Wheel Assy. (Service Only With Item. 28)
	W10110851	Use & Care Guide	10	94613	Terminal			
	W10110638	Tech Sheet	11	3390647	Screw, 8-18 x 1/2	24	W10012460	Detent Wheel (Service Only With Item. 28)
	W10111226	Guide, Quick Start	12	W10112267	Foam-Seal			
2		Top	13	W10030070	Array-Power	25	W10071240	Harness, Communication
	8519251	White	14	3936150	Connector, 7-Circuit	26	W10012820	Knob, Spring (Service Only With Item. 28)
	8579997	Black	15	3395683	Connector, (Motor)			
	8519252	Biscuit	16	8281225	Screw, 8-18 x 1/2	27		Knob, Control (Includes: Item. 21)
	W10114785	Ultimate Silver	17	2203186	Connector, 5-Circuit		W10116702	White
3	8579737	Harness, Main	18	W10031430	User-Interface (Right)		W10116705	Black
4		Panel, Console (Includes Illus: 20,21,22,27,28.)	19	W10048210	User-Interface Center (Includes Illus: 13.)		W10116703	Biscuit
	W10116695	White	20	W10012430	Encoder-Wheel		W10116706	Blue
	W10116698	Black	21	W10012440	Retainer-Snap	28	280230	Encoder, Wheel Kit (Includes Items: 23, 24 & 26)
	W10116696	Biscuit	22	W10012410	Knob, LightRing (Includes: Illus. 21)			
	W10116699	White/Blue				29	W10112268	Clip-Harness (4)
	W10116697	Ultimate Silver				30	3391018	Tie, Cable
5	3394427	Clip, Harness						
6	W10006840	Bracket, Console (Includes No.12)						
7	353424	Connector, Sensor						
8	94614	Terminal						




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool WGD9400SW0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8317340	Cover, Terminal Block	16	3394081	Wire, Belt Switch	51		Front Panel (Includes Illus. 44)
2	3390814	Screw, 8-18 x 3/8	17	8564132	Sound Panel		8578388	White
3	697776	Screw, 10-32 x 5/8 (Ground)	18	233520	Washer, Thrust		8578936	Black
4		Panel, Side (R.H.)	19	8574875	Assembly, Door Switch		8577910	Biscuit
	8578450	White	20	690997	Tri Ring		8578940	Ultimate Silver
	W10095490	Black	21	8066115	Cover-Plate	52	696144	Strike, Door (2)
	8578451	Biscuit	22	8529053	Ramp, Door	55	8579736	Harness, Digital Interface
	W10095480	Ultimate Silver	24	693995	Screw, 8-18 x 3/8	56	8563727	Bracket, Control
5	3394881	Switch, Broken Belt	27	8538263	Motor Assembly 60 HZ.	57	W10110641	Control Board
6	3357011	Screw, 10-16 x 1/2	28	3398948	Wire, Jumper (Broken Belt Switch)	59	3400826	Screw, 8-18 x 3/4
7		Panel, Side (L.H.)	29	8578220	Pulley 60 HZ.	61		Toe, Panel
	8578437	White	30	3387610	Belt, Drive		W10116271	White
	W10095450	Black	31	8529757	Bracket, Burner		W10116273	Black
	8578438	Biscuit	32	3387118	Bracket, Motor		W10116272	Biscuit
	W10095440	Ultimate Silver	33	3401401	Cord, Power		W10116277	Ultimate Silver
8	3392100	Foot, Dryer	34	49026	4" - 90° Elbow	62	8519219	Panel, Rear
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	36	8563747	Exhaust Pipe & Bracket	63	692400	Nut, Push-In
9	660658	Clamp, Motor (2)	37	8563750	Exhaust Pipe (Short)	64	343641	Screw, 10-16 x 1/2
10	3387374	Spring, Idler	38	8563749	Exhaust Pipe (Long)	Optional Parts Not Included		
11	3389420	Retainer, Idler	39	3388674	Idler Bracket	Dryer Exhaust Kit		
12		Plug, Multivent	42	98129	Screw, 6-20 x 1 1/16	(For Side & Bottom Venting)		
	697750	White						
	3388309	Black						
	3388311	Biscuit	43	3390647				
	8579115	Ultimate Silver	44	3387242	Seal, Front Panel	66	279818	White
13	3388672	Pulley Assembly	45	3393008	Screw, 10-16 x 1/2		279820	Black
14	3978776	Bracket, Gas Pipe	46	8519459	Clip, Toe Panel		279925	Biscuit
			50	8519207	Base, Cabinet		280171	Ultimate Silver

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST






Secadora Whirlpool WGD9400SW0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	17	8520836	Bulkhead, Rear	39	3394986	Spring, Lint
2	8066208	Clip-Spring	18	3387459	Washer, Support			Screen Door
3	3394984	Door, Lint Screen	19	8575325	Shaft, L.H. Thread	41	695240	Screw, 8-18 x 1/2
4	3406653	Harness, Sensor	20	690997	Ring, Tri	42	8577274	Thermistor
5	3394346	Air Duct Assembly	21	8536973	Roller, Support	43	487909	Screw, 8-15 x 1/2
6	697813	Seal, Outlet Housing	22	8563745	Exhaust Pipe	44	8544362	Housing, Blower
7	697814	Seal, Drum Front	23	3394985	Housing, Outlet	45	8066168	Lint Duct Assembly
8	3934666	Nut, 3/8 x 16(R.H.)	24	8573713	Thermal, Cut-Off	46	8573824	Funnel, Burner
9	8066086	Drum Hole Plug	25	697282	Complete Drum Assembly	47	8573028	Thermostat, High-Limit 205°F (96°C)
10	3402841	Lens, Drum Light	26	W10109200	Screw, 11-16 x 3/4	48	338906	Sensor, Radiant
11	359625	Screw, 8-18 x 1/2	27	697694	Seal, Drum	49	489463	Screw, 8-18 x 5/8
12	8572105	Clip, Exhaust Pipe	29	90767	Screw, 8-18 x 3/8	50	3401710	Jumper, TCO Hi-Limit
13	8533971	Screw, 8-18 x 5/16	30	8519221	Channel Bracket, Rear Bulkhead (2)	51	3387230	Screw, 10-16 x 1
14	8529007	Plug, Rear Bulkhead	31	8571651	Bracket, Upper Rear Bulkhead	53	697693	Baffle, Drum
15	693995	Screw, 8-18 x 3/8	33	3406124	Bulb, Light	54	8519245	Bulkhead, Front
16	W10001120	Nut, 3/8-16 (L.H.)	34	3387223	Electrode, Sensor	58	8299979	Grill, Outlet
			35	3977373	Bracket, Drum Light	60	697770	Seal, Cover Plate
			36	3403634	Socket Assembly	64	8572268	Lint, Screen
			37	697772	Wheel, Blower			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**USE WITH TYPE 1 - NATURAL
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool WGD9400SW0


**USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES**

Illus. No.	Part No.	DESCRIPTION
1	8576353	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner 15418 Type 1 15422 Type 4 (Butane) 234867 Type 4 (Propane)
10	8281914	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8-18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

8576846 Conversion Kit
(Type 1)
to Type (4) LPG).

Secadora Whirlpool WGD9400SW0



Illus. No.	Part No.	DESCRIPTION
1	W10085210 White W10085230 Silver	Label, Hinge Hole
2	8577250	Door Hinge Assembly
3	W10017850	Screw, 10-24 x 3/64
4	9742177	Screw, 8-18 x 5/8
5	W10048910	Screw-Plug
6	8577821	Seal-Door
7	W10047960 Chrome W10048070 Black W10048080 Gold W10048010 White/Blue	Handle, Ring & Pad Assembly
8	3393008	Screw, 10-16 x 1/2
9	8579520 Chrome 8579521 Gold 8579514 White/Blue	Door Assembly (Outer)

Illus. No.	Part No.	DESCRIPTION
10	8578229	Door Assembly (Inner) (Includes Illus. 12)
11	355515	Screw, 8-18 x 11/16
12	3389441	Door Catch Assembly
13	8519356	Retainer-Window (Upper)
14	8519354	Retainer-Window (Lower)
15	8519353	Gasket, Window
16	8578153	Cover-Hinge, Stationary (LH) (Following Parts Not Included)
	8578152	Stationary (RH)

Illus. No.	Part No.	DESCRIPTION
17	8566254	Window
18	8579460	Clip-Trim (2)
19	W10107070 Chrome W10107120 Black W10107130 Biscuit W10099210 White/Blue W10107140 Ultimate Silver	Tear-drop Trim & Clip Assembly
20	W10074630	Door Shield
21	8578157	Door, Intermediate
22	8578156	Door Mask
23	8578155	Door Screen
24	3393258	Screw, 10-16 x 3/8
25	8580116	Pad-Handle
26	W10059060	Clip-Trim (6)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: WGD9400SW0, WGD9400SB0, WGD9400ST0, WGD9400SZ0, WGD9400SU0
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	72302	Black
	4392899	Biscuit
	8212605	Ultimate Silver

PAINT, PRESSURIZED SPRAY

(12 oz.)

	350930	White
	786020	Black
	4392901	Biscuit
	350938	Primer, Gray

PAINT, BULK (1 qt.)

	799344	White (Uncut)
	4392900	Biscuit (Uncut)
	786032	Black (Uncut)

ACCESSORY PARTS

	8529894	Kit, Hold Down
	8579666A	Kit, Door Reversing
	8541503	Kit, Stack Assembly
	80047	Kit, Dryer Repair
	8521957	Dry Rack