



## **SIDE BY SIDE REFRIGERATOR**


### **MODELS:**

WRS312SNHW00 (White)

WRS312SNHB00 (Black)

WRS312SNHM00 (Stainless Steel)

# REFRIGERADOR WRS312SNH



# REFRIGERADOR WRS312SNH


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9		Hinge, Top	17		Grille
	W11105301	Use and Care Guide		W10922200	White (Refrigerator)		W10920729	White
	W10714502	Tech Sheet		W10922201	White (Freezer)		W10920726	Black
	W11090503	Energy Guide		W10922216	Black (Refrigerator)		W10907263	Grey
2		Assembly, Roller		W10922217	Black (Freezer)	18	W10308750	Screw (White)
	W10304660	Left Hand		W10900868	Grey (Refrigerator)		W10308751	Screw (Black)
	W10304659	Right Hand		W10900869	Grey (Freezer)	19		Cabinet (Not A Servicable Part)
3	W10141645	Screw	10	W11095731	Closer, Door (Freezer)	20	W10905504	Closer, Lower Cam Door (Refrigerator)
4	2150304	Roller	11	488500	Screw	21	489464	Screw
5	2262072	Axle, Roller	12	W10142234	Screw	22	2304888	Fitting, Drain
6	2155013	Clip, Grille	13	W11093938	Assembly, Bottom Hinge (Freezer)	23	W10153550	Extension, Drain Fitting
7	W11036715	Plate, Screw (Refrigerator)	14	3400113	Screw	24	W10898351	Cover, Unit
	W10904380	Plate, Screw (Freezer)	15	2152958	Screw	25	W11097327	Assembly, Bottom Hinge (Refrigerator)
8	W11087168	Clip, Roller	16		Filler, Wrapper	26	549193	Clamp, Power Cord
				W10283959	White			
				W10283960	Black			
				W10283961	Grey			

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# REFRIGERADOR WRS312SNH






# REFRIGERADOR WRS312SNH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10166130	Lens, Light (Includes Gasket)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
3	W11026015	Control, Electronic
4	1118894	Switch, Rocker Arm
5	W10903996	Diffuser, Air

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10805744	Lamp, LED
7	W10384183	Thermistor
8	W10900030	Cover, Light
9	W10352518	Socket, Light

# REFRIGERADOR WRS312SNH



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

# REFRIGERADOR WRS312SNH

Illus.  
No.   Part No.   Description

1 W11041180 Assembly, Cover  
2 W11046494 Pan, Crisper  
3 W11046495 Pan, Meat


Illus.  
No.   Part No.   Description

4 W10173126 Assembly, Shelf Stud  
5 W10191954 Screw

Illus.  
No.   Part No.   Description

6 W11135529 Assembly, Shelf  
7 W10904001 Holder, Pan

# REFRIGERADOR WRS312SNH





Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



# REFRIGERADOR WRS312SNH


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	6	2309758	Bin, Freezer	13	W10318949	Shelf, Wire
2	W10318953	Shelf, Wire	7	W10130299	Cup, Shelf	14	3400893	Screw
3	2155597	Socket, Light	8	W10191954	Screw	15	841180	Tray, Ice Cube
4	1115373	Switch, Rocker Arm (Freezer)	9	2196208	Assembly, Stud	16	2212340	Cover, Light Lens
5	W10318952	Shelf, Wire	10	W10318960	Shelf, Wire (Short)			
			11	W10805744	Lamp, LED			
			12	2315163	Clip, Air Duct			

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# REFRIGERADOR WRS312SNH



Distribuidor Autorizado


**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

# REFRIGERADOR WRS312SNH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Door Gasket)	5		Handle	13	W10142283	Screw (White)
	W10912366	White		W11045527	White		W10308487	Screw (Black)
	W10912374	Black		W11045528	Black		W10308489	Screw (Grey)
	W10912313	Stainless Steel		W11045530	Stainless	14		Bumper, Door
2	2256101	Door, Compartment	6	2200087	Thimble		W10407175	White
3	W10900538	Bin, Door	7	2309941	Trivet		W10407187	Black
4		Gasket, Door	8	W10900464	Thimble, Cam		W10407188	Grey
	W10912372	Beige	9	489420	Screw			
	W10912379	Black	10		Bracket, Door Stop			
	W10912318	Grey		W10900463	Black			
			11	W10884773	Badge			
			12	W10460893	Screw			

# REFRIGERADOR WRS312SNH




# REFRIGERADOR WRS312SNH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes item 8)
	W11023799	White
	W10898296	Black
	W10905818	Stainless
2		Handle
	W11045527	White
	W11045528	Black
	W11045530	Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
3	2200087	Thimble
4		Bracket, Door Stop
	W10900531	Black
5	W10296816	Screw
6	2309717	Trim, Door
7	W10296804	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		Gasket, Door
	W10911504	Black
	W10911461	Grey
9	W10900532	Thimble, Cam
10	W10170540	Screw

# REFRIGERADOR WRS312SNH



# REFRIGERADOR WRS312SNH

Illus.  
No.    Part No.    Description

1	W10912148	Scroll, Fan
2	W10188846	Retainer, Fan Motor
3	489478	Screw
4		Support, Fan Scroll
	2203596	Left Hand
	2203595	Right Hand
5	2203592	Duct, Freezer Air


Illus.  
No.    Part No.    Description

6	2203875	Gasket, Air Duct
7	2315549	Motor, Fan
8	2169142	Blade, Fan
9	2304241	Gasket
10	2176759	Grommet, Motor
11	W10142292	Screw

Illus.  
No.    Part No.    Description

12	W10911770	Harness, Evaporator Fan (Includes Thermal Fuse)
13	2155788	Gasket, Scroll Assembly
14	W10463012	Cover, Evaporator

# REFRIGERADOR WRS312SNH







# REFRIGERADOR WRS312SNH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	2212996	Strap, Bale	19	W10897557	Tray, Evaporator	35	W11189542	Assembly, Precooler Formed
2	2225834	Blade, Fan	20	W10194474	Assembly, Heat Shield and Drain Pan			FOLLOWING PARTS NOT ILLUSTRATED
3	W10904626	Assembly, Condenser	21	W10771114	Drier			
4	W10905882	Rail, Unit Mounting	22	489473	Screw	978025		Valve, Access (1/4")
5	489396	Clip	23	W10905881	Frame, Unit Mounting	978026		Valve, Access (5/16")
6	8533993	Screw	24	489464	Screw	978027		Valve, Access (3/8")
7	W10667072	Harness, Unit (Includes Power Cord)	25	2181929	Bracket, Fan Mounting	978029		Valve, Access (5/8")
8	2161302	Sleeve	26	W10495967	Heater, Defrost	978030		Valve, Access (3/4")
9	489427	Screw	27	2161324	Clip, Defrost Heater	876764		Valve, Access (3/16")
10	W10745338	Tube, Suction	28	W10253005	Compressor (Also Order 876765 Tube Kit)			REFRIGERANT CHARGE
11	2311725	Clip, Condenser	29	W10836504	Grommet, Compressor			5.5 oz (R-134A)
12	W10350564	Capacitor						
13	2325479	Tube, Process	30	489340	Bolt			
14	W10197428	Device, Combination Start (Start Relay and Overload)	31	W10897567	Baffle, Air			
15	8281232	Screw	32	2263990	Tie, Wire			
16	2188822	Evaporator	33	W10905883	Assembly, Unit Cover (Bottom)			
17	2161324	Clip, Defrost Heater	34	1105612	Guard, Fan			
18	W10522629	Motor, Condenser Fan						

# OPTIONAL PARTS

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

## MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet
	W10300794	Kit, Handle Installation
	W10715708	Ice Maker Assembly (ECKMF95)

## TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key