



SIDE BY SIDE REFRIGERATOR


MODELS:

WRS586FLDW00 (White)

WRS586FLDB00 (Black)

WRS586FLDM00 (Monochromatic Stainless)

REFRIGERADOR WRS586FLD



REFRIGERADOR WRS586FLD


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Bottom (Freezer)	24		Closer, Door (Freezer)
	W10632884	Use & Care Guide		W10249940	White		W10770896	White
	W10678659	Service and Wiring Sheet		W10249941	Black		W10770895	Black
	W10922042	Energy Guide		W10249943	Grey		W10770893	Grey
2	2150304	Roller	16		Hinge, Bottom (Refrigerator)	25	W10001250	Screw
3	W10297485	Screw		W10666898	White	26	W10279882	Tube, Filter Inlet
4	12477102	Roller		W10666897	Black	27	W10279884	Tube, Filter Outlet
5	12477202	Axle, Roller		W10666895	Grey	28	W10370680	Fitting, Drain
6	981125	Rivet, Roller	17		Closer, Door (Refrigerator)	29	12957702	Lid, HV Box
7	W10379525	Tube, Drain		W10738913	White	30	W10738538	Control, Electronic
8	W10900758	Bracket, Foot		W10738914	Black	31		Cabinet (Not A Serviceable Part)
9	W10141622	Brake, Roller		W10738911	Grey	32	W10247993	Box, Control
10	W10308750	Screw (White)	18	W10141645	Screw	33	W10238092	Tube, Water
	W10308751	Screw (Black)	19	549193	Clamp, Power Cord	34	W10237915	Bracket, Water Valve
11	W10498992	Valve, Inlet	20	W10333887	Cover, Unit	35	W10141625	Screw
12		Hinge, Top (Freezer)	21		Filler, Wrapper	36	2223388	Clip, Axle Retainer
	W10673330	White		12587703W	White	37	W10341320	Assembly, Dual Water Valve
	W10673329	Black		12587703B	Black	38	W10347034	Assembly, Fill Tube
	W10673327	Grey		12587703AP	Grey			
13		Hinge, Top (Refrigerator)	22		Grille			
	W10611068	White		W10713160	White			
	W10611067	Black		W10713158	Black			
	W10611065	Grey		W10713153	Grey			
14	W10142283	Screw (White)	23	W10142234	Screw			
	W10308487	Screw (Black)						
	W10308489	Screw (Grey)						

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRS586FLD



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



REFRIGERADOR WRS586FLD


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	10	W10141632	Screw	21	W10457603	Cover, Air Filter
2	W10735398	Filter, Water	11	W10271543	Connector, Water Tube	22	2171931	Body, Valve Tube
3	W10300482	Cover, Water Filter	12	W10440814	Socket, Light			
4	W10750143	Assembly, Air Diffuser	13	W10280420	Lens, Top Light			
5	W10457601	Cover, Air Diffuser	14	2162085	Socket, Light			
6	W10656773	Switch, Light	15	W10366790	Reservoir			
7	W10253300	Assembly, Top Light Wire	16	W10574850	Lamp, LED			
8	W10280178	Trim, Light	17	W10269099	Lens, Light			
9	2223680	Shield, Heat	18	W10280385	Thermistor			
			19	W10425252	Cover, Thermistor			
			20	W10394053	Housing, Water Filter			

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRS586FLD






REFRIGERADOR WRS586FLD

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10463648	Shelf, Snack Pan
2	W10281628	Trim, Handle
3	W10282883	Slide, Humidity
4	W10282880	Housing, Humidity

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10463650	Assembly, Cover
6	W10256770	Pan, Snack
7	W10628713	Roller, Pan
8	W10628712	Axle, Roller

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10278653	Pan, Crisper
10	W10256774	Pan, Meat
11	W10309635	Trim, Handle
12	W10309636	Trim, Handle
13	W10774040	Assembly, Shelf

REFRIGERADOR WRS586FLD



Distribuidor Autorizado



Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRS586FLD

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10463653	Assembly, Cover
3	W10774055	Shelf Assembly, Upper
4	W10280386	Thermistor
5	W10774058	Shelf Assembly, Lower

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10260985	Pan, Freezer
7	W10628713	Roller, Pan
8	W10628712	Axle, Roller
9	W10281630	Trim, Handle
10	W10655771	Switch, Rocker Arm
11	2162085	Socket, Light


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10820003	Lamp, Led
13	W10655772	Switch, Rocker Arm
14	W10425252	Cover, Thermistor
15	W10269101	Lens
16	2155597	Socket, Light

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRS586FLD



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRS586FLD

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10774957	Ice Container (Complete)
2	W10693542	Assembly, Latch
3	2220458	Coupling, Bottom
4	W10258544	Shaft, Drive
5	W10754509	Spring, Coupling

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10293211	Assembly, Mounting Plate
7	2198628	Seal
8	W10291905	Gasket
9	2212370	Washer
10	W10225313	Motor, Dispenser


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10287594	Cover, Container
12	W10122576	Assembly, Complete Icemaker
13	W10747726	Bracket, Mounting
14	W10765378	Assembly, Motor Box
15	W10166854	Gasket

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRS586FLD




REFRIGERADOR WRS586FLD

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)
	W11045217	White
	W10334483	Black
	W10644353	Stainless
2	W10710203	Bin, Gallon Door
3	W10296816	Screw
4	W10451873	Bin, Shallow Door
5		Gasket, Door
	W10247884	Beige
	W10249912	Black
	W10249916	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Handle
	W10713677	White
	W10713678	Black
	W10678291	Stainless
7	2200086	Thimble, Top
8	W10460893	Screw
9		Closer, Upper Cam Door
	W10248011	White
	W10257201	Black
	W10257203	Grey
10	W10296804	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10888898	Bracket, Door Stop
12		Nameplate
	W10511975	White
	W10511972	Grey
13	W10010140	Set Screw (Silver)
14		Cover, Door Stop
	W10789144	White
	W10789145	Black
	W10789147	Grey

REFRIGERADOR WRS586FLD




REFRIGERADOR WRS586FLD

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 8 And Dispenser Front Parts)
	W10701907	White
	W10701908	Black
	W10701909	Stainless
2		Handle
	W10713677	White
	W10713678	Black
	W10678291	Stainless
3	2200086	Thimble, Top
4	W10296804	Screw
5	W10460893	Screw
6	W10430639	Bin, Door
7	W10296816	Screw
8		Gasket, Door
	W10247885	Beige
	W10249913	Black
	W10249917	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9		Closer, Upper Cam Door
	W10248015	White
	W10257204	Black
	W10257206	Grey
10	W10247907	Bracket, Door Stop
11	W10010140	Set Screw (Silver)
12		Cover, Door Stop
	W10632059	White
	W10632060	Black
	W10632062	Grey
13	W10331749	Pin, Door
14	2198635	Spring, Door
15	W10258502	Cover, Emitter
16	W10518659	Board, Emitter Circuit
17	W10363396	Cover, Receiver
18	W10518658	Board, Receiver Circuit

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10258520	Door, Emitter
20	W10258540	Slide, Icemaker Shut Off
21	W10411699	Harness, Emitter and Receiver

REFRIGERADOR WRS586FLD






REFRIGERADOR WRS586FLD

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Wall, Dispenser False
	W10254254	White
	W10254255	Black
	W10276226	Satina
2		Grate, Drip Tray
	W10276209	Stainless
3	W10174827	Bracket, Ice Door
4	W10435760	Guide, Ice
5	W10205978	Motor, Dispenser
6	W10781994	Assembly, Separator
7	W10346124	Support, Ice Door
8	4449745	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9		Ring, Trim
	W10276265	White
	W10335549	Black
	W10448931	Chromium Frost
10	W10238083	Assembly, LED
11	W10744624	User Interface Assembly
12		Pad, Ice and Water
	W10370583	White
	W10370577	Black
	W10370582	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13		Tray, Drip
	W10254258	White
	W10254259	Black
	W10276225	Satina
14		Cover, Front
	W10458867	Black
15	W10386778	Assembly, Water Fitting
16	W10876364	Tube, Water

REFRIGERADOR WRS586FLD






REFRIGERADOR WRS586FLD

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	Scroll, Fan
2	2223733	Retainer, Fan Motor
3	W10550199	Duct, Upper Air
4	W10260437	Bi-Metal, Defrost
5	W10260378	Duct, Freezer Air
6	W10001260	Screw
7	W10556724	Motor, Fan

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	2169142	Blade, Fan
9	W10240370	Gasket, Evaporator Cover
10	W10449920	Grommet, Motor
11	W10369602	Clip, Evaporator Cover
12	W10679946	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10142292	Screw
14	W10388268	Cover, Evaporator
15	W10260382	Cover, Light
16	W10820003	Lamp, Led
17	2162085	Socket, Light
18	W10331728	Clip, Air Duct

REFRIGERADOR WRS586FLD



REFRIGERADOR WRS586FLD

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271541	Connector, Union	15	2205813	Tie, Wire	29	2183042	Grommet
2	2225834	Blade, Fan	16	2188822	Evaporator	30	2304287	Clip
3	W10276899	Condenser	17	2161324	Clip, Defrost Heater	31	2169104	Sealer, Insulation
4	W10142255	Screw	18	W10508362	Motor, Condenser			FOLLOWING PARTS NOT ILLUSTRATED
5	W10236396	Strap, Compressor	19	W10703218	Tray, Evaporator			
6	W10171469	Screw	20	W10274575	Shield, Heat	978025		Valve, Access
7	W10277958	Connector, Water	21	W10771114	Drier	978026		Valve, Access
8	W10303521	Sleeve	22	W10679948	Assembly, Unit Wire	978027		Valve, Access
9	W10142287	Bolt	23	W10277704	Basepan	978028		Valve, Access
10	W10815861	Clip, Bottom Cover	24	W10242407	Cord, Power	978029		Valve, Access
11	W10219381	Tube, Suction	25	W10251467	Baffle, Air	978030		Valve, Access
12	W10248621	Clip, Condenser	26	W10495967	Heater, Defrost	876764		Valve, Access
13	W10186719	Assembly, Inverter Box	27	W10278140	Cover, Condenser (Bottom)			REFRIGERANT CHARGE
14	2325479	Tube, Process	28	W10313831	Compressor			5.3 oz. (R-134A)

OPTIONAL PARTS

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque
	8171357	Graphite

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	80051	Graphite

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque
	8171358	Graphite

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10300794	Handle Installation Kit
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	4318168	Sealer
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key